

# Pioneer

## Service Manual



KRP-600P

ORDER NO.  
**ARP3504**

PLASMA DISPLAY

# KRP-600P

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
KRP-600P	WYSIXK5	AC 220 V to 240 V	
KRP-600P	WYS5	AC 220 V to 240 V	
KRP-600P	WA5	AC 220 V to 240 V	



For details, refer to "Important Check Points for good servicing".

**PIONEER CORPORATION** 4-1, Meguro 1-chome, Meguro-ku, Tokyo 153-8654, Japan  
**PIONEER ELECTRONICS (USA) INC.** P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.  
**PIONEER EUROPE NV** Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium  
**PIONEER ELECTRONICS ASIACENTRE PTE. LTD.** 253 Alexandra Road, #04-01, Singapore 159936  
©PIONEER CORPORATION 2008

T-IZS-001 SEPT. 2008 Printed in Japan

# SAFETY INFORMATION



This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.



## WARNING

This product contains certain electrical parts contain chemicals which are known to the State of California to cause cancer, birth defects or other reproductive harm.

Health & Safety Code Section 25249.6 - Proposition 65



## NOTICE

(FOR CANADIAN MODEL ONLY)

Fuse symbols  (fast operating fuse) and/or  (slow operating fuse) on PCB indicate that replacement parts must be of identical designation.

## REMARQUE

(POUR MODÈLE CANADIEN SEULEMENT)

Les symboles de fusible  (fusible de type rapide) et/ou  (fusible de type lent) sur CCI indiquent que les pièces de remplacement doivent avoir la même désignation.

## SAFETY PRECAUTIONS

NOTICE : Comply with all cautions and safety related notes located on or inside the cabinet and on the chassis.

The following precautions should be observed :

1. When service is required, even though the PDP UNIT an isolation transformer should be inserted between the power line and the set in safety before any service is performed.
2. When replacing a chassis in the set, all the protective devices must be put back in place, such as barriers, nonmetallic knobs, adjustment and compartment covershields, isolation resistor-capacitor, etc.
3. When service is required, observe the original lead dress. Extra precaution should be taken to assure correct lead dress in the high voltage circuitry area.
4. Always use the manufacture's replacement components. Especially critical components as indicated on the circuit diagram should not be replaced by other manufacture's. Furthermore where a short circuit has occurred, replace those components that indicate evidence of overheating.
5. Before returning a serviced set to the customer, the service technician must thoroughly test the unit to be certain that it is completely safe to operate without danger of electrical shock, and be sure that no protective device built into the set by the manufacture has become defective, or inadvertently defeated during servicing. Therefore, the following checks should be performed for the continued protection of the customer and servicetechnician.

6. Perform the following precautions against unwanted radiation and rise in internal temperature.
  - Always return the internal wiring to the original styling.
  - Attach parts (Gasket, Ferrite Core, Ground, Rear Cover, Shield Case etc.) surely after disassembly.
7. Perform the following precautions for the PDP panel.
  - When the front case is removed, make sure nothing hits the panel face, panel corner, and panel edge (so that the glass does not break).
  - Make sure that the panel vent does not break. (Check that the cover is attached.)
  - Handle the FPC connected to the panel carefully. Twisting or pulling the FPC when connecting it to the connector will cause it to peel off from the panel.
8. Pay attention to the following.
  - Pay extreme caution when the front case and rear panel are removed because this may cause a high risk of disturbance to TVs and radios in the surrounding.

### Leakage Current Cold Check

With the AC plug removed from an AC power source, place a jumper across the two plug prongs. Turn the AC power switch on. Using an insulation tester (DC 500V), connect one lead to the jumpered AC plug and touch the other lead to each exposed metal part (input/output terminals, screwheads, metal overlays, control shafts, etc.), particularly any exposed metal part having a return path to the chassis. Exposed metal parts having a return path to the chassis should have a minimum resistor reading of 4 MΩ.


The below 4 MΩ resistor value indicate an abnormality which require corrective action. Exposed metal parts not having a return path to the chassis will indicate an open circuit.

### Leakage Current Hot Check

Plug the AC line cord directly into an AC power source (do not use an isolation transformer for this check).

Turn the AC power switch on.

Using a "Leakage Current Tester (Simpson Model 229 equivalent)", measure for current from all exposed metal parts of the cabinet (input/output terminals, screwheads, metal overlays, control shaft, etc.), particularly any exposed metal part having a return path to the chassis, to a known earth ground (water pipe, conduit, etc.). Any current measured must not exceed 1 mA.



### AC Leakage Test

**ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE SET TO THE CUSTOMER.**

### PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in PIONEER set have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a ⚠ on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which dose not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

A

## [Important Check Points for Good Servicing]

In this manual, procedures that must be performed during repairs are marked with the below symbol.  
Please be sure to confirm and follow these procedures.

### 1. Product safety



Please conform to product regulations (such as safety and radiation regulations), and maintain a safe servicing environment by following the safety instructions described in this manual.

- ① Use specified parts for repair.

Use genuine parts. Be sure to use important parts for safety.

- ② Do not perform modifications without proper instructions.

Please follow the specified safety methods when modification (addition/change of parts) is required due to interferences such as radio/TV interference and foreign noise.

- ③ Make sure the soldering of repaired locations is properly performed.

When you solder while repairing, please be sure that there are no cold solder and other debris.  
Soldering should be finished with the proper quantity. (Refer to the example)

- ④ Make sure the screws are tightly fastened.

Please be sure that all screws are fastened, and that there are no loose screws.

- ⑤ Make sure each connectors are correctly inserted.

Please be sure that all connectors are inserted, and that there are no imperfect insertion.

- ⑥ Make sure the wiring cables are set to their original state.

Please replace the wiring and cables to the original state after repairs.  
In addition, be sure that there are no pinched wires, etc.

- ⑦ Make sure screws and soldering scraps do not remain inside the product.

Please check that neither solder debris nor screws remain inside the product.

- ⑧ There should be no semi-broken wires, scratches, melting, etc. on the coating of the power cord.

Damaged power cords may lead to fire accidents, so please be sure that there are no damages.  
If you find a damaged power cord, please exchange it with a suitable one.

- ⑨ There should be no spark traces or similar marks on the power plug.

When spark traces or similar marks are found on the power supply plug, please check the connection and advise on secure connections and suitable usage. Please exchange the power cord if necessary.

- ⑩ Safe environment should be secured during servicing.

When you perform repairs, please pay attention to static electricity, furniture, household articles, etc. in order to prevent injuries.  
Please pay attention to your surroundings and repair safely.

### 2. Adjustments



To keep the original performance of the products, optimum adjustments and confirmation of characteristics within specification.  
Adjustments should be performed in accordance with the procedures/instructions described in this manual.

### 3. Lubricants, Glues, and Replacement parts



Use grease and adhesives that are equal to the specified substance.  
Make sure the proper amount is applied.

### 4. Cleaning



For parts that require cleaning, such as optical pickups, tape deck heads, lenses and mirrors used in projection monitors, proper cleaning should be performed to restore their performances.

### 5. Shipping mode and Shipping screws



To protect products from damages or failures during transit, the shipping mode should be set or the shipping screws should be installed before shipment. Please be sure to follow this method especially if it is specified in this manual.

F



# CONTENTS

SAFETY INFORMATION.....	2	
1. SERVICE PRECAUTIONS.....	6	
1.1 NOTES ON SOLDERING.....	6	A
1.2 NOTES SPECIFIC TO THIS PRODUCT.....	6	
1.3 CHARGED SECTION AND HIGH VOLTAGE GENERATING POINT.....	7	
2. SPECIFICATIONS.....	8	
2.1 ACCESSORIES.....	8	
2.2 SPECIFICATIONS.....	10	
2.3 PANEL FACILITIES.....	11	
3. BASIC ITEMS FOR SERVICE.....	14	
3.1 CHECK POINTS AFTER SERVICING.....	14	
3.2 QUICK REFERENCE.....	15	
3.3 PCB LOCATIONS.....	17	
4. BLOCK DIAGRAM.....	18	
4.1 OVERALL WIRING DIAGRAM (1/2).....	18	B
4.2 OVERALL WIRING DIAGRAM (2/2).....	20	
4.3 OVERALL BLOCK DIAGRAM (1/2).....	22	
4.4 OVERALL BLOCK DIAGRAM (2/2).....	24	
4.5 POWER SUPPLY UNIT.....	26	
4.6 60F X DRIVE ASSY.....	28	
4.7 60F Y DRIVE, 60F SCAN A, B, C and D ASSYS.....	29	
4.8 POWER SUPPLY BLOCK of 60F X, Y DRIVE and 60F SCAN A, B, C and D ASSYS.....	30	
4.9 60F ADDRESS L and S ASSYS.....	31	
4.10 60F DIGITAL ASSY.....	32	
4.11 POWER SUPPLY BLOCK of MAIN and AUDIO ASSYS.....	33	
5. DIAGNOSIS.....	34	
5.1 POWER SUPPLY OPERATION.....	34	C
5.2 DIAGNOSIS FLOWCHART OF FAILURE ANALYSIS.....	42	
5.3 DIAGNOSIS OF PD (POWER-DOWN).....	54	
5.4 DIAGNOSIS OF SD (SHUTDOWN).....	58	
5.5 NON-FAILURE INFORMATION.....	62	
5.6 OUTLINE OF THE OPERATION.....	63	
5.7 OUTLINE OF RS-232C COMMAND.....	68	
5.8 LIST OF RS-232C COMMANDS.....	69	
5.9 DETAILS OF RS-232C COMMANDS.....	76	
6. SERVICE FACTORY MODE.....	90	
6.1 DETAILS OF THE FACTORY MENU.....	90	
7. DISASSEMBLY.....	107	
7.1 FLOWCHART OF REMOVAL ORDER.....	107	D
7.2 DISASSEMBLY.....	108	
8. EACH SETTING AND ADJUSTMENT.....	120	
8.1 ADJUSTMENT REQUIRED WHEN THE UNIT IS REPAIRED OR REPLACED.....	120	
8.2 BACKUP OF THE EEPROM (DIGITAL ASSY).....	123	
8.3 HOW TO CLEAR HISTORY DATA.....	126	
8.4 ADJUSTMENT WHEN THE SERVICE PANEL ASSY IS REPLACED.....	127	
8.5 ADJUSTMENT WHEN THE DRIVE ASSYS ARE REPLACED.....	137	
9. EXPLODED VIEWS AND PARTS LIST.....	140	
9.1 PACKING SECTION (KRP-600P/WYSIXK5).....	140	
9.2 PACKING SECTION (KRP-600P/WYS5).....	142	
9.3 PACKING SECTION (KRP-600P/WA5).....	144	E
9.4 REAR SECTION.....	146	
9.5 FRONT SECTION.....	148	
9.6 CHASSIS SECTION (1/2).....	150	
9.7 CHASSIS SECTION (2/2).....	152	
9.8 PANEL CHASSIS SECTION.....	154	
9.9 MULTIBASE SECTION.....	156	
9.10 PDP SERVICE ASSY.....	158	

# 1. SERVICE PRECAUTIONS

## 1.1 NOTES ON SOLDERING

A

- For environmental protection, lead-free solder is used on the printed circuit boards mounted in this unit.  
Be sure to use lead-free solder and a soldering iron that can meet specifications for use with lead-free solders for repairs accompanied by reworking of soldering.
- Compared with conventional eutectic solders, lead-free solders have higher melting points, by approximately 40 °C.  
Therefore, for lead-free soldering, the tip temperature of a soldering iron must be set to around 373 °C in general, although the temperature depends on the heat capacity of the PC board on which reworking is required and the weight of the tip of the soldering iron.

Do NOT use a soldering iron whose tip temperature cannot be controlled.

B

Compared with eutectic solders, lead-free solders have higher bond strengths but slower wetting times and higher melting temperatures (hard to melt/easy to harden).

The following lead-free solders are available as service parts:

- Parts numbers of lead-free solder:  
GYP1006 1.0 in dia.  
GYP1007 0.6 in dia.  
GYP1008 0.3 in dia.

C

## 1.2 NOTES SPECIFIC TO THIS PRODUCT

D

- In some cases, there are silicon sheets on back side of POWER SUPPLY Unit, X DRIVE Assy and Y DRIVE Assy due to heat release of these boards to panel chassis. When replacing these boards, check backside of them and if silicon sheets are on there, surely put these silicon sheets again to the original location of them.

E

F

### ■ Charged Section

The places where the commercial AC power is used without passing through the power supply transformer.  
If the places are touched, there is a risk of electric shock. In addition, the measuring equipment can be damaged if it is connected to the GND of the charged section and the GND of the non-charged section while connecting the set directly to the commercial AC power supply. Therefore, be sure to connect the set via an insulated transformer and supply the current.

1. Power Cord
2. AC Inlet
3. Power Switch
4. Fuse (In the POWER SUPPLY Unit)
5. STB Transformer and Converter Transformer (In the POWER SUPPLY Unit)
6. Other primary side of the POWER SUPPLY Unit

### ■ High Voltage Generating Point

The places where voltage is 100 V or more except for the charged places described above. If the places are touched, there is a risk of electric shock.

The VSUS voltage remains for several minutes after the power to the unit is turned off. These places must not be touched until about 10 minutes after the power is turned off, or it is confirmed with a tester that there is no residual VSUS voltage.

If the procedures described in “5.6 [1] PANEL DRIVE-POWER ON/OFF FUNCTION” are performed before the power is turned off, the voltage will be discharged in about 30 seconds.

60F X DRIVE Assy	.....	(210 V)
60F Y DRIVE Assy	.....	(-280 V to 420 V)
60F SCAN A Assy	.....	(-280 V to 420 V)
60F SCAN B Assy	.....	(-280 V to 420 V)
60F SCAN C Assy	.....	(-280 V to 420 V)
60F SCAN D Assy	.....	(-280 V to 420 V)

- : Part is Charged Section.
- : Part is the High Voltage Generating Points other than the Charged Section.





Fig. High Voltage Generating Point (Rear view)

# 2. SPECIFICATIONS


## 2.1 ACCESSORIES

### KRP-600P/WYSIXK5

- Remote control unit (AXD1562)




- Power cable (ADG1214)




For Europe, except UK and Republic of Ireland

- Power cable (ADG1223)




For UK and Republic of Ireland

- System cable (2.9 m) (ADF1041)




- Alkaline dry cell battery (LR6, AA) (2)



(for remote control unit)


- Ferrite core (ATX1039)(CTX1089)



Ferrite core x 2 (Grey x 1, Black x 1)


Cable tie (for ferrite core)

- Binder Assy (AEC2158)




Cable clamps (4)


- Cleaning cloth (AED1285)




- Color sensor module (AXF1196)



Colour Sensor




Colour Sensor Bracket (when attached to the top right of the rear panel)




Screw x 2 (M5 x 8 mm)

Cable guide




Operating instructions (2) (ARC1609, ARE1494)




Warranty card

### KRP-600P/WYS5

- Remote control unit (AXD1562)




- Power cable (ADG1214)




For Europe, except UK and Republic of Ireland

- Power cable (ADG1223)




For UK and Republic of Ireland

- System cable (2.9 m) (ADF1041)




- Alkaline dry cell battery (LR6, AA) (2)



(for remote control unit)


- Ferrite core (ATX1039)(CTX1089)



Ferrite core x 2 (Grey x 1, Black x 1)


Cable tie (for ferrite core)

- Binder Assy (AEC2158)




Cable clamps (4)


- Cleaning cloth (AED1285)




- Color sensor module (AXF1196)



Colour Sensor




Colour Sensor Bracket (when attached to the top right of the rear panel)




Screw x 2 (M5 x 8 mm)

Cable guide




Operating instructions (ARC1619)




Warranty card

**KRP-600P/WA5**

- Remote control unit (AXD1569)




- Dry cell battery (R6, AA) (2)




(for remote control unit)

- Power cable



AC power cord (ADG1209)

- Ferrite core (ATX1039)



Ferrite core



Cable tie (for ferrite core)

- When only the cable tie is necessary, please order a nylon binder (AEC-093).




- Binder Assy (AEC2158)


- Cable clamps (4)



- Operating instructions (ARC1610)




- System cable (2.9 m) (ADF1041)



- Cleaning cloth (AED1285)



- Warranty card



2.2 SPECIFICATIONS

A

60" display, model: KRP-600P		
Number of pixels		1920 x 1080 pixels
Audio amplifier		18 W + 18 W (1 kHz, 10 %, 6 Ω)
Sound Effect		SRS FOCUS/SRS/SRS TruBass/SRS Definition
Power Requirements		220 V to 240 V AC, 50 Hz/60 Hz, 478 W (0.4 W Standby) : For WYSIXK5 and WYS5 types 220 V to 240 V AC, 50 Hz/60 Hz, 502 W (0.5 W Standby) : For WA5 type
Weight		Main unit: 49.9 kg (110 lbs) Colour Sensor: 0.1 kg (0.2 lbs) : WYSIXK5 and WYS5 types only
Terminals Rear	SPEAKERS	6 Ω to 16 Ω
	SYSTEM CABLE	1
	Colour Sensor	1

B

■

Dimensions (Display)


KRP-600P

Unit: mm

C

■

D




E


■

F

(Front)




(Rear)



A

## ■ Remote Control Unit (for WYSIXK5 and WYS5 types)

This section describes the functions of the buttons available when the TV mode has been selected by using the **SELECT** button.



- 1 **TV** : Turns on the power to the flat screen TV or places it into the standby mode.
- 2 **INPUT**: Selects an input source of the flat screen TV. ("INPUT 1", "INPUT 2", "INPUT 3", "INPUT 4", "INPUT 5")
- 3 **□**: Switches the screen mode among 2-screen, picture-in-picture, and single-screen.
- 4 **PC**: Selects the PC terminal as an input source.
- 5 **↔**: Switches between the two screens when in the 2-screen or picture-in-picture mode.

- 6 **0 to 9**: TV/External input mode: Selects a channel.  
Teletext mode: Selects a page.  
Turns the power on when the STANDBY indicator lights red.
- 7 **EPG**: Displays the Electronic Programme Guide in DTV/SAT (Satellite) input mode.
- 8 **P+/P-**: TV/External input mode: Selects a channel.  
**⇐/⇒**: Teletext mode: Selects a page.
- 9 **X EXIT**: Returns to the normal screen in one step.
- 10 **↑/↓/←/→**: Selects a desired item on the setting screen.  
**ENTER**: Executes a command.
- 11 **HOME MENU**: Displays the HOME MENU screen.
- 12 **Colour (RED/GREEN/YELLOW/BLUE)**: Controls a BD player for HDMI Control functions only.
- 13 **⋮**: Jumps to Teletext subtitle page.  
Turns subtitle on and off in DTV input mode depending on the broadcast.
- 14 **Ⓜ?**: Displays hidden characters.
- 15 **I-II**: Sets the sound multiplex mode.
- 16 **⏮**: TV/External input mode: Freezes a frame from a moving image. Press again to cancel the function.  
**⏮**: Teletext mode: Stops updating Teletext pages. Press again to release the hold mode.
- 17 **TV, STB, DVD/DVR, VCR**: These indicators show the current selection and status when you control other connected equipment, using the supplied remote control unit.
- 18 **Ⓜ**: Lights up buttons.  
Lights turn off if no operations are performed within five seconds. This is used for remote control use in dark locations.
- 19 **Ⓜ+ Ⓜ-** **INFO**: Displays the channel information.  
Displays the banner information.
- 20 **HMG (Home Media Gallery)**: Displays the Home Media Gallery screen.
- 21 **HDMI CTRL**: Displays the HDMI Control menu.
- 22 **Ⓜ**: Moves the location of the small screen when in the picture-in-picture mode.
- 23 **TV/DTV/SAT**: Switches the mode among TV, DTV and SAT.
- 24 **CH RETURN**: Returns to the previous channel.
- 25 **△ + / △ -**: Sets the volume.
- 26 **⏻**: Mutes the sound.
- 27 **🔧 TOOLS**: Displays the TOOLS Menu.
- 28 **↶ RETURN**: Restores the previous menu screen.
- 29 **Ⓜ**: Selects the Teletext mode (all TV image, all TEXT image, TV/TEXT image).
- 30 **Ⓜ**: Displays an Index page for the CEEFAX/FLOF format.  
Displays a TOP Over View page for the TOP format.
- 31 **Ⓜ**: Selects the screen size.
- 32 **SELECT**: Switches the selection among TV, STB, DVD/DVR, and VCR, so that you can control other connected equipment, using the supplied remote control unit.


### Note

- When using the remote control unit, point it at the display panel.



## Remote Control Unit (for WA5 type)

This section describes the functions of the buttons available when the TV mode has been selected by using the **SELECT** button.



- 1 ⏻: Turns on the power to the flat screen TV or places it into the standby mode.
- 2 **INPUT**: Selects an input source ("INPUT 1", "INPUT 2", "INPUT 3", "INPUT 4", "INPUT 5", "INPUT 6" or "PC")
- 3 **0 to 9**: TV/External input mode: Selects a channel. Turns the power on when the STANDBY indicator lights red.
- 4 **CH RETURN**: Returns to the previously selected channel.
- 5 **P+/P-**: TV/External input mode: Selects a channel.
- 6 **HDMI CONTROL**: Displays the HDMI Control menu.
- 7 **↑/↓/←/→**: Selects a desired item on the setting screen.  
**ENTER**: Executes a command.
- 8 **HOME MENU**: TV/External Input mode: Displays the HOME MENU screen.
- 9 **●/II/■**: Used when operating the Home Gallery function.
- 10 **AV SELECTION**: Selects audio and video settings. (AV source: OPTIMUM, STANDARD, DYNAMIC, MOVIE, GAME, SPORT, USER. PC source: STANDARD, USER.)
- 11 **I-II**: Sets the sound multiplex mode.
- 12 **⏻**: Press to select 2-screen, picture in picture or single screen mode.
- 13 **TV, STB, DVD/DVR, VCR**: These indicators show the current selection and status when you control other connected equipment, using the supplied remote control unit.
- 14 **-/--**: Executes a channel selection.
- 15 **△/▽**: Sets the volume.
- 16 **⏻**: Mutes the sound.
- 17 **INFO**: TV/External input mode: Displays the channel information.
- 18 **↶ RETURN**: Restores the previous menu screen.
- 19 **⏮**: TV/External input mode: Freezes a frame from a moving image. Press again to cancel the function.
- 20 **⏮**: TV/External input mode: Selects the screen size.
- 21 **⏮**: Moves the position of the sub screen when in picture in picture mode.
- 22 **⏮**: Swaps the main and sub screens when in picture in picture or 2-screen mode.
- 23 **SELECT**: Switches the selection among TV, STB, DVD/DVR, and VCR, so that you can control other connected equipment, using the supplied remote control unit.

### Note

- When using the remote control unit, point it at the display.

### 3. BASIC ITEMS FOR SERVICE

#### 3.1 CHECK POINTS AFTER SERVICING

##### A Items to be checked after repair (PDP)

To ensure the quality of the product after repair, check the recommended items shown below:

No.	Procedures	Item to be checked
1	Check if all the symptoms pointed out by the customer have been addressed.	The symptoms in question must not be reproduced.
2	Connect the peripheral equipment.	Connect all external peripheral equipment as originally connected and check if the connections are correct.
3	Check the video and audio.	Tune in to the stations that the customer would normally receive and check if video and audio are normal.
4	Check the buttons and controls.	Use the buttons and controls on the remote control unit and main unit and check if they operate properly.
5	Check the cabinet.	Check for any scratches or dirt that have been made or attached on the cabinet after receiving the product for repair.

See the table below for the items to be checked regarding video and audio:

Item to be checked regarding video	Item to be checked regarding audio
Block noise	Distortion
Horizontal noise	Noise
Dot noise	Volume too low
Disturbed image (video jumpiness)	Volume too high
Too dark	Volume fluctuating
Too bright	Sound interrupted
Mottled color	

##### D Cleaning



Name	Part No.	Remarks
Cleaning paper	GED-008	Used to fan cleaning. Refer to “9.6 CHASSIS SECTION (1/2)”.

## 3.2 QUICK REFERENCE

### Quick Reference upon Service Visit ① Notes, PD/SD diagnosis, and methods for various settings

#### Notes when visiting for service

##### 1. Notes when disassembling/reassembling

###### ① Rear case

When reassembling the rear case, the screws must be tightened in a specific order. Be careful not to tighten them in the wrong order forcibly. For details, see "Rear Case" in "7. DISASSEMBLY".

###### ② Attaching screws for the HDMI and system cable terminals

When attaching the HDMI and system cable terminals after replacing the Assembly, secure the terminals manually with a screwdriver, but not with an electric screwdriver. If you tighten the screws too tightly with an electric screwdriver, the screw heads may be damaged, in which case the screws cannot be untightened/tightened any more.

##### 2. On parts replacement

###### ① How to discharge before replacing the Assys

A charge of significant voltage remains in the Plasma Panel even after the power is turned off. Safely discharge the panel before replacement of parts, in either manner indicated below:

A: Let the panel sit at least for 3 minutes after the power is turned off.  
B: Turn the Large Signal System off before the power is turned off then, after 1 minute, turn the power off.

For details, see "5.6 [1] PANEL DRIVE-POWER ON/OFF FUNCTION".

###### ② On the settings after replacement of the Assys

Some boards need settings made after replacement of the Assys. For details, see "8. EACH SETTING AND ADJUSTMENT".

##### 3. On various settings

###### ① Setting in Factory mode

After a Mask indication into the panel is performed, be sure to set the Mask setting to "OFF" then exit Factory mode.

PD		SD	
No. of LEDs flashing	MR	Panel	No. of LEDs flashing
Red 1	MR_POWER	SQ_LSI	Blue 1
	Panel	Module Device communication	Blue 2
Red 2	POWER	DIGITAL-RST2	Blue 3
Red 3	SCAN	Panel temperature	Blue 4
Red 4	SCN-5V	Audio	Blue 5
Red 6	Y-DCDC	Module microcomputer communication	Blue 6
Red 7	Y-SUS		Blue 7
Red 8	ADRS		Blue 8
Red 10	X-DCDC	Panel main IIC communication	Blue 9
Red 11	X-SUS		Blue 10
Red 12	DIG-DCDC	FAN	Blue 11
Red 15	UNKNOWN	Unit high temperature	Blue 12
		DC-IN	Blue 13
		Panel main EEPROM	Blue 15
			Blue 14

Special LED Patterns		Subcategory confirmation procedure	
Panel	MR	SD	SD Subcategory
PD (2-15)	PD (1)		
SD (1-15)	SD (7-15)		
System failure	Standalone operation (MRMS01)		
MR on standby (Red LED lit)	Rewriting of softwa (PC)		
Rewriting of software (PC)	Rewriting of softwa (USB)		
NO	After rewriting is completed successfully, the orange LED goes dark.		
BACKUP	Rewriting of software failed (USB)		
For special patterns other than described here, see 5.1[1].			
Commands for shifting between standalone and system operations		Other SD main categories have subcategories. For details, see 5.4[2].	
Panel	MR		
To Standalone operation: SYSS00	To Standalone operation: MRMS01		
To System operation: SYSS01	To System operation: MRMS00		
Note: After issuing a command, unplug then again plug in the AC power cord.			

#### How to locate several items on the Factory menu

{ } : Item on the Factory menu  
[ ] : Key on the remote control unit  
" " : Screen indication

##### 1. Confirmation of accumulated power-on time and power-on count

Select {INFORMATION} then {HOUR METER}.  
(After entering Factory mode, press [↓] four times.)

##### 2. Confirmation of the Power-down and Shutdown histories

###### ① Panel system

PD: Select {PANEL FACTORY} then {POWER DOWN}.  
(After entering Factory mode, press [MUTING] once, press [ENTER/SET], then press [↓] two times.)

SD: Select {PANEL FACTORY} then {SHUT DOWN}.  
(After entering Factory mode, press [MUTING] once, press [ENTER/SET], then press [↓] three times.)

###### ② MR section

Select {INFORMATION} then {MAIN NG}.  
(After entering Factory mode, press [↓] two times.)

###### ③ Panel main section

Select {PANEL MAIN FACTORY} then {PM NG INFO}.  
After entering Factory mode, press [MUTING] twice, then press [ENTER/SET].

##### 3. How to display the Mask indication

###### ① Mask indication in the panel side

- Select {PANEL FACTORY} then {RASTER MASK SETUP}.  
(After entering Factory mode, press [MUTING] once, press [ENTER/SET], then press [↓] 8 times.)
- Press [ENTER/SET], then select a Mask indication, using [↑] or [↓].

#### Adjustments and Settings after replacement of the Assys (Procedures in Factory mode)

##### 1. DIGITAL Assy (Panel): Transfer of backup data

- Select {PANEL FACTORY}, {ETC}, then {BACKUP DATA}. (After entering Factory mode, press [MUTING] once, press [ENTER/SET], press [↓] seven times, then press [ENTER/SET].)
- Select {TRANSFER}, using [→], then hold [ENTER/SET] pressed for at least 5 seconds.
- After transfer of backup data is completed, {ETC} is automatically selected, and the LED on the front panel returns to normal lighting.

##### 2. MAIN BLOCK Assy (MR), MAIN Assy (Panel): Execution of FINAL SETUP.

- Select {INITIALIZE} then {FINAL SETUP}, then press [ENTER/SET]. (After entering Factory mode, press [MUTING] three times, then press [↓] four times.)
- Select "YES", using [→]. Then hold [ENTER/SET] pressed for at least 5 seconds.
- After "FINAL SETUP IS COMPLETE" is displayed on the screen, turn the POWER switch of the main unit off.

##### 3. POWER SUPPLY Unit (Panel): Clearance of the accumulated power-on count and maximum temperature value

- Select {PANEL FACTORY}, {ETC}, then {P COUNT INFO}. (After entering Factory mode, press [MUTING] once, press [ENTER/SET], press [↓] seven times, press [ENTER/SET], then press [↓] six times.)
- Press [→] to select "CLEAR". Hold [ENTER/SET] pressed for at least 5 seconds. After clearance is completed, "ETC" is automatically selected. Clear the maximum temperature value (MAX TEMP) in the same manner.


##### 4. Other Assys (panel): Clearance of the maximum temperature value

- Select {PANEL FACTORY}, {ETC}, then {MAX TEMP}. (After entering Factory mode, press [MUTING] once, press [ENTER], press [↓] seven times, press [ENTER/SET], then press [↓] seven times.)
- Press [→] to select "CLEAR". Hold [ENTER/SET] pressed for at least 5 seconds. After clearance is completed, "ETC" is automatically selected.

## Quick Reference upon Service Visit ②

### Mode transition and structure of layers in Service Factory mode

#### Mode transition in Service Factory mode



Up  
↓  
Down

- To shift to another mode, press [MUTING].
- To shift to another item in a specific mode, press [↑] or [↓].
- To shift to the next nested layer below for an item with a "(+)" indication, press [ENTER/SET]. To return to the next nested layer above, also press [ENTER/SET].

#### INFORMATION mode

1. VERSION (1)
2. VERSION (2)
3. VERSION (3)
4. MAIN NG
5. TEMPERATURE
6. HOUR METER
7. HDMI SIGNAL INFO 1
8. HDMI SIGNAL INFO 2
9. VDEC SIGNAL INFO 1
10. VDEC SIGNAL INFO 2



#### INITIALIZE mode

1. SIDE MASK LEVEL
2. FINAL SETUP
3. DTB SERVICE MENU
4. Wide XGA AUTO
5. AUTO ADJUSTMENT



#### OPTION mode

1. CH PRESET
2. Digital AFT
3. SYNC DET
4. CTI



#### PANEL MAIN FACTORY mode

1. PM NG INFO.
2. PM STATE INFO.
3. DP\_RX INFO.
4. PM\_SETUP



#### PANEL FACTORY mode

1. PANEL INFORMATION
2. PANEL WORKS
3. POWER DOWN
4. SHUT DOWN
5. PANEL-1 ADJ
6. PANEL-2 ADJ
7. PANEL FUNCTION
8. ETC.
9. RASTER MASK SETUP
10. PATTEN MASK SETUP
11. COMBI MASK SETUP

#### Structure of Layers in Service Factory Mode

##### INFORMATION mode

- 1. VERSION (1)
- 2. VERSION (2)
- 3. VERSION (3)
- 4. MAIN NG
  - 4-1. CLEAR
- 5. TEMPERATURE
- 6. HOUR METER
- 7. HDMI SIGNAL INFO 1
- 8. HDMI SIGNAL INFO 2
- 9. VDEC SIGNAL INFO 1
- 10. VDEC SIGNAL INFO 2

The software versions for each microcomputer  
The Flash memory versions for each device  
The software versions for display microcomputer  
The shutdown message ID/event times  
(Going Clear mode by [ENTER/SET] key)  
Select Yes by [→] key → pushing and hold [ENTER/SET] key  
The temperature/FAN rotating status  
The HOUR METER/P-COUNT information  
The information of HDMI information files  
The information of HDMI information files  
The signal information of VDEC  
The signal information of VDEC

##### PANEL FACTORY mode

Refer to [PANEL FACTORY MODE]

##### PANEL MAIN FACTORY mode

- 1. PM NG INFO.
- 2. PM STATE INFO.
- 3. DP\_RX INFO.
- 4. PM\_SETUP

Shutdown history of the panel main  
The temperature/FAN rotating status/Room Light Sensor  
Indication of the DPRx ID  
Select the bezel color and clear the shutdown history of the panel main

##### OPTION mode

- 1. CH PRESET
- 2. Digital AFT
- 3. SYNC DET
- 4. CTI

For production line use  
For production line use  
For technical analysis  
For technical analysis

##### INITIALIZE mode

- 1. SIDE MASK LEVEL
  - 1-1. SIDE MASK LEVEL
- 2. FINAL SETUP
  - 2-1. DATA RESET
  - 3-1. MODE SHIFT
- 4. Wide XGA AUTO
- 5. AUTO ADJUSTMENT

For factory use  
Set to Factory default settings (it should perform after replacing a MAIN Assy)  
Information for the Digital Tuner Service Menu is displayed  
For technical analysis

#### Structure of Layers in Panel Factory Mode 1

1. PANEL INFORMATION
2. PANEL WORKS
3. POWER DOWN
4. SHUT DOWN
5. PANEL-1 ADJ (+)
  - 1. VOL SUS
  - 2. VOL OFFSET
  - .....
10. RESET1ST\_KSB
  - .....
25. SUS FREQ
6. PANEL-2 ADJ (+)
  - 1. R-HIGH
  - 2. G-HIGH
  - .....
  - 6. B-LOW
  - 7. ABL
7. PANEL FUNCTION (+)
  - 1. R-LEVEL
  - .....

Version indication of the panel  
Indications of the accumulated power-on time and power-on count of the panel  
Indication of the Power-down history  
Indication of the Shutdown history

Settings required after replacement of the panel

Items for factory use

For AM noise prevention (Depending on the mode, brightness of the screen changes.)  
For confirmation of the result of the setting change, the unit must be turned off then back on again.

For the WB adjustment of the panel and ABL adjustment.  
A setting table is available for each signal frequency.

Items for factory use

To "Structure of Layers in Panel Factory Mode 2"

#### Structure of Layers in Panel Factory Mode 2

8. ETC (+)
  - 1. BACKUP DATA
  - 2. DIGITAL EEPROM
  - 3. PD INFO.
  - 4. SD INFO.
  - 5. HR-MTR INFO.
  - 6. PM/B1-B5
  - 7. P COUNT INFO.
  - 8. MAX TEMP.
  - 9. MIRROR
  - 10. CLS
9. RASTER MASK SETUP (+)
  - 1. MASK OFF
  - 2. RST MASK 01
  - .....
10. PATTERN MASK SETUP (+)
  - 1. MASK OFF
  - 2. PTN MASK 01
  - .....
11. COMBI MASK SETUP (+)
  - 1. MASK OFF
  - 2. CMB MASK 01
  - .....

For transferring backup data (after replacement of the DIGITAL Assy)  
Change the adjustment status of the DIGITAL Assy.

For clearance of data for the corresponding items.  
The clearing method is the same: Select "CLEAR", then hold [ENTER/SET] pressed for at least 5 seconds.

Switch the Mirror display mode.  
Switch the function when checking the color sensor level.


For use while the Raster Mask is displayed.  
Use [↑] or [↓] to select the type of mask.  
Use [→] or [←] to select the sequence.

For use while the Pattern Mask is displayed.  
Use [↑] or [↓] to select the type of mask.  
Use [→] or [←] to select the sequence.

For use while the Combination Mask is displayed.  
Use [↑] or [↓] to select the type of mask.  
Use [→] or [←] to select the sequence.

### 3.3 PCB LOCATIONS

**Note:** The wiring shown in the photo is different from the actual wiring, because the product in the photo is a prototype. Upon servicing, be sure to restore the original wiring of the unit after repair work.



NOTES: ● Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.  
● The ⚠ mark found on some component parts indicates the importance of the safety factor of the part.  
Therefore, when replacing, be sure to use parts of identical designation.

Mark No.	Description	Part No.
LIST OF ASSEMBLIES		
(PDP Panel)		
NSP	60F ADDRESS L ASSY	AWW1341
NSP	60F ADDRESS S ASSY	AWW1342
NSP	60F SCAN A ASSY └ IC2801 - IC2804	AWW1343 AN16184A
NSP	60F SCAN B ASSY └ IC2901 - IC2904	AWW1344 AN16184A
NSP	60F SCAN C ASSY └ IC3001 - IC3004	AWW1345 AN16184A
NSP	60F SCAN D ASSY └ IC3101 - IC3104	AWW1346 AN16184A
	60F DIGITAL Assy	AWW1339
	SENSOR ASSY	AWW1340
	60F X DRIVE ASSY	AWV2597
	60F Y DRIVE ASSY	AWV2598
(MTB)		
	MAIN ASSY	AWW1393
	FAN ASSY	AWW1394
	POW SW ASSY	AWW1395
	SENS ASSY	AWW1396
	FAN CH ASSY	AWW1397
	AUDIO ASSY	AWW1398
	LED ASSY	AWW1399
	IR ASSY	AWW1400
	RLS ASSY	AWW1401
(Power Supply)		
⚠	POWER SUPPLY UNIT	AXY1201
(Service Assy)		
	PDP SERVICE ASSY 609FE	AWU1379



# 4. BLOCK DIAGRAM

## 4.1 OVERALL WIRING DIAGRAM (1/2)

A


B

C

D


E

F




! POWER CORD (※1, ※2, ※3)



※1	KRP-600P/WYS5	POWER CORD	ADG1223-(FOR UK)
※2	KRP-600P/WYS1XK5	POWER CORD	ADG1214-(OTHER)
※3	KRP-600P/WA5	POWER CORD	ADG1209-




TO AUDIO ASS'Y






! POWER SUPPLY UNIT  
AXY1201-



TAL



- When ordering service parts, be sure to refer to "EXPLODED VIEWS and PARTS LIST" or "PCB PARTS LIST".
- The ! mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.




OVERALL DIAGRAM  
KRP-600P

KRP-600P

## 4







## CONNECTOR PIN ASSIGN


CN4201 M4 → CN8301 I01

1. V+6_5V	9. AC_A_MUTE
2. GND	10. A_NG_B
3. MCLK	11. OTW
4. GND	12. PDN
5. LRCK	13. SDA_AV
6. SCLK	14. SCL_AV
7. SDIN	15. GND
8. RST_5504	


## SENSOR MODULE


4-

KRP-600P/WYS5	Attached
KRP-600P/WYSIXK5	
KRP-600P/WA5	Optional

The  mark found on some component parts should be replaced with same parts (safety regulation authorized) of identical designation.



## 4.3 OVERALL BLOCK DIAGRAM (1/2)







## 4





## 4.5 POWER SUPPLY UNIT





A


B

C

D

E

F






4.7 60F Y DRIVE, 60F SCAN A, B, C and D ASSYS

60F SCAN B ASSY  
(HIGH-SIDE\_LOW)

60F SCAN A ASSY  
(HIGH-SIDE\_HIGH)



60F SCAN C ASSY  
(LOW-SIDE\_HIGH)

60F SCAN D ASSY  
(LOW-SIDE\_LOW)

4.8 POWER SUPPLY BLOCK of 60F X, Y DRIVE and 60F SCAN A, B, C and D ASSYS

A



B

C

D

E

F




Note:  
VYPRST, VSNOF12, VYKOF12, VYKOF3, VYKOF4  
VKOF1 and VKOF2 voltages are electrical volume controls.

**60F SCAN A, B, C and D ASSYS**


5 6 7 8

## 4.9 60F ADDRESS L and S ASSYS

60F ADDRESS L ASSY





60F ADDRESS S ASSY



## 4.10 60F DIGITAL ASSY

### 60F DIGITAL ASSY





5. DIAGNOSIS

5.1 POWER SUPPLY OPERATION

A

[1] LED DISPLAY INFORMATION

■ LED Pattern

Status	LED Display Pattern		Remarks
AC-OFF /Main PowerOFF	Blue Red		
Standby	Blue Red		
Power ON	Blue Red		
Abnormality in system connection	Blue Red		
Power down	Blue Red		*1
Shutdown	Blue Red		*2
No digital adjustment data copied for backup	Blue Red		
During download (panel main)	Blue Red		
During download (excepting panel main)	Blue Red		*3

\*1: This LED only flashes when power-down is generated in the display unit.  
When power-down is generated in the MR, the LED on the MR flashes.

\*2: This LED only flashes when shutdown is generated in the display unit.  
When shutdown is generated in the MR, the LED on the MR flashes.


\*3: These LEDs only flash during rewriting of software in the display unit.  
During rewriting of software in the MR, the LEDs on the MR flash.

D

E

F


## [2] POWER ON SEQUENCE



- ① : The KEY signal is input to the IF microcomputer.
- ①' : The remote control signal is input to the IF microcomputer and Panel main microcomputer.
- ② : The IF microcomputer sends the operation data of the remote control unit key to the main microcomputer.
- ③ : The main microcomputer issues a startup command (PON) to the panel main microcomputer through DP Tx and DP Rx.
- ④ : The panel main microcomputer issues a startup command (PON) to the MOD microcomputer.
- ⑤ : The MOD microcomputer controls a MOD relay of the POWER SUPPLY Unit (Display section), then the power is turned on.
- ⑤' : The main microcomputer controls a MOD relay of the POWER SUPPLY Unit (Media Receiver section), then the power is turned on.


### [3] DETAILS OF POWER ON SEQUENCE

#### AC-OFF






Panel Main Power OFF



## Passive Standby



### (MR) Output port setting

IF: ACTIVE	OFF
MR Main: RELAY2	OFF
MR Main: PSW1	OFF

### (MR) Input port state

MR Main: RST4	OFF
MR Main: RST2	OFF
MR Main: PD_TRG	OFF

### (MR) Operation outline

Only the periphery of the IF microcomputer are operated.

### (Panel) Output port setting


Panel Main: MAIN_PWR_CTL	ON
Panel Main: PWR_CTL_MD	OFF
Panel Main: CLS_CTL	OFF
DP Rx: HPD	OFF
Module: RELAY1 / KDD	OFF
Module: DRF_B	OFF

### (Panel) Input port state


Main: DC_IN	OFF
Module: RST2	OFF
Module: PS_PD/PD_TRG_B	OFF

### (Panel) Operation outline


Only the periphery of the Panel main microcomputer and IR are operated.  
In this time, panel main microcomputer is the sleep mode.



## Active Standby



Function Standby



(MR) Output port setting

IF: ACTIVE	ON
MR Main: RELAY2	ON
MR Main: PSW1	OFF

(MR) Input port state

MR Main: RST4	ON
MR Main: RST2	OFF
MR Main: PD_TRG	OFF

- (MR) Operation outline
- Besides the standby power circuits, part of the Vcc circuits are also activated.
  - RGB-SW/AD IC uses the power-save function of the IC.

(Panel) Output port setting

Panel Main: MAIN_PWR_CTL	ON
Panel Main: PWR_CTL_MD	ON
Panel Main: CLS_CTL	OFF
DP Rx: HPD	ON
Module: RELAY1 / KDD	OFF
Module: DRF_B	OFF

(Panel) Input port state

Main: DC_IN	OFF
Module: RST2	OFF
Module: PS_PD/PD_TRG_B	OFF

- (Panel) Operation outline
- Periphery of the Panel main microcomputer, IR, DP Rx and module microcomputer are operated.  
(As same state as the active standby)


## F

1234


## 5.2 DIAGNOSIS FLOWCHART OF FAILURE ANALYSIS

A


### [1] WHOLE UNIT




### Power-On-Related Problems



### PD/SD-Related Problems




### System-Connection-Related Problems



A

### Video-Display-Related Problems



B


C

D

E

F


### Audio-Related Problems






## [2] POWER SUPPLY UNIT


### Flowchart of Failure Analysis for The POWER SUPPLY Unit




### [3] DRIVE ASSY

#### Flowchart of Failure Analysis for The Drive Assy







Assy Name	Voltage to be Checked (V)	Adjustable Range	Measurement Point		Computation Formula for Voltage (Absolute Value)	
		60-inch	Output at the Last Stage	DAC Output (*2)	Computation Using DAC Output Voltage (V)	Computation Using Adjustment Value (*4)
Y DRIVE Assy	VSNOFS	040 to 085	CN2404 (*1)	Lower side of R2723 (*3)	$55.54 - \text{VOFS\_ADJ} \times 13.91$	$\text{VOF value} \times 0.18 + 9.6$
	VYRST	001 to 056	CN2401 (*1)	Upper side of R2621 (*3)	$\text{VYPRST\_ADJ} \times 62.495 + 75.2$	$\text{VRP value} \times 0.81 + 74.4$
	VKNOFS1_2	054 to 107	CN2405 (*1)	Left side of R2754 (*3)	$\text{YVKNOFS1\_ADJ} \times 36.85 + 159.3$	$(\text{V1F value} + \text{VYF value} - 128) \times 0.48 + 158.8$
	VKNOFS3	065 to 117	CN2403 (*1)	Right side of R2757 (*3)	$\text{YVKNOFS3\_ADJ} \times 36.85 + 159.3$	$(\text{V3F value} + \text{VYF value} - 128) \times 0.48 + 158.8$
	VKNOFS4	111 to 164	CN2406 (*1)	Right side of R2755 (*3)	$\text{YVKNOFS4\_ADJ} \times 36.85 + 159.3$	$(\text{V4F value} + \text{VYF value} - 128) \times 0.48 + 158.8$
X DRIVE Assy	XKOFS1	105	CN1302 (*1)	K1402 (*1)	$\text{XKNOFS1\_ADJ} \times 27.3 + 30$	$\text{VX1 value} \times 0.35 + 29.7$
	XKOFS2	063	CN1301 (*1)	K1401 (*1)	$\text{XKNOFS2\_ADJ} \times 25.0 + 69.8$	$\text{VX2 value} \times 0.32 + 69.5$


(\*1): These parts have not been mounted.

(\*2): It is recommended to measure the DAC output voltage with the drive off.


(\*3): View when the Assy is mounted on the unit and viewed from the rear.

(\*4): The value calculated using an adjustment value may be different from the value measured at the last output stage, because various corrections such as temperature correction are not taken into consideration.

Diagrammatic view of the Y DRIVE Assy



Diagrammatic view of the X DRIVE Assy



A	R2754,R2755,R2757
B	R2723
C	R2621
D	CN2405
E	CN2403,CN2406
F	CN2404
G	CN2401
H	K1401
I	K1402
J	CN1301,CN1302

A

Failure analysis for the drive system => DR3

Diagnose the ADDRESS Assy.

The abnormality is associated with one ADDRESS or one TCP.

Is the TCP control signal normal?

No

Are the FFC cables properly connected?

No

Properly connect the FFC cables.

Yes

Yes

NG

B

Replace the panel chassis.

NG

Replace the DIGITAL Assy.

If the FFC cable that connects the DIGITAL and ADDRESS Assys is in failure, the abnormality is associated with one address in most cases.

In most cases of damage on one line, the panel chassis must be replaced.

C

Failure analysis for the drive system => DR4

Diagnose the SCAN Assy.

The abnormality is associated with a single scan line.

Is the waveform normal when the voltage is applied to the panel?  
(See the oscilloscope photos.)

No

Is the 15P connector connected properly to the socket?

No

Reconnect the connector properly.

Yes

Yes

NG

Is the waveform of the SCAN IC control signal from the Y DRIVE Assy normal?

No

Replace the Y DRIVE Assy.

Yes

D

Replace the SCAN IC.

NG

Replace the panel chassis.

E

#### Note 1:

In a case where confirmation of the waveform for a particular line is impossible with an oscilloscope, it is possible to identify a defective line by lighting a particular line, using the following commands: (The SCAN IC outputting each line refers to the table.)

PON  
FAY  
MKRS01  
BSMS01 (Command for reducing phosphor burn-in)  
\$250000\*\*\*\* (In place of \*\*\*\*, input a figure between 0001 and 1080, which denotes an ordinal number of a particular line.)


With the above commands, a particular line lights. Be careful to light a line for as short a time as possible, to avoid phosphor burn-in.  
After a particular line is identified, display an all-white screen to protect the screen from burn-in.

F

IC No.	Line Number	Object Line
No 1	66	0001 to 0066
No 2	68	0067 to 0134
No 3	68	0135 to 0202
No 4	68	0203 to 0270
No 5	68	0271 to 0338
No 6	68	0339 to 0406
No 7	68	0407 to 0474
No 8	66	0475 to 0540
No 9	66	0541 to 0606
No 10	68	0607 to 0674
No 11	68	0675 to 0742
No 12	68	0743 to 0810
No 13	68	0811 to 0878
No 14	68	0879 to 0946
No 15	68	0947 to 1014
No 16	66	1015 to 1080




## [4] DIGITAL ASSY

### Flowchart of Failure Analysis for The DIGITAL Assy



## A [5] MAIN ASSY (PANEL INTERFACE)


### Flowchart of Failure Analysis for The MAIN Assy






## [6] AUDIO SYSTEM

### Flowchart of Failure Analysis for The Audio System



#### • Waveforms


Input signal: L/R 1 kHz, 0.5 Vrms (VOL 30)




1 2 3 4

### 5.3 DIAGNOSIS OF PD (POWER-DOWN)

A [1] BLOCK DIAGRAM OF THE POWER-DOWN SIGNAL



The figures ② to ⑫ indicate the number of times the Red LED flashes when power-down occurs in the corresponding route.




## [2] PD (POWER-DOWN) DIAGNOSIS OF FAILURE ANALYSIS


Red LED Flashing Count	Factory History Display	Defective Assy	PD Outline	Checkpoint	
2	P-PWR	POWER SUPPLY Unit	Each PD in the POWER SUPPLY Unit		
			Connector disconnection	Connector [P14][P15] (60"only)	
		X DRIVE Assy	VSUS under voltage protection	X SUS block	
		Y DRIVE Assy	VSUS under voltage protection	Y SUS block	
		ADDRESS Assy	Connector disconnection	Connector [AD1]	
		DIGITAL Assy	Connector disconnection	Connector [D13] to [D20]	
3	SCAN	SCAN Assy		SCAN IC	
		X DRIVE Assy		X SUS block	
		Y DRIVE Assy	VH over or under voltage protection	Y SUS block	
				VH DC/DC	
				OFFSET block	
			Connector disconnection	Connector [Y1][Y2]	
DIGITAL Assy	Connector disconnection	Connector [D21]			
4	SCN5V	SCAN Assy	Connector disconnection	Connector [SA1][SB1][SB2][SC1][SC2][SD1]	
			IC5V over or under voltage protection	SCAN IC	
		Y DRIVE Assy		IC5V DC/DC	
6	Y-DCDC	Y DRIVE Assy	VNOFS under voltage protection	Y MSK block	
				NOFS block	
				VNOFS DC/DC	
			VYPRST under voltage protection	VPRST regulaotr	
				PR-U block	
			15VDD under voltage protection	15V DC/DC	
				SOFT-G block	
			VKOFS1,2 under voltage protection	Y MSK block	
				KNOFS2 block	
			VKOFS3 under voltage protection	VYKOFS1, 2 regulaotr	
Y MSK block					
VKOFS4 under voltage protection	VYKOFS3 regulaotr				
	Y MSK block				
	KNOFS4 block				
	VYKOFS4 regulaotr				
7	Y-SUS	Y DRIVE Assy	Over or under voltage protection of the center electric potential	Y resonance block	
		DIGITAL Assy	SQ_LSI does not operate	SEQ_LSI (Sync input, output waveform)	
8	ADRS	ADDRESS Assy	VADR under voltage protection	Address resonance block	
			Connector disconnection	Connector [AD1][AD2]	
		DIGITAL Assy	Connector disconnection	Connector [D13] to [D20]	
		Y DRIVE Assy	Connector disconnection	Connector [Y2][Y5][Y6]	
		X DRIVE Assy	Connector disconnection	Connector [X2][X3][X4]	
		POWER SUPPLY Unit	Connector disconnection	Connector [P1][P2]	
10	X-DCDC	X DRIVE Assy	Connector disconnection	Connector [X1][X2]	
			15VDD under voltage protection	X SUS block	
				15V DC/DC	
			VXKOFS1 under voltage protection	VXKOFS1 regulaotr	
				X OFFSET block	
		VXKOFS2 under voltage protection	VXKOFS2 regulaotr		
	X OFFSET block				
DIGITAL Assy	Connector disconnection	Connector [D22]			
11	X-SUS	X DRIVE Assy	Over or under voltage protection of the center electric potential	X resonance block	
12	D-DCDC	DIGITAL Assy	3.3V,2.5V,1.1V	DC/DC controlo IC	
			Over voltage/under voltage/overcurrent protection	DC/DC block	
15	UNKNOW	POWER SUPPLY Unit	Connector disconnection	Connector [P4]	
		DIGITAL Assy	Connector disconnection	Connector [D23]	
			ModuleUcom can not detection	Each PD line of ModuleUcom	

Possible Defective Part	Remarks
	The POWER SUPPLY Unit of 60 inches model is a structure of the two parts.
Q1218,Q1219,Q1221-Q1223,Q1226	VSUS-SUSOUT and SUSOUT-SUSGND are short-circuited.
Q2217-Q2224	VSUS-SUSOUT and SUSOUT-SUSGND are short-circuited.
each SCAN IC	The abnormality of the SCAN IC
Q1218,Q1219,Q1221-Q1223,Q1226	VSUS-SUSOUT and SUSOUT-SUSGND are short-circuited.
Q2217-Q2219,Q2221-Q2223	VSUS-SUSOUT and SUSOUT-SUSGND are short-circuited.
IC2601,IC2603,IC2604	
Q2401,Q2402	KNOFS1 and KNOFS3 are short-circuited.
	[SB2][SC1][SC2][SD1] are 60 inches model only.
each SCAN IC	
Q2764,D2768,R2764	
Q2321-Q2326,Q2328-Q2331,Q2333,Q2334	L MSK is short-circuited.
Q2424,Q2429	NOFS is short-circuited.
D2606,Q2709-Q2711	
Q2604,Q2605,IC2602	
Q2418	PR-U is short-circuited.
Q2662,R2669,L2301,R2335	
Q2427	SOFT-G is short-circuited.
Q2321-Q2326,Q2328-Q2331,Q2333,Q2334	L MSK is short-circuited.
Q2430	KNOFS2 is short-circuited.
Q2702,Q2705,R2714	
Q2321-Q2326,Q2328-Q2331,Q2333,Q2334	L MSK is short-circuited.
Q2703,Q2706,R2715	
Q2321-Q2326,Q2328-Q2331,Q2333,Q2334	L MSK is short-circuited.
Q2432	KNOFS4 is short-circuited.
Q2704,Q2707,R2717	
Q2106-Q2109,Q2111,Q2113,D2104-D2107	
IC3301,IC3302	The history of SD1 remains
Q1711,Q1721,Q1731,Q1741,Q1911,Q1921,Q1931,D1711,D1721,D1731,D1741,D1911,D1921,D1931	
TCP (IC1651,IC1661,IC1671,IC1681,IC1851,IC1861,IC1871)	When the TCP is damaged, replace the panel.
	Ref No. of L Assy (6 pieces) and S Assy (2 pieces) are common use.
L1201,R1217	
Q1402	
Q1405,Q1406	
Q1302,Q1304	
Q1403,Q1404	
Q1301,Q1303	
Q1108,Q1112,Q1116,Q1119	
IC3801	
Q3841,Q3861,Q3881,L3841,L3861,L3881	
R3820,R3848,R3868,R3888	
	EXT_PD line : Open
	EXT_PD line : Open
	It becomes "UNKNOWN" except above-mentioned PD detection condition.

[1] BLOCK DIAGRAM OF THE SHUTDOWN SIGNAL



**Note :** The figures ① to ⑮ indicate the number of times the Blue LED flashes when shut-down occurs in the corresponding route.



## [2] SD (SHUTDOWN) DIAGNOSIS

Frequency of LED Flashing	Major Type	Detailed Type	Log Indication in Factory Mode		
			MAIN	SUB	
Blue 1	Abnormality in the Sequence LSI	Communication error	SQ-LSI	RTRY	
		Drive stop		SQNO	
		Busy		BUSY	
		Version mismatching (hardware, software)		VER-HS	
		Version mismatching (hardware, backup memory)		VER-HM	
		Version mismatching (hardware, DIGITAL memory)		VER-HI	
Blue 2	Failure in module microcomputer device communication	Digital EEPROM	MD-DEV	EEPROM	
		Backup EEPROM		BACKUP	
		DAC IC		DAC	
Blue 3	Abnormality in RST2 power decrease	—	RST2	—	
Blue 4	Abnormality in panel temperature	Abnormality in high temperature	TMP-NG	TMP-H	
		Abnormality in low temperature		TMP-L	
Blue 5	Short-circuiting of the speakers D-AMP temperature abnormality	—	AUDIO	AUDIO	
				OTW	
Blue 6	Failure in communication with the module microcomputer	—	MODULE	—	
Blue 8	Failure in IIC communication with the panel main microcomputer	Display Port Rx	PM-IIC	DP-RX	
		PWM Processor		PWM	
Blue 10	Abnormality in FAN	FAN1	P-FAN	FAN1	
		FAN2		FAN2	
Blue 11	High temperature of the unit	T1 (for outside)	TEMP3	T1	
		T2 (for inside)		T2	
Blue 13	Failure in the power supply of the MAIN Assy	Vcc power decrease of the MAIN Assy	MB-POW	RELAY	
Blue 15	Failure in communication with the EEPROM of the panel main microcomputer	—	—	—	



Checkpoint	Possible Defective Part	Remarks
Communication line between MDU and SQ_LSI	IC3601/IC3301	SQ_IC communication not established. IC3301 may not have properly started up.
Drive detectig signal of MDU (SQ_NON)	CN3201/IC3601/ IC3301/IC3607	A shutdown occurs if the drive waveform periodically does not output. (When SQ_NON of MDU input is High, a shutdown is generated.)
Communication line between MDU and SQ_LSI (BUSY_SQ)	IC3601/IC3301	If BUSY_SQ remains high, a shutdown is generated.
Check the DIGITAL Assy and the software version of SEQ and the destination of the panel. Check the connection between [X1] and [D22].	IC3601/IC3301	When the identification resistor of PSIZE/PLANT and software version of SEQ are incoherent, a shutdown occurs.
Check the DIGITAL Assy and the software version of SEQ and the destination of the panel. Check the connections between [X1] and [D22], and [SE1] and [D24]. Communication line between MDU and BACKUP EEPROM	IC3601/ SENSOR Assy(IC3902)	When the identification resistor of PSIZE/PLANT and stored content of EEPROM on the SENSOR Assy are incoherent, a shutdown occurs.
Check the DIGITAL Assy and the software version of SEQ and the destination of the panel. Check the connections between [X1] and [D22]. Communication line between MDU and DIG EEPROM	IC3601/IC3602	When the identification resistor of PSIZE/PLANT and stored content of EEPROM on the DIGITAL Assy are incoherent, a shutdown occurs.
Communication line between MDU and DIG EEPROM	IC3601/IC3602	
Communication line between MDU and BACKUP EEPROM	IC3601/SENSOR Assy(IC3902)	
Communication line between MDU and DAC	IC3601/IC3605	
3.3 V output (TP3881) of DDC	IC3801/IC3805	If RST2 does not become high after the unit is turned on, a shutdown will be generated in several seconds.
V+6.5V of POWER SUPPLY Unit (Check [D25][P4]) FU3801 has melted.	POWER SUPPLY Unit, FU3801	Check if V + 6.5 V is started. Also check if the FU3801 on the DIGITAL Assy has been melted.
Installation environment	SENSOR Assy (IC3901)	If TEMP1 that is read by the module microcomputer is 85 °C or higher, a shutdown will be generated.
Installation environment Check the connection between [SE1] and [D24].	SENSOR Assy (IC3901)	If TEMP1 that is read by the module microcomputer is -20 °C or less, a shutdown will be generated. Also check the connection between SE1 and D24.
Speaker terminals	JA8551	Check if any speaker cable is in contact with the chassis.
D_AMP	IC8401	Check if the AMP output is short-circuited.
6.5 V power supply for AUDIO Assy	R4203	Check that V+6.5 V is activated in the AUDIO Assy. If it is not, check if R4203 on the MAIN Assy is open.
Periphery of the cable between MAIN and AUDIO, and POWER SUPPLY and AUDIO Assys	CN4201,CN8301, CN8302	Check if cables are firmly connected.
D_AMP	IC8401	Check the temperature of D_AMP IC that is 125 °C or higher.
Communication line between main ucom and module ucom	IC7001,IC3601	Check the communication lines (TXD_MD/RXD_MD/REQ_MD).
Periphery of the cable between MAIN and DIGITAL Assys	CN4002,CN3201	Check if cables are firmly connected.
Communication line between main ucom and DisplayPort Rx	IC7001,IC5001	Check the communication lines (SCL_DP/SDA_DP).
Communication line between main ucom and PWM processor	IC7001,IC8341	Check the communication lines (SCL_AV/SDA_AV).
Periphery of the 3.3 V regulator for IC	IC8331	Check that the voltage outputs it.
Periphery of the cable between MAIN and AUDIO Assys	CN4201,CN8301	Check if cables are firmly connected.
Dirt attached to the fan motor		Check the fan. (SD10 does not detect it at the temperature that fans do not turn.)
Periphery of the cable between MAIN and FAN Assys	CN4101,CN1201	Check if cables are firmly connected.
Periphery of the cable between FAN and FAN CH Assys	CN1202,CN3304	Check if cables are firmly connected.
Periphery of the cable between FAN CH Assy and Fan motor	CN3302	Check if cables are firmly connected.
Periphery of the fan control regulator	IC1202	Check that the voltage outputs it.
Dirt attached to the fan motor		Check the fan. (SD10 does not detect it at the temperature that fans do not turn.)
Periphery of the cable between MAIN and FAN Assys	CN4101,CN1201	Check if cables are firmly connected.
Periphery of the cable between FAN and FAN CH Assys	CN1202,CN3304	Check if cables are firmly connected.
Periphery of the cable between FAN CH Assy and Fan motor	CN3301	Check if cables are firmly connected.
Periphery of the fan control regulator	IC1201	Check that the voltage outputs it.
Ambient temperature of the panel section and temp. sensor	IC1203	Shutdown occurs if the periphery of IC1203 (temp. sensor) is high temperature.
Periphery of the cable between MAIN and FAN Assys	CN4101,CN1201	Check if cables are firmly connected.
Periphery of the cable between FAN and SENS Assys	CN1203,CN2401	Check if cables are firmly connected.
6.5 V power supply of the MAIN Assy	CN4502	Check if V + 6.5 V is started.
Communication line between main ucom and EEPROM	IC7001, IC7003	Check the communcation lines (SCL_E2P/SDA_E2P)

A

[1] FUNCTION OF DECREASING THE BRIGHTNESS LEVEL

If the panel temperature becomes high or a video signal that requires activation of panel protection is input, the unit will protect the panel by decreasing the brightness level.

\* While a mask is being displayed, the panel protection function will not be activated.

■

Protection Function Name	Purpose	Conditions	Protection Function	Remarks
High-temperature protection function 1	For protection of parts (DCF)	Panel temperature (TEMP1) reaches 65 °C.	Offsetting the ABL adjustment value	
High-temperature protection function 2	For reducing heating in the unit	Panel temperature (TEMP1) reaches 80 °C.	Limiting for the maximum number of SUS pulses	
Panel protection function 1	For preventing burn-in	A still image is displayed for 3 minutes or more.	Limiting for the maximum number of SUS pulses	The picture will be considered to be still if only the mouse cursor is moved.
Panel protection function 2	For protection of SCAN ICs	An image with which a particular load is applied to one SCAN IC is displayed. (See Fig. 2)	Limiting for the maximum number of SUS pulses	
Panel protection function 3	For protection against panel cracking	An image with which the heat of part in the panel is increased is displayed. (See Fig. 3)	Limiting for the maximum number of SUS pulses	

■

Limiting for the maximum number of SUS pulses

By gradually decreasing the limit for the maximum number of SUS pulses, the temperature of the panel will be lowered.

- The limit for the maximum number of SUS pulses will be decreased by 8 per 5 seconds.
- The lower limit for the maximum number of SUS pulses is about 700.
- The maximum number of SUS pulses will begin to increase gradually if the conditions that led to activation of the protection function return to normal.

■

ABL adjustment value offset

By gradually offsetting the ABL adjustment value, the temperature of the panel will be lowered. The number of SUS pulses, which is determined based on the input APL (average picture level), will be decreased.

- The ABL adjustment value will be offset by one step per 30 seconds.
- The ABL adjustment value will be gradually restored if conditions that let to activation of the protection function return to normal.




Fig. 2: Detection example: SCAN IC protection





Fig. 3: Detection example: Protection against panel cracking

Fig. 1: Relationship between input APL and number of SUS pulses

## 5.6 OUTLINE OF THE OPERATION

### [1] PANEL DRIVE-POWER ON/OFF FUNCTION

#### Function:

It is an operational mode where the digital signal processing performs circuit operation but the power is not supplied to the panel driving system (Vsus, VAddress) in order to avoid a power down (PD).

#### Application:

1. When it is necessary to check whether the signal output is correctly reaching the drive system in a repairing activity etc.
2. In the case of a PD, to determine whether the problem is with the panel drive-power supply or with the other system power supply.


#### Method:

1. Short-circuit between the specified location of the POWER SUPPLY Unit and GND (Multi base section recommended), using a jumper with alligator clips (refer to the photos below).
2. Execute [DRV S00] by RS-232C command. ([DRV S01] for release)


#### Supplemental explanation:

- When the panel drive-power is in OFF state, there will be no PD, except PS\_PD, as the PD signal has been muted.
- If the clip is removed in the OFF state of the panel drive-power, PD will take place at the instance of clip removal. Therefore, be sure to remove the clip after turning the power OFF.
- Under RS-232C command control, [DRV S01] (release) is possible during power ON. However, there is a possibility of damaging the set. Therefore, make this operation only after turning the power OFF.
- Command [DRV S00/S01] is effective even during standby.
- Setting with RS-232C commands or the remote control unit is enabled during Standby mode. However, if the unit is left unoperated for about 10 seconds in Standby mode after setting with RS-232C commands or the remote control unit is completed, the setting will become void.
- When the main power switch is set to OFF, no command is accepted.
- Setting with RS-232C commands or the remote control unit will become void if the AC power cord is unplugged, the main power switch is set to OFF, or the unit is left unoperated for about 10 seconds in Standby mode.

When the panel drive-power is ON




When the panel drive-power is OFF




## [2] SPECIFICATION OF THE FAN CONTROL

### ■ Block diagram

The external fans cool down the whole unit.



### ■ Operation specifications




- The operating temperature of the fan is higher than the ambient temperature, because the sensor temperature is read by the microcomputer.
  - If the critical values for signals are displayed in the address circuit, the fan may be activated or be rotated at higher speed in response to values lower than the set temperature values shown above.
  - Depending on the ventilation conditions behind the unit, the fan may be activated or be rotated at higher speed in response to values lower than the set temperature values shown above.
  - When the temperature rises, the sensor voltage of TEMP3 increases.
  - When the voltage of the DAC output from the Panel Main microcomputer decreases, rotation speed of the fan rises.
  - Normally, the T1 temperature sensor output is used to control the fan.
- The T2 sensor detects the temperature inside the unit and assists T1.

### [3] PROCESSING IN ABNORMALITY

#### Speaker short-circuit

##### ● Circuit configuration



##### ● Specifications for port monitoring

Port Name	SD/PD Indication	Determination Condition	Monitoring conditions	Operation
A_NG_B	AUDIO	Shutdown occurs when the signal is "L." 30 mS * 10 times	DC_IN = "H" (always) (Monitoring starts 2 sec after the above conditions are established.)	The main CPU operations described below will be performed when either "A_NG_B = L" or "OTW = L" is detected (established) under the monitoring conditions.
OTW	AUDIO	Shutdown occurs when the signal is "L." 120 mS * 3 times		

##### ● Operation specifications of the main CPU

- (1) Establish the short-circuit of the speaker by the main CPU
  - After a warning indication is displayed for 5 sec, a shutdown is generated (the blue LED flashes 5 times).
  - A warning indication is displayed for all input-signal types.
  - Example of a warning indication: "The speaker terminals are short-circuited. After reconnection, turn the unit on again."

##### (2) Display conditions

When the panel is on: A warning indication is displayed immediately.

When the panel is off: A warning indication is not displayed immediately but is displayed when the panel is turned on.


**Note:** A warning indication is displayed each time the panel is turned on if the conditions for a shutdown persist.

##### ● Conditions for resetting the circuits

The circuits will be reset upon Standby ON/OFF.

#### Power supply

##### ● Circuit configuration




##### ● Specifications for port monitoring

Port Name	SD/PD Indication	Determination Condition	Monitoring conditions	Operation
DC_IN	PANEL MAIN power (MB-POW)	If the signal to DC IN does not become H within 5 seconds after the PON command is issued, the unit will shut itself off.	• During panel screen ON	Shutdown occurs immediately Blue LED flashes 13 times

## Fan and temperature sensor

### ● Circuit configuration



### ● Specifications for port monitoring

Port Name	SD/PD Indication	Determination Condition	Monitoring conditions	Operation
FAN_NG_A FAN_NG_B	FAN	Shutdown occurs when the signal is "H." 1 S * 15 times	DC_IN = H and FAN_ON_A = H (Monitoring starts 3 sec after the above conditions are established.)	Shutdown occurs immediately Blue LED flashes 10 times
TEMP1	Panel temperature is high Panel temperature is low	Shutdown occurs if any values equal to or greater than minimum to require a shutdown are detected. 200 mS * 5 times	Digital video RST2 = H	Shutdown occurs after waiting for 30 sec. Blue LED flashes 4 times Shutdown occurs after waiting for 3 sec. Blue LED flashes 4 times
TEMP3_1	Ambient temperature of the display	Shutdown occurs if any values equal to or greater than minimum to require a shutdown are detected. 1 S * 3 times	DC_IN = H (Monitoring starts 1 sec after the above conditions are established.)	In the Panel screen ON: Shutdown occurs after the warning indication is displayed for 30 sec. Blue LED flashes 11 times
TEMP3_2	Inside temperature of the display	Shutdown occurs if any values equal to or greater than minimum to require a shutdown are detected. 1 S * 3 times	DC_IN = H (Monitoring starts 1 sec after the above conditions are established.)	In the Panel screen ON: Shutdown occurs after the warning indication is displayed for 30 sec. Blue LED flashes 11 times




## [4] Standalone Operation Mode

Standalone Operation mode is available with the KRP-600P and KRP-500P, by issuing the RS-232C command shown below. After disconnecting the system cable, connect an RS-232C cable to the display unit to issue a command.


SYSS00: Standalone Operation mode

SYSS01: System Operation mode



### Notes:

- To update the software for the display, disconnect the system cable, connect an RS-232C cable (straight), then perform updating.
- During System Operation mode, most of the RS-232C commands are invalid.
- The setting data during Standalone Operation mode immediately before the display is turned off will be stored in memory. After finishing operation in Standalone Operation mode, be sure to issue the SYSS01 command to return the display to System Operation mode before reconnecting it to the MR. If the display is connected to the MR without returning it to System Operation mode, the MR will automatically enter Standby mode soon after it is turned on, in which case no image will be displayed even though the display is turned on.
- No audio nor video signals are output if any display port cable other than the one for this display is connected to its system cable port (terminal). The mask signal (output in response to a mask command) is the only video output available during Standalone Operation mode.
- During normal System Operation mode (SYSS01) the display monitors the connection status with the MR. If communication between the MR and the display cannot be established for any reason, such as disconnection of the system cable or MR's AC power being off, a system error warning will be indicated with the LED and on the mask screen for about 10 seconds, after which the display will automatically shut itself off. (Even after power-off, flashing of the LED for warning continues.)



## 5.7 OUTLINE OF RS-232C COMMAND

A

### [1] PREPARED TOOLS

- It is necessary to prepare the following one to use 232C command.
- PC
  - Application for control
  - 232C cable (straight)
- \* The setting of the Com port cannot be communicated if it doesn't do correctly.  
(Please follow a set explanation of PC in the Com port)

B

■

### [2] USING RS-232C COMMANDS

Issue the SYSS00 command to set the unit to Standalone Operation mode.

C

■

D

■

E

■

F



## 5.8 LIST OF RS-232C COMMANDS

**Note:** While the display is in System Operation mode (SYSS01) with the Media Receiver (MR,) among the received commands via the RS-232C connector on the display, only the SYS commands are valid.  
To enable other RS-232C commands, set the display to Standalone Operation mode (SYSS00).

### RS-232C command list

Command		Function	Command Receiving UCOM		Last Memory	Effective only during FAY	Remarks
			MOD	PM			
A							
ABL	***	To adjust the upper limit of power	●		MOD	●	
ALM	S00	To enable SD operation of the display main unit		●	PM		
	S01	To disable SD operation of the display main unit		●	PM		
AP0	S**	Addresses L1 and L2 setting	●		MOD	●	For enabling changed setting, it is necessary to turn the unit off then back on again.
AP1	S**	Addresses L3 and L4 setting	●		MOD	●	
AP2	S**	Addresses U1 and U2 setting	●		MOD	●	
AP3	S**	Addresses U3 and U4 setting	●		MOD	●	
APN	***	Average number of pulses for 1V	●		MOD	●	
AMP	S00	To set audio muting to OFF		●			
	S01	To set audio muting to ON		●			
B							
BCP		To copy EEPROM data for backup	●		MOD	●	
BRA	S01	To set the baud rate for the RS-232C connector on the panel to 1200 bps		●	PM		Corresponding to reception via the RS-232C connector on the display
	S02	To set the baud rate for the RS-232C connector on the panel to 2400 bps		●	PM		
	S03	To set the baud rate for the RS-232C connector on the panel to 4800 bps		●	PM		
	S04	To set the baud rate for the RS-232C connector on the panel to 9600 bps		●	PM		
BSM	S00	Afterimage/Burn-In Reduction mode: OFF	●				
	S01	Afterimage/Burn-In Reduction mode: ON	●				
BZS	S00	Bezel Setup: EP		●	PM		For use by engineers
	S01	Bezel Setup: R1 (Black)		●	PM		
	S02	Bezel Setup: R2 (White)		●	PM		
	S03	Bezel Setup: R3 (Beige)		●	PM		
C							
CAL		To clear the NG (SD) history managed by the Panel Main microcomputer		●	PM	●	
CBU		To set Backup setting to "No backup"	●		MOD	●	
CHM		To clear hour-meter data	●		MOD	●	
CMT		To clear stored maximum-temperature data	●		MOD	●	
CPC		To clear the power-on count	●		MOD	●	
CPD		To clear the power-down history	●		MOD	●	
CPM		To clear pulse-meter data	●		MOD	●	
CSD		To clear the shutdown history of the DIGITAL Assy of the display unit	●		MOD	●	
CSF	S00	Color sensor function: OFF	●				
	S01	Color sensor function: ON	●				
CSM	S01	Color Space mode 1: Pioneer original standard	●				
	S02	Color Space mode 2: In compliance with the EBU standard	●				
CSB	***	Color sensor blue coefficient	●		MOD	●	
CSG	***	Color sensor green coefficient	●		MOD	●	
CSR	***	Color sensor red coefficient	●		MOD	●	
CTP	S00	Color temperature setting: OFF	●				
	S01	Color temperature setting: LOW	●				
	S02	Color temperature setting: MID LOW	●				
	S03	Color temperature setting: MID	●				
	S04	Color temperature setting: MID HIGH	●				
	S05	Color temperature setting: HIGH	●				
D							
DIZ	S00	Dither/L dither: OFF, noise: OFF	●			●	
	S01	Dither/L dither: ON, noise: ON	●			●	
	S02	Dither/L dither: OFF, noise: ON	●			●	
	S03	Dither/L dither: ON, noise: OFF	●			●	
DRV	S00	Panel drive-power: OFF	●				
	S01	Panel drive-power: ON	●				

A

Command		Function	Command Receiving UCOM		Last Memory	Effective only during FAY	Remarks
			MOD	PM			
F							
FAJ		To set the flag for DIGITAL Assy adjustment to “Adjusted”	●		MOD	●	
FAN		Factory mode: OFF	●	●		●	
FAY		Factory mode: ON	●	●			
FBM	S00	OFF (disabling in-phase SUS drive)	●		MOD	●	For enabling changed setting, it is necessary to turn the unit off then back on again.
	S01	MODE 1 (enabling in-phase SUS drive)	●		MOD	●	
FCP	S00	To cancel Panel FAN Control mode (Normal mode)		●	PM	●	
	S01	To set to Panel FAN Control MAX mode		●	PM	●	
	S02	To set to Panel FAN Control MIN mode		●	PM	●	
	S03	To set to Panel FAN Control STOP mode		●	PM	●	
FSP		To set the Panel main microcomputer to factory-preset values		●	PM	●	
L							
LED	S00	Display front indicators: All unlit		●		●	Corresponding to reception via the RS-232C connector on the display
	S02	Display front indicators: Normal operation		●		●	
	S10	Display front indicators: ON lit		●		●	
	S11	Display front indicators: STANDBY lit		●		●	
M							
MIR	S00	Mirror indication mode: OFF	●				
	S01	Mirror indication mode: Flip horizontal	●				
	S02	Mirror indication mode: Flip vertical	●				
	S03	Mirror indication mode: Flip horizontal and vertical	●				
MKC	S00	MASK OFF	●		MOD		
	S01	H RAMP (Slant 1) M	●		MOD	●	
	S02	H RAMP (Slant 4) M	●		MOD	●	
	S03	Slanting ramp M	●		MOD	●	
	S04	30 for aging	●		MOD	●	
	S05	05 for aging	●		MOD	●	
	S06	Afterimage wiping 1	●		MOD	●	
	S07	Afterimage wiping 2	●		MOD	●	
	S08	White (luminance change)	●		MOD	●	
	S09	Peak detection raster	●		MOD	●	
	S10	Address-lack check	●		MOD	●	
	S11	To scroll vertical green lines	●		MOD	●	
	S12	To scroll horizontal green lines	●		MOD	●	
	S13	To scroll vertical ramp vertically (white)	●		MOD	●	
	S14	To scroll vertical ramp vertically (green)	●		MOD	●	
	S15	To scroll horizontal ramp horizontally (white)	●		MOD	●	
	S16	To scroll horizontal ramp horizontally (green)	●		MOD	●	
S17	Crosshatch + Window	●		MOD	●		
MKS	S00	MASK OFF	●		MOD		
	S01	H RAMP (Slant 1)	●		MOD	●	
	S02	H RAMP (Slant 4)	●		MOD	●	
	S03	V RAMP (Slant 1)	●		MOD	●	
	S04	Slanting ramp	●		MOD	●	
	S05	Window (Hi= 870, Lo= 102)	●		MOD	●	
	S06	Window (Hi= 1023, Lo= 102)	●		MOD	●	
	S07	Window (Hi= 1023, Lo= 000)	●		MOD	●	
	S08	Window (Hi= 1023) 4%	●		MOD	●	
	S09	Window (Hi= 1023) 1.25%	●		MOD	●	
	S10	Window (1/7LINE)	●		MOD	●	
	S11	STRIPE (MGT/GRN)	●		MOD	●	
	S12	STRIPE (GRN/MGT)	●		MOD	●	
	S13	Checker in monochrome (1 line)	●		MOD	●	
	S14	Checker in monochrome (2 lines)	●		MOD	●	
	S15	Checker in monochrome (4 lines)	●		MOD	●	
	S16	Checker in monochrome (8 lines)	●		MOD	●	
	S17	COLOR BAR	●		MOD	●	
	S18	Slanting lines	●		MOD	●	
	S19	Checker in black and red (1 line)	●		MOD	●	
S20	Checker in black and red (2 lines)	●		MOD	●		

Command		Function	Command Receiving UCOM		Last Memory	Effective only during FAY	Remarks
			MOD	PM			
M							
MKS	S21	Checker in black and red (4 lines)	●		MOD	●	
	S22	Checker in black and red (8 lines)	●		MOD	●	
	S23	Afterimage wiping (RGB zigzag, V reverse)	●		MOD	●	
	S24	Black raster (maximum pulse count)	●		MOD	●	Change of the Peak Brightness Detection function (PKD) impossible
	S25	1 for perfect linear	●		MOD	●	
	S26	2 for perfect linear	●		MOD	●	
	S27	3 for perfect linear	●		MOD	●	
	S28	4 for perfect linear	●		MOD	●	
	S29	RGB checker 1	●		MOD	●	
	S30	RGB checker 2	●		MOD	●	
	S31	Window RED (RED= 1023)	●		MOD	●	
	S32	Window GREEN (GREEN= 1023)	●		MOD	●	
	S33	Window BLUE (BLUE= 1023)	●		MOD	●	
	S34	Horizontal stripes for even-numbered lines	●		MOD	●	
	S35	Horizontal stripes for odd-numbered lines	●		MOD	●	
	S36	Afterimage test 1	●		MOD	●	
	S37	Afterimage test 2	●		MOD	●	
	S38	Afterimage test 3	●		MOD	●	
	S39	Afterimage test 4	●		MOD	●	
	S40	Slanting ramp in Red only	●		MOD	●	
	S41	Slanting ramp in Green only	●		MOD	●	
	S42	Slanting ramp in Blue only	●		MOD	●	
	S43	1 for checking lighting of the display	●		MOD	●	
	S44	2 for checking lighting of the display	●		MOD	●	
	S45	5 for perfect linear	●		MOD	●	
	S46	6 for perfect linear	●		MOD	●	
	S47	7 for perfect linear	●		MOD	●	
	S48	8 for perfect linear	●		MOD	●	
	S49	Mask for ABL adjustment	●		MOD	●	
MKR	S00	MASK OFF	●		MOD		
	S01	Raster - White	●		MOD	●	
	S02	Raster - Red	●		MOD	●	
	S03	Raster - Green	●		MOD	●	
	S04	Raster - Blue	●		MOD	●	
	S05	Raster - Black	●		MOD	●	
	S06	Raster - Cyan	●		MOD	●	
	S07	Raster - Magenta	●		MOD	●	
	S08	Raster - Yellow	●		MOD	●	
	S09	Raster - Light purple	●		MOD	●	
	S10	Raster - Pink	●		MOD	●	
	S11	Raster - Yolk-colored	●		MOD	●	
	S12	Raster - Light blue	●		MOD	●	
	S13	Raster - Beige	●		MOD	●	
	S14	Raster - Red 996+	●		MOD	●	
	S15	Raster - Red 1023+	●		MOD	●	
	S16	Raster - Gren 1023+	●		MOD	●	
	S17	Raster - Blue 1023+	●		MOD	●	
	S18	Raster - Red 626+	●		MOD	●	
	S19	Raster - Green 718+	●		MOD	●	
	S20	Raster - Blue 626+	●		MOD	●	
	S21	Raster - Gray 120	●		MOD	●	
	S22	Raster - Cyan 169	●		MOD	●	
	S23	Raster - Magenta 169	●		MOD	●	
	S24	Raster - Yellow 169	●		MOD	●	
S25	Raster - Gray 307	●		MOD	●		

A

B

C

D

E

F

Command		Function	Command Receiving UCOM		Last Memory	Effective only during FAY	Remarks
			MOD	PM			
N							
NGP	S00	Negative/positive inverse: OFF	●				
	S01	Negative/positive inverse: ON	●				
P							
PAV	S00	AV selection: FACTORY	●				
	S01	AV selection: STANDARD/PERFORMANCE	●				
	S02	AV selection: DYNAMIC	●				
	S03	AV selection: MOVIE	●				
	S04	AV selection: GAME	●				
	S05	AV selection: SPORTS	●				
	S06	AV selection: PURE	●				
	S07	AV selection: USER	●				
	S08	AV selection: isf-DAY	●				
	S09	AV selection: isf-NIGHT	●				
	S10	AV selection: OPTIMUM	●				
	S11	AV selection: isf-AUTO	●				
	S12	AV selection: Standerd	●				
	S13	AV selection: Reserved (Australian standard)	●				
PBH	***	Panel white balance adjustment-Blue high-light	●		MOD	●	
PBL	***	Panel white balance adjustment-Blue low-light	●		MOD	●	
PBX	***	Panel Bx measurement value	●		MOD	●	
PBY	***	Panel By measurement value	●		MOD	●	
PCS	S00	Normal operation	●				
	S01	Catalog specifications operation	●				
PDM	S00	To enable power-down operation (To input a PD signal to the POWER SUPPLY Unit)	●				
	S01	To disable power-down operation (Not to input a PD signal to the POWER SUPPLY Unit)	●				
PES	S00	Common to displays for consumer use: Standard	●				
	S01	Common to displays for consumer use: Power-save 1	●				
	S02	Common to displays for consumer use: Power-save 2	●				
	S10	Domestic standard for displays for consumer use: Standard	●				
	S11	Domestic standard for displays for consumer use: Power-save 1	●				
	S12	Domestic standard for displays for consumer use: Power-save 2	●				
PFL	S**	Correction of luminance at the center of the screen	●				
	S00	Correction of luminance at the periphery of the screen: OFF	●				
	S01	Correction of luminance at the periphery of the screen: Fixed at ON	●				
	S02	Correction of luminance at the periphery of the screen: APL-interlocked to ON	●				
PFN		Panel module: Factory mode OFF	●			●	
PFS		Panel module: Factory-preset settings	●		MOD	●	
PFY		Panel module: Factory mode ON	●				Mask setting and MTB picture-quality settings remain the same.
PGB	S00	Blue gamma setting: Straight	●				
	S01	Blue gamma setting: Fixed at 1.6	●				
	S02	Blue gamma setting: Fixed at 1.7	●				
	S03	Blue gamma setting: Fixed at 1.8	●				
	S04	Blue gamma setting: Fixed at 1.9	●				
	S05	Blue gamma setting: Fixed at 2.0	●				
	S06	Blue gamma setting: Fixed at 2.1	●				
	S07	Blue gamma setting: Fixed at 2.2	●				
	S08	Blue gamma setting: Fixed at 2.3	●				
	S09	Blue gamma setting: Fixed at 2.4	●				
	S10-31	Blue gamma setting: Customized	●				
PGG	S00	Green gamma setting: Straight	●				
	S01	Green gamma setting: Fixed at 1.6	●				
	S02	Green gamma setting: Fixed at 1.7	●				
	S03	Green gamma setting: Fixed at 1.8	●				
	S04	Green gamma setting: Fixed at 1.9	●				
	S05	Green gamma setting: Fixed at 2.0	●				
	S06	Green gamma setting: Fixed at 2.1	●				
	S07	Green gamma setting: Fixed at 2.2	●				

Command		Function	Command		Last	Effective only	Remarks	
			Receiving	UCOM				Memory
MOD								PM
P								
PGG	S08	Green gamma setting: Fixed at 2.3	●					
	S09	Green gamma setting: Fixed at 2.4	●					
	S10-31	Green gamma setting: Customized	●					
PGH	***	Panel white balance adjustment-Green high-light	●		MOD	●		
PGL	***	Panel white balance adjustment-Green low-light	●		MOD	●		
PGX	***	Panel Gx measurement value	●		MOD	●		
PGY	***	Panel GY measurement value	●		MOD	●		
PGR	S00	Red gamma setting: Straight	●					
	S01	Red gamma setting: Fixed at 1.6	●					
	S02	Red gamma setting: Fixed at 1.7	●					
	S03	Red gamma setting: Fixed at 1.8	●					
	S04	Red gamma setting: Fixed at 1.9	●					
	S05	Red gamma setting: Fixed at 2.0	●					
	S06	Red gamma setting: Fixed at 2.1	●					
	S07	Red gamma setting: Fixed at 2.2	●					
	S08	Red gamma setting: Fixed at 2.3	●					
	S09	Red gamma setting: Fixed at 2.4	●					
	S10-31	Red gamma setting: Customized	●					
PKD	S00	Peak Brightness Detection: OFF	●			●		
	S01	Peak Brightness Detection: ON	●			●		
PKL	S00	No brightness limitation: 100%	●					
	S01	Brightness limitation1: 87%	●					
	S02	Brightness limitation2: 73%	●					
	S03	Brightness limitation3: 60%	●					
	S04	Brightness limitation4: 52%	●					
	S05	Brightness limitation5: 40%	●					
	S06	Brightness limitation6: 27%	●					
	S07	Brightness limitation7: 13%	●					
PMT	S00	To cancel panel muting	●					
	S01	Panel muting	●				Muting cannot be performed while the built-in mask signal output is being displayed.	
POF		To turn the unit OFF	●	●	PM			
PON		To turn the unit ON	●	●	PM			
PPT	S00	Panel Protection function: OFF	●			●		
	S01	Panel Protection function: ON	●			●		
PRH	***	Panel white balance adjustment-Red high-light	●		MOD	●		
PRL	***	Panel white balance adjustment-Red low-light	●		MOD	●		
PRX	***	Panel Rx measurement value	●		MOD	●		
PRY	***	Panel Ry measurement value	●		MOD	●		
Q								
QAJ		To acquire various adjustment values	●					
QAL		To acquire the NG (SD) history managed by the Panel Main microcomputer		●				
QPB		To acquire various data managed by the Panel Main microcomputer		●				
QPD		To acquire the history of power-down places	●					
QPM		To acquire pulse-meter data	●					
QPW		To acquire white balance adjustment data of the panel	●					
QPF		To acquire characteristics/function settings data of the panel	●					
QS1		To acquire panel information, such as software versions	●					
QS2		To acquire panel status data, such as acquired temperatures of the panel in cases of operation changes	●					
QS3		To acquire panel information other than the above	●					
QS5		To acquire panel information (Individual functions)	●					
QSB		To acquire versions of various microcomputers of the panel main unit		●				
QSP		To acquire subversions of various microcomputers of the panel	●					
QSD		To acquire shutdown data	●					
QSI		To acquire signal-related data	●					

A

Command		Function	Command Receiving UCOM		Last Memory	Effective only during FAY	Remarks
			MOD	PM			
R							
R1K	***	First reset (wedge width)	●		MOD	●	
R2K	***	Second reset (wedge width)	●		MOD	●	
RBL	S00-7	Correction of panel deterioration, Blue level 0 to 7	●		MOD	●	For enabling changed setting, it is necessary to turn the unit off then back on again.
RGL	S00-7	Correction of panel deterioration, Green level 0 to 7	●		MOD	●	
RLS	S00	Room light sensor operation: OFF	●				
	S01-5	Room light sensor operation: 1 to 5	●				
RRL	S00-7	Correction of panel deterioration, Red level 0 to 7	●		MOD	●	For enabling changed setting, it is necessary to turn the unit off then back on again.
S							
SAT	***	Timing adjustment between the scan and address	●		MOD	●	
SCW	S00	Normal operation	●				
	S01	Warning, depiction in the blue window (left)	●				
	S02	Warning, depiction in the red window (right)	●				
SDM	S00	To enable shutdown operation	●				
	S01	To disable shutdown operation	●				
SFR	S01-8	Measurement against AM radio noise: Patterns 1 to 8	●		MOD	●	For enabling changed setting, it is necessary to turn the unit off then back on again.
SKM	S00	Streaking Correction mode: OFF	●		MOD	●	
	S01-8	Streaking Correction mode: 1 to 8	●		MOD	●	
SMC	S00	Smooth clear driving: OFF	●			●	
	S01	Smooth clear driving: ON	●			●	
SN0	***	Serial No. setting 0 (Panel)	●		MOD	●	
SN1	***	Serial No. setting 1 (Panel)	●		MOD	●	
SN2	***	Serial No. setting 2 (Panel)	●		MOD	●	
SN3	***	Serial No. setting 3 (Panel)	●		MOD	●	
SN4	***	Serial No. setting 4 (Panel)	●		MOD	●	
SQM	S01	VIDEO sequence setting	●				
	S02	PC sequence setting	●				
	S03	Retake sequence setting	●				
SSM	S00	SSCG OFF	●			●	
	S01	SSCG ON	●			●	
SWA	***	Estimate value for the color of the light source (absolute value)	●				
SWF	S00	Reflection of estimate value for the color of the light source: OFF	●				
	S01	Reflection of estimate value for the color of the light source: ON	●				
SWR	***	Estimate value for the color of the light source (relative value)	●				
SYS	S00	Disabling monitoring of system cable disconnection (Standalone Operation)		●	PM		Effective only for the RS-232C connector on the panel
	S01	Enabling monitoring of system cable disconnection (System Operation)		●	PM		Effective only for the RS-232C connector on the panel
T							
THS	S00	Interlocked operation of the theater port: OFF	●				
	S01	Interlocked operation of the theater port: ON	●				
U							
UAJ		To set the flag for DIGITAL Assy adjustment to "Not adjusted"	●		MOD	●	
V							
V1F	***	To adjust the reference value for VyknoFs 1 and 2 voltages	●		MOD	●	
V3F	***	To adjust the reference value for VyknoFs 3 voltage	●		MOD	●	
V4F	***	To adjust the reference value for VyknoFs 4 voltage	●		MOD	●	
VFQ	S02	To set the frequency during mask display to VD-50 Hz	●		MOD	●	
	S03	To set the frequency during mask display to VD-60 Hz	●		MOD	●	
	S05	To set the frequency during mask display to VD-72 Hz	●		MOD	●	
	S06	To set the frequency during mask display to VD-75 Hz-1	●		MOD	●	
	S07	To set the frequency during mask display to VD-75 Hz-2	●		MOD	●	
	S13	To set the frequency during mask display to PC-60 Hz	●		MOD	●	
VOF	***	To adjust the reference value for VysnoFs voltage	●		MOD	●	
VRP	***	To adjust the reference value for Vyprst voltage	●		MOD	●	
VSU	***	To adjust the reference value for Vsus voltage	●		MOD	●	
VX1	***	To adjust the reference value for Vxpofs1 voltage	●		MOD	●	
VX2	***	To adjust the reference value for Vxpofs2 voltage	●		MOD	●	
VYF	***	To adjust the reference value for ΔVyknoFs1,2/3/4 voltages	●		MOD	●	

A

Command		Function	Command Receiving UCOM		Last Memory	Effective only during FAY	Remarks
			MOD	PM			
W							
WBI	S00	Panel WB standard output mode: OFF	●			●	
	S01	Panel WB standard output mode: ON	●			●	
X							
X1B	***	3SF and after to First X SUS (oscillation increase amount)	●		MOD	●	
X3B	***	2SF to Third X SUS (oscillation increase amount)	●		MOD	●	
XSB	***	2SF to Repetition X SUS (oscillation increase amount)	●		MOD	●	
Y							
Y1K	***	1SF to Y SUSTAIL (wedge width)	●		MOD	●	
Y1Z	***	1SF to Y SUSTAIL (oscillation decrease amount)	●		MOD	●	
Y2B	***	2SF to Second Y SUS (oscillation increase amount)	●		MOD	●	
Y2K	***	2SF to Y SUSTAIL (wedge width)	●		MOD	●	
Y2Z	***	2SF to Y SUSTAIL (oscillation decrease amount)	●		MOD	●	
YNK	***	3SF and after (2-pulse SSF) to Y SUSTAIL (wedge width)	●		MOD	●	
YTK	***	3SF and after to Y SUSTAIL (wedge width)	●		MOD	●	
YTZ	***	3SF and after to Y SUSTAIL (oscillation decrease amount)	●		MOD	●	
YSB	***	2SF to Repetition Y SUS (oscillation increase amount)	●		MOD	●	

C

D

E

F

[1] QS1 (PANEL STATUS)

Model information and version information are returned.

Command Format	Effective Operation Modes	Function	Remarks
[QS1]	Every Time	Output of status	Return data: 3 (ECO) + 112 (DATA) + 2 (CS) = 117 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QS1
1	Resolution/Size	1 byte	F
2	Panel Generation	1 byte	9
3	Destination	1 byte	*
4	Grade	1 byte	*
5	Panel Product Form	1 byte	A
6	Boot version of Module microcomputer	3 byte	-01A
7	Program version of Module microcomputer	8 byte	-01A ' ' ' '
8	Boot version of sequence processor	3 byte	-01Z
9	Program version of sequence processor	8 byte	-01Z ' ' ' '
10	Panel information	8 byte	G9_50F_2
11	Derivative operation identification	1 byte	*
12	Reserved (panel section)	7 byte	*****
13	, (comma)	1 byte	,
14	MTB generation	1 byte	9
15	MTB destination	1 byte	A
16	MTB grade	1 byte	H
17	MTB product form	1 byte	B
18	Program version of IF microcomputer	8 byte	-01A
19	Boot version of IF microcomputer	4 byte	01A
20	Program version of Main microcomputer	8 byte	-01A
21	Boot version of Main microcomputer	4 byte	01A
22	Common version of ASIC	8 byte	-01A
23	Boot version of ASIC	8 byte	01A
24	PRS version of ASIC	8 byte	-01A
25	PIC version of ASIC	8 byte	-01A
26	Common version of the Digital Tuner	8 byte	-0A
27	Boot version of the Digital Tuner	4 byte	01A
CS	2 Byte	2 byte	4A

11: Derivative Operation Identification	
*	Standard model operation
1	Derivative model operation

14: MTB Generation	
9	G9

15: MTB Destination	
A	North America
C	China
E	Europe
G	General
J	Japan
U	Australia

16: MTB Grade	
H	Elite/One body Europe HD /System Europe HD/One body Australia
T	Regular/One body Europe SD
D	Derivative Model
*	No Grade (Japan/General/China)

17: MTB Product Form	
B	One body model
S	System model

1: Resolution/Size	
F	50-FHD (1920*1080)
G	60-FHD (1920*1080)

2: Panel Generation	
9	G9

3: Destination	
*	Commonness

4: Grade	
*	Commonness
Z	Evaluation

5: Not used	
A	"A" fixed

10: Panel Information (8 Byte)		
1 to 2nd byte	G9	Generation information
4 to 5th byte	50	50 inch
	60	60 inch
6th byte	F	FHD
8th byte	3	50 inch 2nd PLANT (Reserved)
	2	50 inch 2nd PLANT
	1	50 inch 1st PLANT
	'	Others

' = space



## [2] QS2 (PANEL OPERATION DATA)

The command QS2 is for acquiring data on the panel's operational information.

Command Format	Effective Operation Modes	Function	Remarks
[QS2]	Every Time	Output of status	Return data: 3 (ECO) + 34 (DATA) + 2 (CS) = 39 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QS2
1	Notify of the standby operation transition	1 byte	1
2	Adjustment flag of the main unit	1 byte	0
3	Adjustment-data backup flag	1 byte	0
4	"1st PD" data	1 byte	0
5	"2nd PD" data	1 byte	0
6	Color sensor data	1 byte	0
7	Reserved	2 byte	**
8	Temperature data (TEMP 1)	3 byte	128
9	SD data	1 byte	0
10	SD subcategory data	1 byte	0
11	Operation status induced by SD	1 byte	0
12	Reserved	3 byte	***
13	HOUR METER	8 byte	00000259
14	MASK indication	1 byte	0
15	Still picture detection	1 byte	0
16	SCAN protection detection	1 byte	0
17	Panel crack detection	1 byte	0
18	Address emergency detection	1 byte	0
19	Reserved	4 byte	****
CS	2 Byte	2 byte	4A

### 1: Power supply status

P	During power ON
0	Shifting to Passive Standby is not possible.
1	Shifting to Passive Standby is possible.

### 2: Adjustment flag of the main unit

0	Adjustment completed
1	Adjustment not completed

### 3: Adjustment-data backup flag

0	Adjustment completed
1	Adjustment not completed

### 4, 5: PD data

0	No PD data
2	POWER
3	SCAN
4	SCN-5V
6	Y-DCDC
7	Y-SUS
8	ADRS
A	X-DCDC
B	X-SUS
C	DIG-DCDC
F	UNKNOWN

### 6: Color sensor data

-	Function OFF (including standby)
0	Normal
1	Hardware connection is not completed
2	Data mismatching

### 9: SD data

0	No SD
1	SQ_LSI
2	MDU-DEVICE
3	RST2
4	Panel temperature

### 10-1: SD subcategory (SQ\_LSI)

0	No SD-Sub data
1	Communication error
2	Drive stop
3	BUSY
4	Version mismatching (H/S)
5	Version mismatching (H/M)
6	Version mismatching (H/I)

### 10-2: SD subcategory (MDU-DEVICE)

0	No SD-Sub data
1	EEPROM
2	BACKUP
3	DAC

### 10-3: SD subcategory (Panel temperature)

0	No SD-Sub data
1	Panel high temperature
2	Panel low temperature

### 11: Operation status induced by SD

0	Normal
1	Relay-off completed
2	During warning indication

### 14: MASK indication

0	MASK-OFF
1	MASK-ON

### 15 to 18: Detection of Each Protection function

0	Normal operation
1	At detection of protection operation

### [3] QS3 (OTHER DATA ON THE PANEL)

The command QS3 is for acquiring data on operational information of the panel.

Command Format	Effective Operation Modes	Function	Remarks
[QS3]	Every Time	Output of status	Return data: 3 (ECO) + 58 (DATA) + 2 (CS) = 63 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QS3
1	SERIAL	15 byte	-----
2	HOUR METER	8 byte	00000000
3	TOTAL HR METER	8 byte	00000000
4	PON COUNTER	8 byte	00000000
5	Panel temperature (*1)	5 byte	23.5
6	Reserved (TEMP0 acquisition)	5 byte	-----
7	MAX panel temperature history (*1)	5 byte	78.3
8	Reserved	4 byte	****
CS	2 Byte	2 byte	94

Note  
(\*1) : Centigrade scale

### [4] QS5 (COLOR SENSOR DATA)

The command QS5 is for acquiring the color sensor information.

Command Format	Effective Operation Modes	Function	Remarks
[QS5]	Every Time	Output of status	Return data: 3 (ECO) + 45 (DATA) + 2 (CS) = 50 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QS5
1	Color sensor data (Note)	1 byte	2
2	RED data of color sensor	4 byte	0425
3	GREEN data of color sensor	4 byte	2112
4	BLUE data of color sensor	4 byte	5000
5	Reserved	32 byte	** to **
CS	2 Byte	2 byte	94

Note: The color sensor data is output as the same data as QS2.

## [5] QSP (SUB VERSION OF THE PANEL SECTION)

The command QSP is for acquiring sub version data on software of the panel.

Command Format	Effective Operation Modes	Function	Remarks
[QSP]	Every Time	Output of status	Return data: 3 (ECO) + 40 (DATA) + 2 (CS) = 45 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QSP
1	MDUcom-PRG	8 byte	=01Y
2	MDUcom-DATA_TBL	8 byte	=01Y ''''
3	SQ_LSI-PRG	4 byte	=01Y
4	SQ_LSI-PIC_TBL	8 byte	=01Y ''''
5	SQ_LSI-SEQ_DATA	4 byte	=01Y
6	Reserved	8 byte	*****
CS	2 Byte	2 byte	A3

## [6] QAJ (PANEL ADJUSTMENT DATA)

The command QAJ is for acquiring the panel's factory-preset data.

Command Format	Effective Operation Modes	Function	Remarks
[QAJ]	Every Time	Output of status	Return data: 3 (ECO) + 84 (DATA) + 2 (CS) = 89 Byte

Data Arrangement	Data Length	Output Example
ECO	3 byte	QAJ
1 Vsus adjustment value	3 byte	128
2 Vysnfs adjustment value	3 byte	128
3 Vyprst adjustment value	3 byte	128
4 Vxpofs1 adjustment value	3 byte	128
5 Vxpofs2 adjustment value	3 byte	128
6 Vyknofs1,2 adjustment value	3 byte	128
7 Vyknofs3 adjustment value	3 byte	128
8 Vyknofs4 adjustment value	3 byte	128
9 Δ Vyknofs1,2/3/4 adjustment value	3 byte	128
10 Reserved	6 byte	*****
11 R1K adjustment value	3 byte	128
12 R2K adjustment value	3 byte	128
13 Y1K adjustment value	3 byte	128
14 Y1Z adjustment value	3 byte	128
15 X1B adjustment value	3 byte	128
16 Y2B adjustment value	3 byte	128
17 X3B adjustment value	3 byte	128
18 YSB adjustment value	3 byte	128
19 XSB adjustment value	3 byte	128
20 YTK adjustment value	3 byte	128
21 YTZ adjustment value	3 byte	128
22 Y2K adjustment value	3 byte	128
23 Y2Z adjustment value	3 byte	128
24 YNK adjustment value	3 byte	128
25 SAT adjustment value	3 byte	128
26 Reserved	3 byte	***
27 AM radio countermeasure	1 byte	1
28 Reserved	2 byte	**
CS 2 Byte	2 byte	B7

27: AM radio countermeasure	
n	n: 1 to 8 (SUS frequency n)

## [7] QPW (VIDEO ADJUSTMENT DATA OF THE PANEL)

The command QPW is for acquiring the factory-preset data about the video of the panel.

Command Format	Effective Operation Modes	Function	Remarks
[QPW]	Every Time	Output of status	Return data: 3 (ECO) + 40 (DATA) + 2 (CS) = 45 Byte

Data Arrangement		Data Length	Output Example	1: Type of Drive sequence		11, 12, 13: RGB Gamma setting		15: Center luminance correction		17: Interlocked with APL		18: Transition of protective operations	
ECO		3 byte	QPW	50VS	Video 50 Hz	n	00 to 31	0	OFF	0	OFF	0	Upper limit state for brightness
1	Type of drive sequence (Note 1)	4 byte	60VS	60VS	Video 60 Hz			1	ON	1	ON	1	Brightness being reduced
2	ABL adjustment table	1 byte	1	72VS	Video 72 Hz			2	ON (interlocked with APL)	2	WB interlocked ON/ $\gamma$ OFF	2	Lower limit state for brightness
3	Type of WB adjustment table (Note 1)	1 byte	1	75V1	Video 75-1 Hz					3	WB interlocked OFF/ $\gamma$ ON	3	Brightness being increased
4	ABL adjustment value	3 byte	128	75V2	Video 75-2 Hz								
5	R-HIGH adjustment value	3 byte	256	60PS	PC 60 Hz								
6	G-HIGH adjustment value	3 byte	256	2: ABL adjustment table									
7	B-HIGH adjustment value	3 byte	256	n	n: 1 to 3								
8	R-LOW adjustment value	3 byte	512	3: Type of WB adjustment table									
9	G-LOW adjustment value	3 byte	512	n	n: 1 to 4								
10	B-LOW adjustment value	3 byte	512										
11	R gamma setting	2 byte	31										
12	G gamma setting	2 byte	10										
13	B gamma setting	2 byte	10										
14	Streaking correction	1 byte	1										
15	Center luminance correction	1 byte	0										
16	Reserved	1 byte	*										
17	Interlocked with APL	1 byte	0										
18	Transition of protective operations	1 byte	0										
19	Reserved	2 byte	**										
CS	2 Byte	2 byte	37										

**Note 1:** The "75 Hz-2" Drive Sequence type signals and WB Adjustment Table 4 are output only when "75 Hz-2" (VFQS07) is selected for internal signals (mask signals).  
When external signals are selected and the Drive Sequence type is 75 Hz, "75 Hz-1" is output because "75 Hz-1" and "75 Hz-2" are not distinguished for external signals.

## [8] QPF (FUNCTION OF THE PANEL)

The command QPF is for acquiring the characteristic and the function setting value of the panel.

Command Format	Effective Operation Modes	Function	Remarks
[QPF]	Every Time	Output of status	Return data: 3 (ECO) + 69 (DATA) + 2 (CS) = 74 Byte

Data Arrangement	Data Length	Output Example
ECO	3 byte	QPF
1 R-REVISE setting value	1 byte	0
2 G-REVISE setting value	1 byte	0
3 B-REVISE setting value	1 byte	0
4 Reserved	3 byte	***
5 ADDRESS L1,L2 setting value	2 byte	01
6 ADDRESS L3,L4 setting value	2 byte	13
7 ADDRESS U1,U2 setting value	2 byte	32
8 ADDRESS U3,U4 setting value	2 byte	30
9 Reserved	4 byte	****
10 Streaking correction	1 byte	1
11 Full-screen black display mode	1 byte	1
12 Reserved	4 byte	****
13 PANEL RX	3 byte	512
14 PANEL RY	3 byte	512
15 PANEL GX	3 byte	512
16 PANEL GY	3 byte	512
17 PANEL BX	3 byte	512
18 PANEL BY	3 byte	512
19 Reserved	6 byte	*****
20 Color sensor R coefficient	3 byte	***
21 Color sensor G coefficient	3 byte	***
22 Color sensor B coefficient	3 byte	***
23 Reserved	12 byte	** to **
CS 2 Byte	2 byte	37

### 1: 2: 3: RGB-REVISE setting value

n n: 0 to 7 (Level n)

### 5 to 8: ADDRESS $\alpha$ , $\beta$ setting

nm n: 0 to 9 (Address  $\alpha$  setting PHASE n)

m: 0 to 9 (Address  $\beta$  setting PHASE m)

### 10: Streaking correction

0 OFF

n n: 1 to 8 (Mode n)

### 11: Full-screen black display mode

0 OFF (In-phase SUS drive prohibition)

1 MODE1 (In-phase SUS drive permission)

## [9] QPM (PULSE METER VALUE)

The command QPM is for acquiring the accumulated pulse count.

Command Format	Effective Operation Modes	Function	Remarks
[QPM]	Every Time	Output of status	Return data: 3 (ECO) + 40 (DATA) + 2 (CS) = 45 Byte

Data Arrangement	Data Length	Output Example
ECO	3 byte	QPM
1 Pulse meter B 1	8 byte	00000000
2 Pulse meter B 2	8 byte	00000000
3 Pulse meter B 3	8 byte	00000000
4 Pulse meter B 4	8 byte	00000000
5 Pulse meter B 5	8 byte	00000000
CS 2 Byte	2 byte	E7

### Note:

The minimum for a returned value of the pulse meter for each block (B1-B2) is one million.

## [10] QPD (POWER DOWN LOGS)

The command QPD is for acquiring data from the 8 latest power-down (PD) logs.

Command Format	Effective Operation Modes	Function	Remarks
[QPD]	Every Time	Output of status	Return data: 3 (ECO) + 80 (DATA) + 2 (CS) = 85 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QPD
1	Latest "1st PD" data	1 byte	A
2	Latest "2nd PD" data	1 byte	2
3	Data from the hour meter for the latest PD	8 byte	00010020
4	Second latest "1st PD" data	1 byte	E
5	Second latest "2nd PD" data	1 byte	9
6	Data from the hour meter for the second latest PD	8 byte	00008523
7	Third latest "1st PD" data	1 byte	4
8	Third latest "2nd PD" data	1 byte	3
9	Data from the hour meter for the third latest PD	8 byte	00004335
10	Fourth latest "1st PD" data	1 byte	2
11	Fourth latest "2nd PD" data	1 byte	0
12	Data from the hour meter for the fourth latest PD	8 byte	00000945
13	Fifth latest "1st PD" data	1 byte	4
14	Fifth latest "2nd PD" data	1 byte	0
15	Data from the hour meter for the fifth latest PD	8 byte	00000715
16	Sixth latest "1st PD" data	1 byte	A
17	Sixth latest "2nd PD" data	1 byte	2
18	Data from the hour meter for the sixth latest PD	8 byte	00000552
19	Seventh latest "1st PD" data	1 byte	A
20	Seventh latest "2nd PD" data	1 byte	0
21	Data from the hour meter for the seventh latest PD	8 byte	00000213
22	Eighth latest "1st PD" data	1 byte	D
23	Eighth latest "2nd PD" data	1 byte	0
24	Data from the hour meter for the eighth latest PD	8 byte	000001A7
CS		2 byte	27

• PD data	
0	No PD
2	P-POWER
3	SCAN
4	SCN-5V
6	Y-DCDC
7	Y-SUS
8	Address
A	X-DCDC
B	X-SUS
C	DIGI-DCDC
F	UNKNOWN

## [11] QSD (SHUTDOWN LOGS of the Panel Section)

The command QSD is for acquiring the data from the 8 latest shutdown (SD) logs of the panel section.

Command Format	Effective Operation Modes	Function	Remarks
[QSD]	Every Time	Output of status	Return data: 3 (ECO) + 80 (DATA) + 2 (CS) = 85 Byte

Data Arrangement		Data Length	Output Example
ECO		3 byte	QSD
1	Latest SD data	1 byte	1
2	Latest SD subcategory data	1 byte	0
3	Data from the hour meter for the latest SD	8 byte	00752013
4	Second latest SD data	1 byte	5
5	Second latest SD subcategory data	1 byte	0
6	Data from the hour meter for the second latest SD	8 byte	00495204
7	Third latest SD data	1 byte	2
8	Third latest SD subcategory data	1 byte	3
9	Data from the hour meter for the third latest SD	8 byte	00100355
10	Fourth latest SD data	1 byte	2
11	Fourth latest SD subcategory data	1 byte	5
12	Data from the hour meter for the fourth latest SD	8 byte	00075620
13	Fifth latest SD data	1 byte	1
14	Fifth latest SD subcategory data	1 byte	0
15	Data from the hour meter for the fifth latest SD	8 byte	00000852
16	Sixth latest SD data	1 byte	2
17	Sixth latest SD subcategory data	1 byte	2
18	Data from the hour meter for the sixth latest SD	8 byte	00000451
19	Seventh latest SD data	1 byte	0
20	Seventh latest SD subcategory data	1 byte	0
21	Data from the hour meter for the seventh latest SD	8 byte	00000000
22	Eighth latest SD data	1 byte	0
23	Eighth latest SD subcategory data	1 byte	0
24	Data from the hour meter for the eighth latest SD	8 byte	00000000
CS	2 Byte	2 Byte	7D

### • SD data

0	No SD
1	SQ_LSI
2	MDU-DEVICE
3	RST2
4	Panel temperature

### • SD subcategory (SQ\_LSI)

0	No SD-Sub data
1	Communication error
2	Drive stop
3	BUSY
4	Version mismatching (H/S)
5	Version mismatching (H/M)
6	Version mismatching (H/I)

### • SD subcategory (MDU-DEVICE)

0	No SD-Sub data
1	EEPROM
2	BACKUP
3	DAC

### • SD subcategory (Panel temperature)

0	No SD-Sub data
1	TEMP1 (high temperature)
2	TEMP1 (low temperature)



## [12] QSI (INPUT SIGNAL DATA)

The command QSI is for acquiring all data on input video signals.

Command Format	Effective Operation Modes	Function	Remarks
[QSI]	Every Time	Output of status	Return data: 3 (ECO) + 66 (DATA) + 2 (CS) = 71 Byte

Data Arrangement		Data Length	Output Example
ECO		3 Byte	QSI
1	Type of drive sequence (Note)	4 Byte	60VS
2	Type of ABL adjustment table (Note)	1 Byte	1
3	Type of WB adjustment table (Note)	1 Byte	1
4	Reserved	4 Byte	****
5	Total value of PRH	4 Byte	0256
6	Total value of PGH	4 Byte	0256
7	Total value of PBH	4 Byte	0256
8	Reserved	4 Byte	****
9	Total value of PRL	4 Byte	0512
10	Total value of PGL	4 Byte	0512
11	Total value of PBL	4 Byte	0512
12	Total value of ABL	3 Byte	128
13	V frequency distinction	4 Byte	6002
14	Reserved	4 Byte	****
15	APL acquiring data	4 Byte	1023
16	Number of SUS pulses	4 Byte	0457
17	Detection status of still picture	1 Byte	1
18	Detection status of cracking in the panel	1 Byte	1
19	Detection status of SCAN protection	1 Byte	1
20	Detection status of external protection	1 Byte	1
21	Transition of protection operations	1 Byte	0
22	Address emergency status	1 Byte	1
23	Detection status of reset operation	1 Byte	1
24	In-phase SUS mode status	1 Byte	1
25	Reserved	1 Byte	1
CS	2 Byte	2 Byte	27

### 18 to 20: Each protection function

0	Setting: OFF
1	Setting: ON (during wait)
2	Setting: ON (during operation)

### 21: Transition of protection operations

0	Upper limit status for brightness
1	Brightness being reduced
2	Lower limit status for brightness
3	Brightness being increased

### 22: Address emergency status

0	Normal status
1	Emergency status

### 23: Reset operation status

A	All reset operation
2	Interlace 1/2 reset operation
4	Interlace 1/4 reset operation
L	Reset less operation (specifications operation)

### 24: In-phase SUS mode status

0	Normal status
1	In-phase SUS mode status
2	Assist status at the cancellation

Note: The types of drive sequence and ABL/WB table are output as the same data as QPW.

### [13] DRV (PANEL DRIVE-POWER ON/OFF)

Panel drive-power ON/OFF (drive ON/OFF) is controllable.

Command Format	Operation		Remarks
	Effective Operation Modes	Function	
[DRV+S00]	Every time	DRIVE OFF	If a command is issued in Standby mode, and the unit is left unoperated for more than 10 seconds, the command will become void.
[DRV+S01]	Every time	DRIVE ON (default)	

**Note:** The function of the DRIVE OFF key on the remote control unit for servicing is the same as that of the DRVS00 command.  
(A function equivalent to that of the DRVS01 command is not provided for the remote control unit for servicing.)

### [14] FAY/FAN (ADJUSTMENT COMMANDS PERMISSION/PROHIBITION)

The commands FAY/FAN are for prohibiting/permitting panel/MTB-adjustment commands.

Command Format	Operation		Remarks
	Effective Operation Modes	Control	
[FAY]	Normal operation mode while the power is on	Adjustment command is valid.	For details, refer to the section "6.1 [3] FUNCTIONS WHEN ENTERING THE SERVICE FACTORY MODE" of the Service Manual for Media Receiver (KRP-M01).
[FAN]	During FAY	Adjustment command is invalid.	

### [15] FAJ/UAJ/CBU/BCP (BACKUP FUNCTION FOR ADJUSTMENT VALUE)

When the DIGITAL Assy is to be replaced, adjustment values can be copied from the backup EEPROM to the EEPROM of the Assy for service.

Command Format	Operation		Remarks
	Effective Operation Modes	Control	
[FAJ]	During FAY	To make the status of the EEPROM on the DIGITAL Assy "adjustment completed" and copy the data to the EEPROM for backup	This takes at least 350 msec.
[UAJ]		To make the status of the EEPROM on the DIGITAL Assy "adjustment not completed"	Only the status is changed, and the real data are not erased.
[CBU]		To make the status of the EEPROM on for backup "adjustment not completed"	Only the status is changed, and the real data are not erased. However, if the status of the EEPROM on the DIGITAL Assy is "adjustment completed," the data in the EEPROM of the DIGITAL Assy will be copied to the EEPROM for backup upon POF.
[BCP]		To copy the backup data from the EEPROM for backup to the EEPROM on the DIGITAL Assy	

## [16] QSB

Data on models and versions of the Module microcomputer and Panel Main microcomputer can be acquired.

Command Format	Effective status	Function	Remarks
[QSB]	Every time	To acquire versions of various programs managed by the Panel Main and Module microcomputers	Return data: 3 (ECO) + 87 (DATA) + 2 (CS) = 92 Byte

Data Arrangement			Data Length	Output Example	Remarks
ECO	Echo back		3	"QSB"	
1	Data managed by the Module microcomputer	Display data 1 (resolution, size)	1	F	See QS1.
2		Display data 2 (generation)	1	9	See QS1.
3		Display data 3 (destination)	1	*	See QS1.
4		Display data 4 (grade)	1	*	See QS1.
5		Display data 5 (product style)	1	A	See QS1.
6		Boot version of the Module microcomputer	3	01A	See QS1.
7		Program version of the Module microcomputer (common program of the MD microcomputer)	8	001A ‘ ’ ’ ’	See QS1.
8		Boot version of the later ASIC (SQ_LSI Boot)	3	01H	See QS1.
9		Program version of the later ASIC (common program of the SQ_LSI)	8	001Y ‘ ’ ’ ’	See QS1.
10		PANEL INFO	8	G9_50F_2	See QS1.
11		Reserved	8		(All digits are padded with asterisks.)
12	Data managed by the Panel Main microcomputer	Delimiter	1	" , "	
13		Dummy	4	"*****"	
14		Version data of the Panel Main microcomputer	3	– 01	Version of the program
			1	A	A (fixed)
			1	S	S (fixed)
			3	Space	Reserved for the version of the program
			1	Space	Reserved for the version of the boot program
			3	07A	Version of the boot program
15		Model data (Bezel color data, etc.)	1	1	1: R1 (ROM Table 1, 2: R2 (ROM Table 2), 3: R3 (ROM Table 3), E: EP (For use by engineers)
16		Firmware version data of the Displayport_Rx	16	1.10	Version of the program
17		Firmware version data of the Displayport_Rx	4	0C15	Version of hardware
18		Reserved	6		"Space"
CS	Check sum		2	(CS)	

## [17] QPB (Panel Main Operation Information)

Data on operation of the display main unit can be acquired.

Command Format	Effective status	Function	Remarks
[QPB]	Every time	To acquire data on current statuses managed by the Panel Main microcomputer	Return data: 3 (ECO) + 53 (DATA) + 2 (CS) = 58 Byte

Data Arrangement		Data Length	Output Example	Remarks
ECO	Echo back	3	"QPB"	
1	Data on panel temperature	5	*****	Temperature of the panel (in Centigrade) (Tmd)
2	Delimiter	1	","	Comma
3	Unit temperature data 1	5	*****	Temperature inside the unit (in Centigrade) (T1)
4	Delimiter	1	","	Comma
5	Unit temperature data 2 (reserved)	5	*****	Temperature inside the unit (in Centigrade) (T2) (Reserved, All digits are padded with asterisks.)
6	Delimiter	1	","	Comma
7	Unit temperature data 3 (reserved)	5	*****	Temperature inside the unit (in Centigrade) (T3) (Reserved, All digits are padded with asterisks.)
8	Delimiter	1	","	Comma
9	Fan rotation speed A	1	A	Fan setting A (S: stop, L: Low, H: High, and A: Auto)
10	Fan control A/D value (A)	3	***	Fan control D/A value, A, decimal code
11	Fan rotation speed B	1	A	Fan setting B (S: stop, L: Low, H: High, and A: Auto)
12	Fan control A/D value (B)	3	***	Fan control D/A value, B, decimal code
13	Room Light Sensor level	1	5	0-7, padded with an asterisk during the sensor is off
14	Room Light Sensor A/D value	4	****	Brightness sensor A/D value, decimal code
15	Dummy 1	2	**	All digits are padded with asterisks.
16	System Operation mode of the panel	1	S	S: System Operation mode, T: Standalone Operation mode
17	Dummy 2	2	**	All digits are padded with asterisks.
18	Audio muting	1	0	0: Canceling muting, 1: Muting
19	Reserved	10	**	All digits are padded with asterisks.
CS	Check sum	2	(CS)	

## [18] QAL (Shutdown information for the display main unit)

Up to the 8 latest shutdown logs of the display main unit can be acquired.

Command Format	Effective status	Function	Remarks
[QAL]	Every time	To acquire up to the 8 latest shutdown logs managed by the Panel Main microcomputer	Return data: 3 (ECO) + 96 (DATA) + 2 (CS) = 101 Byte

Data Arrangement		Data Length	Output Example	Remarks
ECO	Echo back	3	"QAL"	
1	Data on the latest shutdown	12		Reasons of the latest 8 shutdowns and hour-meter data when the shutdowns were generated (For details, see the tables below.)
2	Data on the 2nd latest shutdown	12		
3	Data on the 3rd latest shutdown	12		
4	Data on the 4th latest shutdown	12		
5	Data on the 5th latest shutdown	12		
6	Data on the 6th latest shutdown	12		
7	Data on the 7th latest shutdown	12		
8	Data on the 8th latest shutdown	12		
CS	Check sum	2	(CS)	

### ■ Shutdown (SD) data

Order	Content	Length (BYTE)	Value	Remarks
1	SD category data	1		SD category (For details, see the table below.) 0 for no SD
2	SD subcategory data	1		SD subcategory (For details, see the table below.)
3	HOUR METER	7		Time when a shutdown managed by the Panel Main microcomputer was generated All digits are padded with asterisks when there was no SD.
4	Dummy	3		All digits are padded with asterisks.

### ■ SD categories/SD subcategories

SD category (response)	Reason for SD	w/wo subcategory	SD subcategory (response)	Reason for subcategory
"0"	No SD (no abnormality)	Without subcategory	"0"	
"5"	Shutdown signal from D-Amp. Short-circuit of speaker terminal.	With subcategory	"1"	A_NG_B : L
			"2"	OTW : L
"6"	Failure in module microcomputer communication	Without subcategory	"0"	
"8"	Failure in IIC communication	With subcategory	"1"	Displayport receiver
			"2"	Failure in AUDIO PWM IC communication
"A"	FAN stop	With subcategory	"1"	FAN_A stop
			"2"	FAN_B stop
"B"	Abnormal temperature of the display unit (high)	With subcategory	"1"	High temperature at Temperature Sensor 1
			"2"	High temperature at Temperature Sensor 2
"D"	Abnormality in power of the Display MAIN Assy	With subcategory	"1"	Abnormality in 6.5V power supply.

6. SERVICE FACTORY MODE

6.1 DETAILS OF THE FACTORY MENU

A

The Factory menu will be displayed only when the Media Receiver is connected. For details on how to enter Factory menu, refer to “6.1 DETAILS OF THE FACTORY MENU” in the service manual for the Media Receiver.

■ [1] PANEL FACT.

■ Operation Items

This is the menu screen for the adjustment of the panel. Data acquisition and value adjustment can be performed for the following items:

B

No.	Indication	Description of functions
[1-1]	PANEL INFORMATION	Data, such as the version of the microcomputer of the panel, product serial number, and statuses of EEPROM for adjustment values for the main unit and for backup, are displayed.
[1-2]	PANEL WORKS	Operation data, such as accumulated pulse-meter count, accumulated hour-meter count, accumulated power-on count, and the temperature detected by the sensor, are displayed.
[1-3]	POWER DOWN	The power-down history is displayed.
[1-4]	SHUT DOWN	The shutdown history of the panel section is displayed.
[1-5]	PANEL-1 ADJ (+)	Settings of the driving voltage and AM radio prevention can be performed.
[1-6]	PANEL-2 ADJ (+)	White balance and ABL (power consumption) for the panel can be set.
[1-7]	PANEL FUNCTION (+)	Setting of the panel-degradation correction-level and various functions are displayed.
[1-8]	ETC. (+)	Copying of backup data, clearing of various settings, and changing of settings for functions for which setting data are not stored upon last update are performed.
[1-9]	RASTER MASK SETUP (+)	The mask indication (RASTER) can be set and indicated.
[1-10]	PATTERN MASK SETUP (+)	The mask indication (PATTERN) can be set and indicated.
[1-11]	COMBI MASK SETUP (+)	The mask indication (COMBI) can be set and indicated.

C

D

E

F

## ■ Details of indications in each layer

### [1-1] PANEL INFORMATION

- Data, such as the version of the microcomputer of the panel, product serial number, and statuses of digital EEPROM for storing the adjustment values and for backup EEPROM, are displayed. No other layers are nested below this layer, and there are no adjustment items.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.			IN1-30602-RGB-JHB			
	AREA1	PANEL	INFORMATION						
2		MODULE		-01A			01A		
3		-PRG		-01A					
4		-DAT		-01A					
5		SEQ PRS		-01Y			02A		
6		-PRQ		-01Y					
7		-PIC		-01Y					
8		-SEQ		520Y					
9									
A		SERIAL							
B		DIG.EEP		ADJUSTED					
C		BACKUP		NO DATA!					
D									
E									

#### ■ Key operation

- <DOWN> : Shifting to PANEL WORKS  
 <UP> : Shifting to COMBI MASK SETUP  
 (+)  
 <L/R> : Updating displayed information

#### ■ Contents of the Display item

- MODULE : The version of data written in the Module microcomputer is indicated.  
 -PRG : The program version of the Module microcomputer is indicated.  
 -DAT : The data version of the Module microcomputer is indicated.  
 SEQ PRS : The version of data written in the Sequence LSI is indicated.  
 -PRG : The program version of the Sequence LSI is indicated.  
 -PIC : The Picture-data version of the Sequence LSI is indicated.  
 -SEQ : The sequence-data version of the Sequence LSI is indicated.  
 SERIAL : The serial number of the module is indicated.  
 DIG.EEP : The adjusted status of the EEPROM that is mounted on the DIGITAL Assy is indicated.  
 BACKUP : The adjusted status of the EEPROM for backup that is mounted on the SENSOR Assy is indicated.

### [1-2] PANEL WORKS

- Data on operations, such as the accumulated pulse-meter counts, hour-meter count, power-on count, and temperature detected by the sensor, are displayed. No other layers are nested below this layer, and there are no adjustment items.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.			IN1-30602-RGB-JHB			
	AREA1	PANEL	WORKS						
2									
3		PM-B1		00000715	M				
4		PM-B2		00000607	M				
5		PM-B3		00000852	M				
6		PM-B4		00000668	M				
7		PM-B5		00000733	M				
8									
9		HR-MTR		000025H	20M				
A		P-COUNT		00000095	TIMES				
B		TEMP1		+27.4	/ +70.8				
C		CLS-RGB		2000/0325	/ 1223-OK				
D									
E									

#### ■ Key operation

- <DOWN> : Shifting to POWER DOWN  
 <UP> : Shifting to PANEL INFORMATION  
 <L/R> : Updating displayed information

← Temperature unit is " °C (Centigrade) ".

#### ■ Contents of the Display item

- PM-B1 to B5: The accumulated pulse-meter counts for the 5 blocks on the screen are indicated. (the lowest-order digit represents millions of pulses.)
- HR-MTR: The hour-meter value (accumulated power-on hours) is indicated.
- P-COUNT: The accumulated power-on count is indicated.
- TEMP1: The current panel temperature and the historical maximum temperature recorded in memory are indicated. The temperature unit is " °C (Centigrade) ".
- CLS-RGB: Data obtained from the color sensor are displayed in the order R, G, and B, with the status indication at the end.

CLS Status	OSD Indication
Function OFF	-OFF
Color sensor module non connection	-NC
Data abnormality	-INV
Data normal	-OK

#### Note:

Neither the color sensor value nor the status indication will be displayed if the color sensor function is set to ON in the ETC (+) layer beforehand.

A

### [1-3] POWER DOWN

- The power-down history is displayed. No other layers are nested below this layer.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.			IN1-30602-RGB-JHB			
	AREA1	POWER	DOWN						
2		1ST		2ND		000124H	23M		
5	3								
	4	1	X-DCDC	-----		000124H	21M		
	5	2	Y-SUS	SCAN		000115H	05M		
	6	3	SCAN	-----		000107H	53M		
	7	4	POWER	SCAN		000098H	47M		
10	8	5	ADRS	-----		000051H	30M		
	9	6	SCN5V	X-DCDC		000022H	21M		
	A	7	Y-DCDC	-----		000000H	57M		
	B	8					H	M	
	C								
	D								
15									
16	E								

#### ■ Key operation

- <DOWN> : Shifting to SHUT DOWN
- <UP> : Shifting to PANEL WORKS
- <L/R> : Updating displayed information

B

#### ■ Contents of the Display item

- The last most 8 power-down histories are displayed with the hour-meter values that indicate the hours when power-downs occurred.
- When power-down is confirmed, the factor is displayed as "1st", "2nd", according to the accuracy order.
- The power-down history is not recorded when the power-down occurred at the same place and same time.

C

#### <Causes of power-down and corresponding OSD indications>

Cause of power-down	OSD Indication	Cause of power-down	OSD Indication
POWER SUPPLY Unit	P-PWR	ADDRESS Assy	ADRS
SCAN Assy	SCAN	DC/DC converter for X drive	X-DCDC
5 V power for SCAN	SCN5V	X-SUS	X-SUS
DC/DC converter for Y drive	Y-DCDC	DIG-DCDC	D-DCDC
Y-SUS	Y-SUS	Unknown	UNKNOW

D

E

F



## [1-4] SHUT DOWN

- The shutdown history of panel section is displayed. No other layers are nested below this layer, and there are no adjustment items.

		1	5	10	15	20	25	30	32
1		PANEL	FACT.			IN1-30602-RGB-JHB			
	AREA1	SHUT	DOWN						
2		MAIN	SUB			000124H	23M		
3									
4	1	TMP-NG	TMP-H			000124H	21M		
5	2	SQ-LSI	RTRY			000115H	05M		
6	3	MD-DEV	DAC			000107H	53M		
7	4	SQ-LSI	VER-HS			000098H	47M		
8	5	MD-DEV	BACKUP			000051H	30M		
9	6	SQ-LSI	BUSY			000012H	07M		
A	7						H	M	
B	8						H	M	
C									
D									
E									

### Key operation

- <DOWN> : Shifting to PANEL-1 ADJ (+)
- <UP> : Shifting to POWER DOWN
- <L/R> : Updating displayed information

### Contents of the Display item

- The shutdown history is displayed. The last most 8 shutdown histories are displayed with the hour-meter values that indicate the hours when shutdowns occurred.
- When there is detail information when shutdown occurred, the possible defective part is displayed as Sub information.
- The shutdown history is not recorded when the shutdown occurred at the same place and same time.

### <Cause of shutdown and corresponding OSD Indication >

Cause of shutdown (MAIN)		Cause of shutdown (SUB)	
Main cause	OSD Indication	Sub cause	OSD Indication
SQ_LSI	SQ_LSI	Communication Error	RTRY
		Drive Stop	SQNO
		Busy	BUSY
		Version mismatching (H/S)	VER-HS
		Version mismatching (H/M)	VER-HM
		Version mismatching (H/I)	VER-HI
MDU-DEVICE	MD-DEV	Digital EEPROM	EEPROM
		Backup EEPROM	BACKUP
		DAC IC	DAC
Abnormally in RST2 power supply	RST2	—	—
Abnormally in panel temperature	TMP-NG	High temperature of the panel	TMP-H
		Low temperature of the panel	TMP-L



A

## &lt;Next nested layer of PANEL-1 ADJ (+)&gt;

No.	Item	OSD Indication	Variable Range	Setting Value	RS-232C Command	Remarks
1	Vsus voltage	VOL SUS <=>	000 to 255	Factory adjustment value	VSU	
2	Vysnfs voltage	VOL OFFSET <=>			VOF	
3	Vyprst voltage	VOL RST P <=>			VRP	
4	Vxpofs1 voltage	VOL XPOFS1 <=>			VX1	
5	Vxpofs2 voltage	VOL XPOFS2 <=>			VX2	
6	Vyknofs1,2 voltage	VOL YKNOFS1 D <=>			V1F	
7	Vyknofs3 voltage	VOL YKNOFS3 D <=>			V3F	
8	Vyknofs4 voltage	VOL YKNOFS4 D<=>			V4F	
9	Δ Vyknofs1,2/3/4	VOL YKNOFSA D<=>			VYF	
10	First reset (wedge width)	RESET1ST_KSB <=>	112 to 144	128	R1K	Factory use item
11	Second reset (wedge width)	RESET2ND_KSB <=>			R2K	
12	1SF - Y sus tail (wedge width)	YSTL_1SF_KSB <=>			Y1K	
13	1SF - Y sus tail (resonance down width)	YSTL_1SF_HZ <=>			Y1Z	
14	3SF and later - first X sus (resonance up width)	XSUS_1ST_B <=>			X1B	
15	2SF - second Y sus (resonance up width)	YSUS_2ND_B <=>			Y2B	
16	2SF - third X sus (resonance up width)	XSUS_3RD_B <=>			X3B	
17	2SF - repeat Y sus (resonance up width)	YSUS_B <=>			YSB	
18	2SF - repeat X sus (resonance up width)	XSUS_B <=>			XSB	
19	3SF and later - Y sus tail (wedge width)	YSTL_KSB <=>			YTK	
20	3SF and later - Y sus tail (resonance down width)	YSTL_HZ <=>			Y TZ	
21	2SF - Y sus tail (wedge width)	YSTL_2SF_KSB <=>			Y2K	
22	2SF - Y sus tail (resonance down width)	YSTL_2SF_HZ <=>			Y2Z	
23	3SF and later (2 pulses of SSF) - Y sus tail (wedge width)	YSTL_FMR_KSB <=>			YNK	
24	Timing between Scan and Address	SCAN ADRS ADJ <=>			SAT	
25	SUS frequency (AM radio anti-jamming)	SUS FREQ <=>	MODE1 to 8	MODE1	SFR	Note

Note: It is necessary to turn OFF and ON the power for reflecting the setting change.

D

E

F



## A

- E



9



D

1

E

## F

KRP-600P

A

**[1-8] ETC. (+)**

- Clearance of various log data for the panel and changing of settings for which setting data were not stored upon last update can be performed.

Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

**■ Key operation**

- <DOWN> : Shifting to RASTER MASK SETUP (+)  
 <UP> : Shifting to PANEL FUNCTION (+)  
 <SET> : Shifting to the next nested layer

B

**■ Key operation**

- <DOWN> : Shifting to the next item  
 <UP> : Shifting to the previous item  
 <RIGHT> : Adding by one to the adjustment/setting value  
 <LEFT> : Subtracting by one from the adjustment/setting value  
 <SET> : Determining the adjustment/setting value and shifting to the upper layer

C


D

**<Next nested layer of ETC (+)>**

No.	Item	OSD Indication	Processing Contents	RS-232C COMMAND	Remarks
1	Backup EEPROM data	BACKUP DATA <=>	• NO OPRT (No operation) • TRANSFER (Backup data transmission)	BCP	
2	Digital EEPROM data	DIGITAL EEPROM <=>	• NO OPRT (No operation) • REPAIR (Adjustment is complete) • DELETE (Adjustment is not complete)	FAJ/UAJ	
3	PD history	PD INFO. <=>	• NO OPRT (No operation) • CLEAR (Data clear)	CPD	
4	SD history	SD INFO. <=>		CSD	
5	HOURLY METER	HR-MTR INFO. <=>		CHM	
6	Pulse meter	PM/B1-B5 <=>		CPM	
7	PON counter	P COUNT INFO. <=>		CPC	
8	Maximum temperature	MAX TEMP. <=>		CMT	
9	Mirror reversing display	MIRROR <=>	• Mirror reversing display OFF • MODE1 (Right and left reversing) • MODE2 (Top and bottom reversing) • MODE3 (Right and left, Top and bottom reversing)	MIR	The indication on the menu is also highlighted. The setting is canceled upon power-off.
10	Color sensor mode	CLS <=>	• Color sensor operation OFF • Color sensor operation ON	CSF	


## [1-9] RASTER MASK SETUP (+)

- This menu set the RASTER MASK and the drive sequence at RASTER MASK state. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.



### ■ Key operation

<DOWN> : Shifting to PATTERN MASK SETUP  
(+)  
<UP> : Shifting to ETC. (+)  
<SET> : Shifting to the next nested layer



### ■ Key operation

<DOWN> : Shifting to the next MASK  
<UP> : Shifting to the previous MASK  
<RIGHT> : Changing MASK sequence (+)  
<LEFT> : Changing MASK sequence (-)  
<SET> : Determining the adjustment/setting value and shifting to the upper layer

- The changed sequence and the ABL/WB table are retained until the mask is turned off.

**<Next nested layer of RASTER MASK SETUP (+)>**

No.	Item	OSD Indication	MASK Display Sequence	RS-232C COMMAND	Remarks
1	Mask off	MASK OFF		MKR/VFQ	
2	Display raster mask 01	RST MASK 01 <=>	<=>50V<=>60V<=>60P<=> 72V<=>75V1<=>75V2<=>		
...		...			
26	Display raster mask 25	RST MASK 25 <=>			





## [1-11] COMBI MASK SETUP (+)

- This menu set the COMBI MASK and the drive sequence at COMBI MASK state. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

		1	5	10	15	20	25	30	32
1				PANEL FACT.				IN1-30602-RGB-JHB	
	AREA1							[A1W1/60VS]	
	2								
5		3							
		4							
		5							
		6							
		7							
10		8							
		9							
		A							
		B							
		C							
15		D		COMBI MASK SETUP (+)					
16		E							

### Key operation

- <DOWN> : Shifting to PANEL INFORMATION
- <UP> : Shifting to PATTERN MASK SETUP (+)
- <SET> : Shifting to the next nested layer

		1	5	10	15	20	25	30	32
1				PANEL FACT.				IN1-30602-RGB-JHB	
	AREA1			COMBI MASK SETUP				[A1W1/60VS]	
	2								
5		3							
		4							
		5							
		6							
		7							
10		8							
		9							
		A							
		B							
		C							
15		D		CMB MASK 01				: 60V	
16		E							

### Key operation

- <DOWN> : Shifting to the next MASK
- <UP> : Shifting to the previous MASK
- <RIGHT> : Changing MASK sequence (+)
- <LEFT> : Changing MASK sequence (-)
- <SET> : Determining the adjustment/setting value and shifting to the upper layer

- The changed sequence and the ABL/WB table are retained until the mask is turned off.

### <Next nested layer of COMBI MASK SETUP (+)>

No.	Item	OSD Indication	MASK Display Sequence	RS-232C COMMAND	Remarks
1	Mask off	MASK OFF		MKC/VFQ	
2	Display raster mask 01	CMB MASK 01 <=>	<=>50V<=>60V<=>60P<=> 72V<=>75V1<=>75V2<=>		
...		...			
18	Display raster mask 17	CMB MASK 17 <=>			

## [2] PANEL MAIN FACT.

### ■ Operation Items in the PANEL MAIN FACT. Menu

On the PANEL MAIN FACT. menu screen, acquisition of information on and settings for the display main unit can be performed, as shown in the table below:

No.	Indication	Description of functions
[2-1]	VERSION (3)	To indicate the versions of the microcomputers for the display (incl. those for the display main unit)
[2-2]	PM NG INFO.	To indicate the shutdown history of the display main unit
[2-3]	PM STATE INFO.	To indicate temperatures of the display main unit, state of the fans, brightness, and model information
[2-4]	DP_RX INFO.	Data on the DP receiver
[2-5]	PM_SETUP (+)	To clear the history and perform function settings whose data are not retained after the unit is turned off
[2-6]	PM_BEZEL_SETUP	To perform the bezel setup
[2-7]	PM_NG_CLEAR	To clear the shutdown history

### ■ Description of Indications on Each Layer

#### [2-1] VERSION (3)

The versions of the microcomputers for the display (incl. those for the display main unit) are indicated on the VERSION (3) screen. No other layers are nested below this layer, and there are no adjustment items.

Although the description on the VERSION (3) screen is included in the PANEL MAIN FACT. section, this screen actually belongs to the INFORMATION layer.

	1	5	10	15	20	25	30	32
1	I N F O R M A T I O N			I N 1 - 3 0 1 0 1 - N T V - J H B				
	V E R S I O N ( 3 )							
5	P M A I N			- 0 2 A S			0 1 A	
	M O D U L E			- 0 2 A			0 2 A	
	S E Q P R S			- 0 1 U			0 1 U	
	D P R X			1 . 1 0				
10	D P R X H A R D			0 C 1 5				
	P A N E L I N F O			X X X X X X X X				
15								
16								

#### ■ Contents of the Display item

- P MAIN: Version of the writing data for the Panel Main microcomputer
- MODULE: Version of the writing data for the Module microcomputer
- SEQ PRS: Version of the writing data for the sequence LSI
- DP RX: Version of the writing data for the DP receiver firmware
- DP RX HARD: Version of the hardware for the DP receiver
- PANEL INFO: Information on the display panel



A

## [2-3] PANEL MAIN STATE INFORMATION

The display (unit) temperatures detected by the temperature sensors, FAN rotating status, the value acquired by the Room Light Sensor, and settings for the model are indicated.  
No other layers are nested below this layer.

	1	5	10	15	20	25	30	32
1	PM	FACTORY			IN1-30101-NTV-JHB			
	PM	STATE	INFO.					
5	TEMP1	:		+60	(C)			
	TEMP3	T1:		+31	(C)			
		T2:		+31	(C)			
		T3:		***	(C)			
	FAN A	:		LOW		123	(D/A)	
10	FAN B	:		LOW		102	(D/A)	
	B-SENSOR:			1023	(A/D)			
	MODEL INFO.:			R1				
15								
16								

### ■ Key operation

- <DOWN> : Shifting to DP\_RX INFO.
- <UP> : Shifting to PM NG INFO.
- <L/R> : Updating displayed information

B

■

### ■ Contents of the Display item

- TEMP1: The current display (panel) temperature is indicated. Temperature is in °C (Centigrade).
- TEMP3, T1-T2, T3 (reserved): The current display (unit) temperature is indicated. Temperature is in °C (Centigrade).
- FAN A, B: Controlled state of the fans (HIGH, LOW, STOP), D/A value
- B-SENSOR: A/D value of the Room Light Sensor
- MODEL INFO.: Model information, such as setup status of the bezel

C

■

D

## [2-4] DP-RX INFORMATION

This screen is for use by engineers.  
No other layers are nested below this layer.

	1	5	10	15	20	25	30	32
1	PM	FACTORY			IN1-30101-NTV-JHB			
	DP_RX	INFO.						
5	MR DEV-ID	:		00E036				
	PDP DEV-ID	:		00E036-070CA1				
15								
16								

### ■ Key operation

- <DOWN> : Shifting to PM\_SETUP (+).
- <UP> : Shifting to PM STATE INFO.
- <L/R> : Updating displayed information

E

■

F

## [2-5] PANEL MAIN SETUP (+)

The shutdown logs can be cleared, and temporary settings for functions that you do not wish to retain after the unit is turned off can be performed. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

1	PM	FACTORY	IN1-30101-NTV-JHB
5	PM	SETUP	
10			
15	PM	SETUP (+)	
16			

### ■ Key operation

<UP> : Shifting to DP\_RX INFO.

<ENTER/SET> : Shifting to the next nested layer

1	PM	FACTORY	IN1-30101-NTV-JHB
5	PM	SETUP	
10			
15	PM	BEZEL SETUP <=> R1	
16			

### ■ Key operation

<DOWN> : Shifting to the next item

<UP> : Shifting to the previous item

<RIGHT> : Changing the setting value upward (+)

<LEFT> : Changing the setting value upward (-)

<ENTER/SET> : Determining the changed value and return to the layer above

### <Next nested layer of PANEL MAIN SETUP (+)>

No.	Item	OSD Indication	Content	RS-232C COMMAND	Remarks
1	Bezel setting	PM_BEZEL_SETUP <=>	<ul style="list-style-type: none"> <li>• NO OPRT (No operation)</li> <li>• R1 (Bezel setting 1) Black</li> <li>• R2 (Bezel setting 2) White</li> <li>• R3 (Bezel setting 3) Beige</li> <li>• EP (For use by engineers)</li> </ul>	BZS	
2	SD history clear (panel main)	PM NG CLEAR <=>	<ul style="list-style-type: none"> <li>• NO OPRT (No operation)</li> <li>• CLEAR (Clearance of data)</li> </ul>	CAL	

## A [2-6] PANEL MAIN BEZEL SETUP

Setup of the bezel can be performed on the PANEL MAIN BEZEL SETUP screen.

	1	5	10	15	20	25	30	32
1	PM	FACTORY			IN1-30101-NTV-JHB			
	PM	SETUP						
5								
10								
15	PM	BEZEL	SETUP	<=>	R1			
16								

### ■ Key operation

- <DOWN> : Shifting to the next item
- <UP> : Shifting to the previous item
- <RIGHT> : Changing the setting value upward (+)
- <LEFT> : Changing the setting value upward (-)
- <ENTER/SET> : Determining the changed value and return to the layer above

Select the bezel setup setting, using the L or R key, then press the SET key to determine the setting. When NO OPT is selected, bezel setup is not performed.

Each time the L or R key is pressed, setup settings are changed, as shown below:

→ R1 ↔ R2 ↔ R3 ↔ EP ↔ NO OPT ←

“NO OPT” is selected immediately after the PANEL MAIN BEZEL SETUP screen is displayed.

R1: The bezel setup is performed according to ROM table 01. (Default)

R2: The bezel setup is performed according to ROM table 02.

R3: The bezel setup is performed according to ROM table 03.

EP: The bezel setup is performed according to the EEPROM table. (For use by engineers)

NO OPT: Bezel setup is not performed.

## D [2-7] PANEL MAIN NG CLEAR

The shutdown logs can be cleared on the PM NG CLEAR screen.

	1	5	10	15	20	25	30	32
1	PM	FACTORY			IN1-30101-NTV-JHB			
	PM	SETUP						
5								
10								
15	PM	NG	CLEAR	<=>	CLEAR			
16								

### ■ Key operation

- <DOWN> : Shifting to the next item
- <UP> : Shifting to the previous item
- <RIGHT> : Changing the setting value upward (+)
- <LEFT> : Changing the setting value upward (-)
- <ENTER/SET> : Determining the changed value and return to the layer above

“NG CLEAR” denotes clearing of the SD logs managed by the Panel Main microcomputer.

Select the setting, using the L or R key, then press the ENTER/SET key to clear the data. When NO OPT is selected, NG CLEAR is not performed.

Pressing the L or R key toggles between CLEAR and NO OPT, as shown below:

CLEAR ↔ NO OPT


# 7. DISASSEMBLY

## 7.1 FLOWCHART OF REMOVAL ORDER

**Note:** Even if the unit shown in the photos and illustrations in this manual may differ from your product, the procedures described here are common.

### Flowchart of removal order for the main parts and boards

It is efficient to proceed with removal of the main parts and boards in the order shown in the chart below:



A

B

C

D


E

F


Disassembly

1 Rear Case Assy (60M)

- Stand cover (L) and (R)
- ① Remove the four N grip screws. (ABA1381)
- ② Remove the stand covers (L) and (R).
- OP. button cover (S)
- ③ Remove the two screws. (ABA1379)
- ④ Remove the OP. button cover (S).
- Power button case
- ⑤ Remove the two screws. (ABA1379)
- ⑥ Remove the power button case.



- Under grip
- ⑦ Remove the four N grip screws. (ABA1381)
- ⑧ Remove the two under grips.





### ● Rear case Assy (60M)


- ⑨ Remove the four screws. (ABA1380)
- ⑩ Remove the 19 N grip screws. (ABA1381)
- ⑪ Remove the three screws. (ABA1379)
- ⑫ Remove the 15 N grip screws. (ABA1381)
- ⑬ Remove the rear case Assy (60M).

#### ● Reference

ABA1379

ABA1380

ABA1381



### ● Screw tightening order

The other screws are random order.




A

## Notes on Removing the POWER SUPPLY Unit

### 1. Construction of the POWER SUPPLY Unit

The POWER SUPPLY Unit comprises two boards, which must be replaced at the same time.  
(These boards are delivered as a set if ordered.)



POWER SUPPLY Unit

B

### 2. Discharge of residual electric charge

Immediately after the power cord is unplugged, residual electric charge remains for about 3-5 minutes in the capacitor inside the POWER SUPPLY Unit.

Before removing the POWER SUPPLY Unit, make sure that residual electric charge has fallen to a safe level.

C


#### How to discharge residual electric charge rapidly

Discharge residual electric charge by connecting two 220  $\Omega$  (10 W) forced discharging resistors (440  $\Omega$  in total,) one to each end, of C121.

### <How to remove the POWER SUPPLY Unit>

- ① Make sure that the power cord is unplugged. Check the voltage of both ends of C121 on the PKG2, using a tester.
- ② Wait until the voltage at both ends of C121 has fallen to 5 V or less.
- ③ When the voltage becomes less than 5 V, disconnect the connectors of the POWER SUPPLY Unit then remove it.

D



#### Points of checking residual electric charge:

After making sure that the voltage of both ends of C121 has fallen to 5 V or less, disconnect the PFC connector.

PFC connector

P14


E

F




## 2 Center Frame (60M)

**Note:** The wiring shown in the photo is different from the actual wiring, because the product in the photo is a prototype. Upon servicing, be sure to restore the original wiring of the unit after repair work.

- ① Remove the eight screws. (AMZ40P080FTB)
- ② Remove the two center frames (60M).



The J101 and J102 cables require correct orientation for connection. Connect the connectors with white tape to the POWER SUPPLY Unit.






### 3 MAIN and AUDIO Assys

**Note:** The wiring shown in the photo is different from the actual wiring, because the product in the photo is a prototype. Upon servicing, be sure to restore the original wiring of the unit after repair work.

#### ● Under cover

- ① Remove the three N grip screws. (ABA1381)
- ② Remove the under cover.




Under cover

#### ● Terminal panel SEP

- ① Remove the two screws. (BPZ30P080FTB)
- ② Remove the one screw. (AMZ30P060FTB)
- ③ Remove the one screw. (BMZ30P060FTB)
- ④ Remove the two hexagon headed screws. (ABA1382)
- ⑤ Remove the four N grip screws. (ABA1381)


#### **Note:**

Do not use an electric screwdriver.  
If the screw is over-tightened, the screw thread may be damaged.



Terminal panel SEP

- ⑥ Remove the three N grip screws. (ABA1381)
- ⑦ Remove the two screws. (AMZ30P060FTB)
- ⑧ Remove the terminal panel SEP.



Terminal panel SEP


#### ● Screw tightening order

The other screws are random order.




**● MAIN and AUDIO Assys**

- ① Remove the nine screws. (PMB30P060FNI)
- ② Release the two PCB spacers (reuse).
- ③ Disconnect the two flexible cables.
- ④ Disconnect cables, connectors, as required.



- ⑤ Lift the MAIN and AUDIO Assys to the direction of the arrow.



KRP-600P

A

#### 4 60F DIGITAL Assy


**Note:** The wiring shown in the photo is different from the actual wiring, because the product in the photo is a prototype. Upon servicing, be sure to restore the original wiring of the unit after repair work.

**Note:**

When you remove whole Multibase Section, it is not necessary to remove terminal panel SEP.


- ① Remove the two screws. (ABA1351)
- ② Remove the two screws. (AMZ30P060FTB)
- ③ Disconnect the two flexible cables.

B



C

- ④ Lift the multi base section to the direction of the arrow.




D

60F DIGITAL Assy

• Screw tightening order

E








F



## 5 Front Bezel (60MSEP)

- ① Remove the five rivets.
- ② Pull the lower part of the front bezel (60MSEP) toward you and out.
- ③ Remove the front bezel (60MSEP), by pulling it upward.






## 6 Access to 60F ADDRESS L and S Assys


### ● Top frame (60M)

- ① Remove the eight screws. (TBZ40P060FTC)
- ② Remove the two top frames (60M).




### ● Sub frame Assy (60M)

- ① Remove the 12 screws. (TBZ40P060FTC)
- ② Remove the two sub frame Assys (60M).



### ● Screw tightening order


The other screws are random order.








### ● F. chassis HT Assy (60M)

- ① Remove the three screws. (APZ30P080FTB)
- ② Remove the two screws. (ABZ30P080FTC)
- ③ Remove the F. chassis HT Assy (60M).





### ● F. chassis HB (60M)

- ① Release the jumper wire.
- ② Remove the one N grip screws. (ABA1381)
- ③ Remove the operation button holder.
- ④ Remove the two N grip screws. (ABA1381)
- ⑤ Remove the power button support.
- ⑥ Release the jumper wire.
- ⑦ Remove the three screws. (APZ30P080FTB)
- ⑧ Remove the two screws. (ABZ30P080FTC)
- ⑨ Remove the F. chassis HB (60M).



### ● Screw tightening order


The other screws are random order.




A

**● Address heatsink S and L**

- ① Remove the 22 screws. (ABA1351)
- ② Remove the two address heatsinks S and six address heatsinks L.




B




C



D



E





F

## 7 Access to 60F SCAN A, B, C and D Assys



### ● F. chassis V Assy (60M)


- ① Release the two jumper wires.
- ② Remove the one screw. (APZ30P080FTB)
- ③ Remove the two screws. (ABZ30P080FTC)
- ④ Remove the F. chassis V Assy (60M).



### ● Screw tightening order

The other screws are random order.



- 
- A
1. At shipment, the unit is adjusted to its best conditions. Normally, it is not necessary to readjust even if an assembly is replaced. If the adjustment is shifted or if it becomes necessary to readjust because of part replacement, etc., perform the adjustment as described below.

2. Any value changed in Service/Factory mode will be stored in memory as soon as it is changed. Before readjustment, take note of the original values for reference in case you need to restore the original settings.

3. Use a stable AC power supply.

8.1 ADJUSTMENT REQUIRED WHEN THE UNIT IS REPAIRED OR REPLACED

■ When any of the following assemblies is replaced

POWER SUPPLY Unit	➡	Refer to “8.3 HOW TO CLEAR HISTORY DATA” .
DIGITAL Assy	➡	Writing of backup data is required. Refer to the “8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)”.
X DRIVE Assy	➡	No adjustment required
Y DRIVE Assy	➡	No adjustment required
Service Panel Assy	➡	Refer to “8.3 HOW TO CLEAR HISTORY DATA” and “8.4 ADJUSTMENTS WHEN THE SERVICE PANEL ASSY IS REPLACED”.
MAIN Assy (Note)	➡	No adjustment required
AUDIO Assy	➡	No adjustment required
SENSOR Assy	➡	Writing of backup data is required. Refer to the “8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)”.
Other assemblies	➡	No adjustment required

**Note:** After replacing the MAIN Assy, be sure to perform the FINAL SETUP.

To perform the FINAL SETUP for the display main unit and module via the RS-232C connector on the display, set the unit to Standalone Operation mode, by issuing the SYSS00 command, then issue the FAY command then FSP command. (Common to models of any size and for any destination)

To perform the FINAL SETUP of the entire system, i.e., the display and the Media Receiver (MR), input commands via the RS-232C connector on the MR in System Operation mode.

For details, refer to the service manual of the Media Receiver.

## ■ When any of the following parts is replaced

### Notes on replacing parts

For the parts described in the list below, replacement is required for the whole Assy, not only the defective part.

If any part listed below is identified as defective and needs replacement, replace the whole Assy, and make necessary adjustments after replacement.

PCB Assy No.	Assy Name	Parts that Require Whole-Assy Replacement		
		Ref No.	Function Name	Part No.
AWV2538	DIGITAL Assy	IC3302	Flash ROM	AGC1069
		IC3601	Flash UCOM	AGC1068
AWV2597	X DRIVE Assy	• Parts of X D-D CON BLOCK		
AWV2598	Y DRIVE Assy	<ul style="list-style-type: none"> <li>• Parts of Y VF D-D CON BLOCK 1</li> <li>• Parts of Y MAIN D-D CON BLOCK 1</li> <li>• Parts of Y MAIN D-D CON BLOCK 2</li> </ul>		
AWW1393	MAIN Assy	IC5001	Display port Rx IC	GM68020H-CG-K
		IC5003	EEPROM	S25FL016A0LMF013
		IC5005	EEPROM	M2404HEPROM
		IC7001	Flash UCOM	MB91F356B-G-SPE1-K
		IC7003	EEPROM	BR24L02FJ-W

**Reason:** The whole Assy must be replaced, because adjustments and data rewriting for the Assy at the level of production line are required.

For the parts described in the table below, replacement of individual parts is difficult, because a heat pad is provided under the bottom of the ICs.

PCB Assy No.	Assy Name	Parts that Replacement is Possible		
		Ref No.	Function Name	Part No.
AWW1393	MAIN Assy	IC4501	Regulator IC	NJM2871BF05
		IC4503	Regulator IC	PQ025ENA1ZPH
		IC4504	Regulator IC	NJM2846DL3-18
		IC7004	Regulator IC	NJM2846DL3-33
AWW1398	AUDIO Assy	IC8331	Regulator IC	NJM2846DL3-33
		IC8401	Digital Amp	TAS5122DCA
AWW1394	FAN Assy	IC1201	Regulator IC	PQ200WNA1ZPH
		IC1202	Regulator IC	PQ200WNA1ZPH

A

POWER SUPPLY Unit



The assembly must be replaced as a unit, and no part replacement is allowed.

MAIN Assy



No adjustment required

AUDIO Assy



No adjustment required

B

DIGITAL Assy



No adjustment required

X DRIVE Assy



No adjustment is required after replacement of parts other than those shown in "8.5 ADJUSTMENT WHEN THE DRIVE ASSYS ARE REPLACED."

Y DRIVE Assy



No adjustment is required after replacement of parts other than those shown in "8.5 ADJUSTMENT WHEN THE DRIVE ASSYS ARE REPLACED."

C

ADDRESS Assy



No adjustment required

SENSOR Assy



No adjustment required

Other assemblies



No adjustment required

D

E

F

## 8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)

### Outline

Adjustment data are stored in the EEPROM on the DIGITAL Assy in the production process. Those adjustment data are also automatically stored in the EEPROM (for backup) on the SENSOR Assy.

If the DIGITAL Assy is replaced, those adjustment data for backup can be copied from the EEPROM on the SENSOR Assy to a new DIGITAL Assy.

### Backed up data

- Drive voltage adjustment value
- Panel white balance adjustment value
- Drive waveform adjustment value
- Hour-meter count
- Pulse-meter count
- P-ON counter value
- Serial No.
- PD/SD histories


### How to copy backup data

#### 1. When the DIGITAL Assy is replaced with one for service (usual service)

Immediately after the DIGITAL Assy is replaced, the EEPROM on the DIGITAL Assy is in the status "adjustment not completed," and the EEPROM for backup on the SENSOR Assy is in the status "adjustment completed." The LED on the main unit warns you that the adjustment data in the EEPROM for backup have not been copied to the EEPROM on the DIGITAL Assy, by lighting the red LED and flashing the blue LED. In such a case, the adjustment data for backup can be used by copying the data to the EEPROM on the DIGITAL Assy, with the following procedures:

##### (1) Copying, using the Factory menu

- ① Turn on the power.
- ② Enter the Panel Factory mode.
- ③ Display the PANEL INFORMATION page, then check if "NO DATA!" is set for "DIG. EEP" and "ADJUSTED" is set for "BACKUP".
- ④ Copy the backup data, as shown in the figure below.



- ⑤ Check if "ADJUSTED" is set for "DIG. EEP" on the PANEL INFORMATION page.
- ⑥ Turn off the power.

##### (2) Copying, using the RS-232C commands

- ① Turn on the power.
- ② Issue the FAY command.
- ③ With the QS2 command, confirm that the main unit adjustment flag is "adjustment not completed" and that the adjustment backup flag is "adjustment completed."
- ④ Issue the BCP command to transfer the data stored in the EEPROM for backup.
- ⑤ With the QS2 command, confirm that the main unit adjustment flag becomes "adjustment completed."
- ⑥ Turn off the power.


**Note:** If both the DIGITAL and SENSOR Assys are to be replaced, replace the SENSOR Assy first in order to store the backup data. Then turn the unit on then back off again, then replace the DIGITAL Assy.

## 2. When manual adjustment is required after the DIGITAL Assy is replaced with one for service

If backup data cannot be transferred to the DIGITAL Assy because of defective parts, etc., after the DIGITAL Assy is replaced and manual adjustment is performed, those manually adjusted data can be registered as adjusted data with the following procedures. Once the data on the DIGITAL Assy are registered as adjusted data, the adjustment data for backup will be automatically updated each time the unit is turned off. Therefore, if a DIGITAL Assy with adjusted data is mounted on the unit, the following procedures are not required, even after manual adjustment.

### (1) Copying, using the Factory menu

- ① Turn on the power.
- ② Enter the Panel Factory mode.
- ③ Display the PANEL INFORMATION page, then check if "NO DATA!" is set for "DIG. EEP".
- ④ Register the changed adjustment data as adjusted data, as described for the following procedures, then transfer them as backup data.



- ⑤ Check if "ADJUSTED" is set for "DIG. EEP" on the PANEL INFORMATION page.
- ⑥ Turn off the power.

### (2) Copying, using the RS-232C commands

- ① Turn on the power.
- ② Issue the FAY command.
- ③ With the QS2 command, confirm that the main unit adjustment flag is "adjustment not completed."
- ④ Issue the FAJ command to register the changed adjustment data as adjusted data then transfer them as backup data.
- ⑤ With the QS2 command, confirm that the main unit adjustment flag becomes "adjustment completed."
- ⑥ Turn off the power.




### 3. When a secondhand DIGITAL Assy is to be reused

A DIGITAL Assy in good condition that had been mounted in another product can be reused. Before reuse, by following the procedures described below, make the data in the EEPROM on the DIGITAL Assy "adjustment not completed" data in order to prevent accidental updating of backup data when the secondhand DIGITAL Assy is mounted in another product

#### (1) Copying, using the Factory menu

- ① Turn on the power.
- ② Enter the Panel Factory mode.
- ③ Display the PANEL INFORMATION page, then check if "ADJUSTED" is set for "DIG. EEP".
- ④ Make the data in the EEPROM on the DIGITAL Assy "adjustment not completed" data, by following the procedures below:



- ⑤ Check if "NO DATA!" is set for "DIG. EEP" on the PANEL INFORMATION page.
- ⑥ Turn off the power.

#### (2) Copying, using the RS-232C commands

- ① Turn on the power.
- ② Issue the FAY command.
- ③ With the QS2 command, confirm that the main unit adjustment flag is "adjustment completed."
- ④ Issue the UAJ command to make the data in the EEPROM on the DIGITAL Assy "adjustment not completed" data.
- ⑤ With the QS2 command, confirm that the main unit adjustment flag becomes "adjustment not completed."
- ⑥ Turn off the power.

**Note:** If you mount a secondhand Assy to the product without performing the above procedures, the adjustment data and logs for the main unit specific to the product will be erased, and those of the secondhand Assy will be copied when the unit is turned off.

A

### ■ Clearance of various logs after the Assys are replaced

Besides adjustment data, data on accumulated power-on time and logs on defective parts of the product are backed up. Some of those data must be cleared after the Assys are replaced for service. Clearance of those data can be performed in the ETC layer of the Factory menu or with RS232C commands.

Item	Content	Clearing at the Replacement			Clearing method	
		Panel	POWER SUPPLY Unit	Other parts	Factory Menu (ETC layer)	RS-232C Commands
Hour-meter	Accumulated power-on time	Must be cleared	No need to be cleared	No need to be cleared	HR-MTR INFO.	CHM
Pulse-meter	Accumulated number of pulses emitted	Must be cleared (mandatory)	No need to be cleared	No need to be cleared	PM/B1-B5	CPM
Shutdown history of the panel	Causes and hour-meter values for the last eight shutdowns (SD) of the Panel	Must be cleared	No need to be cleared	No need to be cleared	SD INFO.	CSD
Power-down history	Causes and hour-meter values for the last eight power-downs (PDs) of the Panel	Must be cleared	No need to be cleared	No need to be cleared	PD INFO.	CPD
Power-on counter	Relay-on count	No need to be cleared	Must be cleared (mandatory)	No need to be cleared	P COUNT INFO.	CPC
MAX TEMP	Historical max. temperature of the panel	Must be cleared	Must be cleared	Must be cleared	MAX TEMP.	CMT


- Notes:
- As the pulse-meter count is used for each correction function, the log must be cleared when the panel is replaced.
  - After you clear the log, the unit must be turned off then back on again to reflect the cleared data for each correction function. If any adjustment is required after clearing the log, be sure to turn the unit off then back on again before adjustment.

C

#### (1) Clearance of logs, using the Factory menu

- Turn on the power.
- Enter the Panel Factory mode.
- Clear the various logs, as shown in the figure below.

Note: The following example shows how to clear the PD log (PD INFO.). To clear other items, select each item you wish to clear then perform the same procedures.



- ④ Turn off the power.

F

#### (2) Using the RS-232C commands

- Turn on the power.
- Issue the FAY command.
- Issue the Delete command for a log you wish to clear.
- Turn off the power.



A

## Overview

### Preparation

Clearing of the hour meter and pulse meter  
Aging with CMB MASK 01 (moving ramp)  
displayed

### Main flowchart (1)

Checking VOL OFFSET (min)  
(RST MASK 12: Light blue)

NG

OK

Checking VOL OFFSET (min)  
(RST MASK 10: Pink)

NG

OK

Checking VOL OFFSET (max)  
(RST MASK 02: Red)

NG

OK

Checking VOL OFFSET (max)  
(RST MASK 03: Green)

NG

OK

B

C

### Main flowchart (2)

Checking VOL YNOFSA D (min)  
(RST MASK 19: Green 718+)

NG

OK

Checking VOL YNOFSA D (min)  
(RST MASK 18: Red 626+)

NG

OK

Checking VOL YNOFSA D (max)  
(RST MASK 23: Magenta 169)

NG

OK

D

E

### Adjustment completed

### Replacement with the parts for service

- Re-replacement of the panel
- Replacement of the DRIVE Assy

F

### Recovery flowchart (1-1)

Checking VOL OFFSET (min)  
(RST MASK 12: Light blue)

NG

OK

### Recovery flowchart (1-2)

Checking VOL OFFSET (min)  
(RST MASK 10: Pink)

NG

OK

Checking VOL OFFSET (max)  
(RST MASK 02: Red)

NG

OK

Checking VOL OFFSET (max)  
(RST MASK 03: Green)

NG

OK

### Recovery flowchart (1-3)

Checking VOL OFFSET (max)  
(RST MASK 02: Red)

NG

OK

### Recovery flowchart (1-4)

Checking VOL OFFSET (max)  
(RST MASK 03: Green)

NG

OK

Checking VOL OFFSET (min)  
(RST MASK 12: Light blue)

NG

OK

Checking VOL OFFSET (min)  
(RST MASK 10: Pink)

NG

OK

### Recovery flowchart (2-1)

Checking VOL YNOFSA D (min)  
(RST MASK 19: Green 718+)

NG

OK

### Recovery flowchart (2-2)

Checking VOL YNOFSA D (min)  
(RST MASK 18: Red 626+)

NG

OK

Checking VOL YNOFSA D (max)  
(RST MASK 23: Magenta 169)

NG

OK

### Recovery flowchart (2-3)

Checking VOL YNOFSA D (max)  
(RST MASK 23: Magenta 169)

NG

OK

Checking VOL YNOFSA D (min)  
(RST MASK 19: Green 718+)

NG

OK


Checking VOL YNOFSA D (min)  
(RST MASK 18: Red 626+)

NG

OK

## Range of margin measuring

Read the voltage within the hysteresis (stricter value).



## Definition of limits for the voltage margins (abnormal lit/dead cells)

### Abnormal lit cells:

- Five or fewer abnormal cells on the whole screen
- Two or fewer abnormal cells within a radius of 1 cm

### Abnormal dead cells

- Fifteen or fewer abnormal cells on the whole screen
- Two or fewer abnormal cells within a radius of 1 cm

\*: Abnormal cells visually recognizable at a distance of 1 meter from the panel must be counted.

\*: Cells displayed abnormally for less than one second are not counted as abnormal cells.

## Definition of tones for the measuring signals

FHD signal (1920\*1080)/Video 60-Hz sequence  
/Dither: ON, L dither: ON, noise: OFF

Red	RST MASK 02 (R 1023 /G 0 /B 0)
Green	RST MASK 03 (R 0 /G 1023 /B 0)
Pink	RST MASK 10 (R 908 /G 718 /B 908)
Light blue	RST MASK 12 (R 447 /G 812 /B 812)
Red 626+	RST MASK 18 (R 626 /G 120 /B 120)
Green 718+	RST MASK 19 (R 120 /G 718 /B 120)
Magenta 169	RST MASK 23 (R 169 /G 0 /B 169)

## Interlocked settings for Voltages Vyknofs1/3/4

For the 9th-generation PDPs, interlocked setting for Voltages Vyknofs1/3/4 is available on the Factory menu or with RS232C commands, for easier adjustment. Therefore, in the adjustment flowchart, the interlocked setting function is used. (Individual setting for each adjustment value is also possible, as in the conventional setting methods.

Set Voltage	Factory Menu	Command
Vyknofs1 individual	VOL YNOFS1 D	[V1F]
Vyknofs3 individual	VOL YNOFS3 D	[V3F]
Vyknofs4 individual	VOL YNOFS4 D	[V4F]
Vyknofs1,3,4 interlocked	VOL YNOFSA D	[VYF]


### Note:

- The initial value for the interlocked setting value is 128, including for factory preset values.
- See "[3] DRIVE ASSY" of "5.2 DIAGNOSIS FLOWCHART OF FAILURE ANALYSIS" for calculation of actually used voltage values.


## Preparation before adjustment

[Replacement with the panel for service is completed.]

### Procedures for resetting corrections for change over time



### Procedures for stabilizing the panel before adjustment



\* To reflect the results of log clearing for each correction function, the unit must be turned off then back on again. Before adjustment, be sure to turn the unit off then back on again.

### Indication example of the adjustment label of service panel

**AWU1287 Data VOF=068**  
**VRP=018 V1F=086 V3F=096+ $\alpha$**   
**V4F=143 Hour Meter \_\_\_\_\_ H**  
 Data 08/02/28 Chassis CXX99999  
 Time 18:27 Pnl FTEST123456

**Note:** The symbol " $\alpha$ " denotes the adjustment value plus 0.

\* Each setting value described on the adjustment label denotes an indicated data value but not a real voltage value. Therefore, just enter the data value as a setting value.

\* To store the VFQ S03 command in memory, transmit it after displaying the mask.

[To the Main flowchart (1)]

### Note:

\* When you perform the adjustment with RS232C commands, issue the following commands in addition.


\* If the unit is shut down in the middle of performing the adjustment flowchart, reissuing of the command is required.

- [PAV S00] : To set panel drive mode to Factory
- [VFQ S03] : To set Drive Sequence to Video 60-Hz
- [SQM S01] : To set Drive Sequence to Video
- [WBI S01] : To temporarily reset the Panel WB adjustment value to default (WBI S00 cancels this setting.)
- [PGR S00] : To set the gamma R value to that for Factory mode
- [PGG S00] : To set the gamma G value to that for Factory mode
- [PGB S00] : To set the gamma B value to that for Factory mode
- [DIZ S03] : Dither ON, L dither ON, noise OFF.
- [\$1800000001] : LUT mode ON

A


## ■ Main flowchart (1)...Checking VOL OFFSET

[From Preparation]



F

## Main flowchart (2)...Checking VOL YNOFSA D



### Note:

Make sure that the following values become the final setting values.

VOL SUS *1	VOL XPOSF2 *1
VOL OFFSET	VOL YNOFS1 D *1
VOL RST P *1	VOL YNOFS3 D *1
VOL XPOFS1 *1	VOL YNOFS4 D *1
	VOL YNOFS4 A

\*1: The tentative setting value becomes the final value.

A

## Recovery flowchart (1-1)...Changing the VOL OFFSET setting

[From the Main flowchart (1)]

RST MASK 12 (Light blue)

Gradually increase the VOL OFFSET value until disappear the discharge (lit cell).  
The VOL OFFSET value must be 057 or less.

Current VOL OFFSET > 051?

Yes

Replacement of abnormal circuits or  
re-replacement of the panel required

No

Display RST MASK 10 (Pink). / [MKR S10]

[To the Recovery flowchart (1-2)]

C

## Recovery flowchart (1-2)...Changing the VOL OFFSET setting

[From the Main flowchart (1) / Recovery flowchart (1-1)]

RST MASK 10 (Pink)

Gradually increase the VOL OFFSET value until disappear the discharge (lit cell).  
The VOL OFFSET value must be 057 or less.

Current VOL OFFSET > 051?

Yes

Replacement of abnormal circuits or  
re-replacement of the panel required

No

Display RST MASK 02 (Red). / [MKR S02]

Set VOL OFFSET to the current setting value plus 100. / [VOF \*\*\*]

Is there erroneous discharge (abnormal dead cell)?  
(Check on the PANEL 1-ADJ menu.)


Yes

Replacement of abnormal circuits or  
re-replacement of the panel required


No

(A)





### Recovery flowchart (1-3)...Changing the VOL OFFSET setting



## Recovery flowchart (1-4)...Changing the VOL OFFSET setting

[From the Main flowchart (1) / Recovery flowchart (1-3)]

RST MASK 03 (Green)

Gradually decrease the VOL OFFSET value until disappear the discharge (dead cell).  
The VOL OFFSET value must be 101 or greater.

Current VOL OFFSET < 107?

Yes

Replacement of abnormal circuits or  
re-replacement of the panel required

No

Display RST MASK 12 (Light blue). / [MKR S12]

Set VOL OFFSET to the current setting value minus 101. / [VOF \*\*\*]

Is there erroneous discharge (abnormal lit cell)?  
(Check on the PANEL 1-ADJ menu.)

Yes

Replacement of abnormal circuits or  
re-replacement of the panel required

No

Display RST MASK 10 (Pink). / [MKR S10]

Is there erroneous discharge (abnormal lit cell)?  
(Check on the PANEL 1-ADJ menu.)

Yes

Replacement of abnormal circuits or  
re-replacement of the panel required


No

Set VOL OFFSET to the current setting value plus 33. / [VOF \*\*\*]

Determine the current VOL OFFSET setting value as the final value.


[To the Main flowchart (1)]

## Recovery flowchart (2-1)...Changing the VOL YNOFSA D setting



## Recovery flowchart (2-2)...Changing the VOL YNOFSA D setting

[From the Main flowchart (2) / Recovery flowchart (2-1)]



## Recovery flowchart (2-3)...Changing the VOL YNOFSA D setting

[From the Main flowchart (2)]

RST MASK 23 (Magenta 169)

Gradually decrease the VOL YNOFSA D value until disappear the discharge (lit cell).  
The tentative setting value of VOL YNOFS1 D + current setting value of VOL YNOFSA D must be 192 or greater.

Tentative setting value of VOL YNOFS1 D  
+ current setting value of VOL YNOFSA D  
< 194?

Yes

**Replacement of abnormal circuits or  
re-replacement of the panel required**

No

Display RST MASK 19 (Green 718+). / [MKR S19]

Set VOL YNOFSA D to the current setting value minus 44. / [VYF \*\*\*]

Is there erroneous discharge (abnormal dead cell)?  
(Check on the PANEL 1-ADJ menu.)

Yes

**Replacement of abnormal circuits or  
re-replacement of the panel required**

No

Display RST MASK 18 (Red 626+). / [MKR S18]

Is there erroneous discharge (abnormal dead cell)?  
(Check on the PANEL 1-ADJ menu.)

Yes

**Replacement of abnormal circuits or  
re-replacement of the panel required**

No

Set VOL YNOFSA D to the current setting value plus 32. / [VYF \*\*\*]

Determine the current VOL YNOFSA D setting value as the final value.

[To the Main flowchart (2)]

## 8.5 ADJUSTMENT WHEN THE DRIVE ASSYS ARE REPLACED

Waveform adjustments required when replacing the following parts of the X DRIVE and Y DRIVE Assys.


Assy Name	Ref No.	Part Name	Part Category	Remarks
X DRIVE Assy	IC1101	PS9818-1(P)	Photo Coupler	
	IC1104	TND307TD	FET Driver	
	IC1204	PS9818-2(P)	Photo Coupler	
	IC1209	TND307TD	FET Driver	
Y DRIVE Assy	IC2101	PS9818-1(P)	Photo Coupler	
	IC2103	TND307TD	FET Driver	
	IC2201	PS9818-1(P)	Photo Coupler	
	IC2203	TND307TD	FET Driver	

### TIME LAG ADJUSTMENT OF THE CONTROL SIGNAL (SUS-B)

- Measure the time lag for the SUS-U signal to the SUS-B signal.
  - Check the time lag for the SUS-B Gate signal to the SUS-U Gate signal.
- Adjust the variable control so that the time lag of Gate becomes "time lag of input signal +  $\alpha \pm 5$  nsec."

**Note:**

- Be sure to set the Drive to OFF for adjustment.
- For details on measuring points of waveform, see the figure below.



#### Time lag of SUS-U Gate and SUS-B Gate : $\Delta Tsus-gub$

Adjust so that " $\Delta Tsus-gub = \Delta Tsus-iub + \alpha \pm 5$  nsec," using the variable controls shown in the table below:

Assy	VR	Value of $\alpha$
X DRIVE Assy	VR1002	60 nsec
Y DRIVE Assy	VR2002	60 nsec

A


■ **DELAY ADJUSTMENT OF THE CONTROL SIGNAL (SUS-D)**

- ① Measure the pulse width of the SUS-D signal.
- ② Check the pulse width of the SUS-D input signal (gate terminal of Q2111).  
Adjust the variable control so that the pulse width of the SUS-D input signal (gate terminal of Q2111) becomes the same pulse width  $\pm 5$  nsec as the SUS-D signal.


■

**Note:** • For details on measuring points of waveform, see the figure below.

B



C



■

D

**SUS-D pulse width:  $T_{sus - Dg}$**   
Adjust so that " $T_{sus - Dg} = T_{sus - D} \pm 5$  nsec," using the variable control shown in the table below:

Assy	VR
Y DRIVE Assy	VR2001

■


E

■


F

## SUS-B ADJUSTMENT

### X DRIVE Assy




### Y DRIVE Assy



## SUS-D ADJUSTMENT

### Y DRIVE Assy



△

A

- B





# PACKING SECTION PARTS LIST (KRP-600P/WYSIXK5)

<u>Mark</u>	<u>No.</u>	<u>Description</u>	<u>Part No.</u>	
⚠	1	System Cable (2.9 m)	ADF1041	
⚠	2	Power Cable	ADG1214	A
⚠	3	Power Cable	ADG1223	
	4	Remote Control Unit	AXD1562	
	5	Battery Cover (Black)	AZN2784	
NSP	6	Alkaline Dry Cell Battery (LR6, AA)	VEM1045	
	7	Binder Assy	AEC2158	
	8	Cleaning Cloth	AED1285	
⚠	9	Ferrite Core (L5321)	ATX1039	
	10	Color Sensor Module	AXF1196	B
	11	Ferrite Core (L5320)	CTX1089	
	12	Operating Instructions (Italian / Dutch / Spanish / Russian)	ARC1609	
	13	Operating Instructions (English / French / German)	ARE1494	
	14	Caution Card	ARM1310	
	15	Cleaning Caution PTK	ARM1311	
	16	Ferrite Core Info.	ARM1396	
	17	Block Diagram (600M)	ARY1211	
NSP	18	Warranty Card EU	ARY7129	C
NSP	19	Vinyl Pouch	AHG-195	
	20	Vinyl Bag	AHG1337	
NSP	21	Vinyl Bag	AHG1340	
	22	Accessory Box	AHC1122	
	23	Pad (6095E T-L)	AHA2747	
	24	Pad (6095E T-R)	AHA2748	
	25	Pad (6095E B-L)	AHA2749	
	26	Pad (6095E B-R)	AHA2750	D
	27	Pad (6095E C)	AHA2751	
	28	Reinforce Carton (6095E)	AHC1121	
	29	Under Carton (6095E)	AHD3691	
	30	Upper Carton (60P EU)	AHD3728	
	31	Mirror Mat	AHG1385	

## 9.2 PACKING SECTION (KRP-600P/WYS5)

A


B

C

D

E

F



PACKING SECTION PARTS LIST (KRP-600P/WYS5)

Mark	No.	Description	Part No.	
⚠	1	System Cable (2.9 m)	ADF1041	
⚠	2	Power Cable	ADG1214	A
⚠	3	Power Cable	ADG1223	
	4	Remote Control Unit	AXD1562	
	5	Battery Cover (Black)	AZN2784	
NSP	6	Alkaline Dry Cell Battery (LR6, AA)	VEM1045	■
	7	Binder Assy	AEC2158	
	8	Cleaning Cloth	AED1285	
⚠	9	Ferrite Core (L5321)	ATX1039	
	10	Color Sensor Module	AXF1196	B
	11	Ferrite Core (L5320)	CTX1089	
	12	Operating Instructions (Russian)	ARC1619	
	13	•••••		
	14	Caution Card	ARM1232	■
	15	Cleaning Caution (11L)	ARM1283	
	16	Ferrite Core Info.	ARM1395	
	17	•••••		
NSP	18	Warranty Card EU	ARY7127	C
NSP	19	Vinyl Pouch	AHG-195	
	20	Vinyl Bag	AHG1337	
NSP	21	Vinyl Bag	AHG1340	
	22	Accessory Box	AHC1083	
	23	Pad (6095 T-L)	AHA2752	■
	24	Pad (6095 T-R)	AHA2753	
	25	Pad (6095 B-L)	AHA2754	
	26	Pad (6095 B-R)	AHA2755	
	27	Center Pad	AHA2687	
	28	Reinforce Carton (6095)	AHC1123	D
	29	Under Carton (6095)	AHD3693	
	30	Upper Carton (60P EUJ)	AHD3729	
	31	Mirror Mat	AHG1385	■

E

F

1 2 3 4

# 9.3 PACKING SECTION (KRP-600P/WA5)

A


B

C

D

E

F



PACKING SECTION PARTS LIST (KRP-600P/WA5)

Mark	No.	Description	Part No.	
⚠	1	System Cable (2.9 m)	ADF1041	
⚠	2	AC Power Cord	ADG1209	A
	3	•••••		
	4	Remote Control Unit	AXD1569	
	5	Battery Cover (Black)	AZN2784	
NSP	6	Dry Cell Battery (R6, AA)	VEM1031	
	7	Binder Assy	AEC2158	
	8	Cleaning Cloth	AED1285	
⚠	9	Ferrite Core (L5321)	ATX1039	
	10	•••••		
	11	•••••		B
	12	Operating Instructions (Simp-Chinese)	ARC1610	
	13	•••••		
	14	Caution Card (PC)	ARM1302	
	15	Cleaning Caution (11L)	ARM1283	
	16	•••••		
	17	•••••		
NSP	18	Warranty Card	ARY1161	
	19	•••••		C
	20	Vinyl Bag	AHG1336	
NSP	21	Vinyl Bag	AHG1340	
	22	Accessory Box	AHC1083	
	23	Pad (6095 T-L)	AHA2752	
	24	Pad (6095 T-R)	AHA2753	
	25	Pad (6095 B-L)	AHA2754	
	26	Pad (6095 B-R)	AHA2755	
	27	Center Pad	AHA2687	
	28	Reinforce Carton (6095)	AHC1123	D
	29	Under Carton (6095)	AHD3693	
	30	Upper Carton (60P C)	AHD3731	
	31	Mirror Mat	AHG1385	
	32	Nylon Binder	AEC-093	

A


B

C

D

E

F



## (1) REAR SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	POW SW Assy	AWW1395
	2	•••••	
	3	3P Housing Wire (J103)	ADX3655
	4	Under Grip Shield	ANG3169
	5	Coil Spring	ABH1125
	6	Under Grip	AMR3811
	7	Operation Button Holder	AMR3815
	8	Power Button Support	AMR3878
	9	•••••	
	10	Power Button Case	AAK2938
	11	Stand Cover (L)	AMR3876
	12	Stand Cover (R)	AMR3804
	13	OP. Button Cover (S)	AMR3882
	14	•••••	
	15	Power Button (508F)	AAD4152
⚠	16	Rear Case Assy (60M)	ANE1689
NSP	17	Name Label	See Contrast table (2)
	18	Serial Sheet	AAX3143
	19	Caution Label	See Contrast table (2)
	20	Terminal Label	See Contrast table (2)
	21	•••••	
	22	•••••	
	23	Screw (3 x 8 P)	ABA1379
	24	Screw (3 x 25 P)	ABA1380
	25	N Grip Screw (M3 x 6)	ABA1381
	26	Screw	APZ30P080FTB

## (2) CONTRAST TABLE

KRP-600P/WYSIXK5, WYS5 and WA5 are constructed the same except for the following:

Mark	No.	Symbol and Description	KRP-600P /WYSIXK5	KRP-600P /WYS5	KRP-600P /WA5
NSP	17	Name Label (60P-EU)	AAL3066	Not used	Not used
NSP	17	Name Label (60P-EUJ)	Not used	AAL3067	Not used
NSP	17	Name Label (60P-C)	Not used	Not used	AAL3069
	19	Caution Label (60M-EU)	AAX3592	AAX3592	Not used
	19	Caution Label (60P-C)	Not used	Not used	AAX3613
	20	Terminal Label (60S-EU)	AAX3597	AAX3597	Not used
	20	Terminal Label (60S-CH)	Not used	Not used	AAX3605

1 2 3 4

# 9.5 FRONT SECTION

A


B

C

D

E

F





FRONT SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	LED Assy	AWW1399
2	RLS Assy	AWW1401
3	IR Assy	AWW1400
4	6/3/3P Housing Wire (J117)	ADX3705
5	Front Bezel (60MSEP)	AMB3109
6	Blind Cushion (508F)	AEB1479
7	Nylon Rivet	AEC1671
8	Rivet (Plastic)	AEC1877

A

B

C

D

E

F

# 9.6 CHASSIS SECTION (1/2)



Cleaning paper :  
GED-008


Refer to  
"9.9 MULTIBASE SECTION".

Refer to  
"9.7 CHASSIS SECTION (2/2)".

## CHASSIS SECTION (1/2) PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
⚠ 1	DC FAN Motor 80 x 15L	AXM1065
⚠ 2	DC FAN Motor 75 x 12T	AXM1066
3	Top Frame (60M)	ANG3166
4	Center Frame (60M)	ANG3165
5	Sub Frame Assy (60M)	ANA2162
⚠ 6	F. Chassis V Assy (60M)	ANA2163
⚠ 7	F. Chassis HT Assy (60M)	ANA2167
⚠ 8	F. Chassis HB (60M)	ANA2166
9	Wire Clip	AEC1948
10	Reuse Wire Saddle	AEC2134
11	F. Chassis H Guide	AMR3756
12	FAN Bracket	AMR3805
13	Front Bezel Support	AMR3806
14	Support Bracket V	AMR3807
15	Rear Case Support	AMR3808
16	Coner Spacer	AMR3818
17	FAN Bracket Y	AMR3885
⚠ 18	Address Gasket	ANK1947
⚠ 19	Front Gasket H	ANK1960
⚠ 20	Front Gasket V	ANK1961
21	Under Cover	ANG3168
22	Under Cover Bracket	ANG3195
23	Drive Wire Saddle	AMR3850
24	Cushion	AEB1503
25	•••••	
26	Screw	ABA1351
27	N Grip Screw (M3 x 6)	ABA1381
28	Screw	ABZ30P060FTB
29	Screw	ABZ30P080FTC
30	Screw	AMZ30P060FTB
31	Screw	AMZ40P080FTB
32	Screw	APZ30P080FTB
33	Screw	BMZ30P080FTB
34	Screw	BPZ30P080FTB
35	Screw	PPZ50P100FTB
36	Screw	TBZ40P060FTC

## 9.7 CHASSIS SECTION (2/2)



CHASSIS SECTION (2/2) PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.	
	1 60F DIGITAL Assy	AWW1339		46 Drive Sheet	AEH1155	
	2 SENSOR Assy	AWW1340	⚠	47 Power Assy Silicon	AEH1181	A
	3 60F X DRIVE Assy	AWV2597		48 Y Drive Silicon	AEH1184	
	4 60F Y DRIVE Assy	AWV2598		49 X Drive Silicon	AEH1185	
	5 •••••			50 FAN Sheet A	AMR3764	
	6 SENS Assy	AWW1396	⚠	51 Power Sheet B	AMR3767	
	7 FAN CH Assy	AWW1397		52 Y Drive Sheet B	AMR3769	
⚠	8 POWER SUPPLY Unit	AXY1201	⚠	53 Power Sheet 95A	AMR3809	
⚠	9 Ferrite Core (F1 - F8)	ATX1072		54 Y Drive Sheet C	AMR3819	
	10 Flexible Cable (J201)	ADD1550		55 FFC Sheet	AMR3821	
	11 Flexible Cable (J202)	ADD1551		56 FAN Sheet B	AMR3831	B
	12 Flexible Cable (J203)	ADD1552	⚠	57 Y Drive Sheet A (M)	AMR3881	
	13 Flexible Cable (J204)	ADD1553		58 DIGITAL Sheet (M)	AMR3884	
	14 Flexible Cable (J205)	ADD1554		59 Gasket (10 x 10 x 80)	ANK1974	
	15 Flexible Cable (J206)	ADD1555		60 •••••		
	16 Flexible Cable (J207)	ADD1556		61 Screw	ABA1351	
	17 Flexible Cable (J208)	ADD1557		62 Screw	ABA1364	
	18 Flexible Cable (J209)	ADD1558				
	19 Flexible Cable (J210)	ADD1559				
	20 12P/11P Housing Wire (J101)	ADX3649				C
	21 11P Housing Wire (J102)	ADX3650				
	22 10P Housing Wire (J106)	ADX3652				
	23 6P Housing Wire (J107)	ADX3656				
	24 5/3/3P Housing Wire (J112)	ADX3658				
	25 5/3/3P Housing Wire (J113)	ADX3659				
	26 5/3/3P Housing Wire (J114)	ADX3660				
	27 5/3/3P Housing Wire (J115)	ADX3661				
	28 5P Housing Wire (J108)	ADX3662				
	29 9/3/3P Housing Wire (J130)	ADX3666				D
	30 7/3/3P Housing Wire (J131)	ADX3667				
	31 Plate Y	ANG3133				
	32 Nylon Rivet	AEC1671				
	33 Flat Clamp	AEC1879				
	34 Nylon Rivet	AEC2089				
	35 Reuse Card Spacer	AEC2117				
	36 PCB Spacer (Reuse)	AEC2122				
	37 Flat Clamp	AEC2132				
	38 Reuse Wire Saddle	AEC2134				E
	39 Reuse PCB Spacer 6.0	AEC2135				
	40 Cap Spacer	AEC2145				
	41 Mini PCB Spacer 5.0	AEC2149				
	42 Reuse Card Spacer S	AEC2153				
	43 Reuse Clamp S	AEC2154				
	44 Reuse Fastener S	AEC2155				
	45 Reuse PCB Spacer 4.5B	AEC2161				F

A


B

C

D

E

F



# PANEL CHASSIS SECTION PARTS LIST

Mark	No.	Description	Part No.	
NSP	1	60F ADDRESS L Assy	AWW1341	
NSP	2	60F ADDRESS S Assy	AWW1342	A
NSP	3	60F SCAN A Assy	AWW1343	
NSP	4	60F SCAN B Assy	AWW1344	
NSP	5	60F SCAN C Assy	AWW1345	
NSP	6	60F SCAN D Assy	AWW1346	
NSP	7	P. Chassis (609FE) Assy	AWU1288	
NSP	8	P. Panel (60FE) Assy	AWU1290	
	9	Reuse PCB Spacer 4.5B	AEC2161	
	10	Scan Sheet	AEH1154	
	11	Plate Holder	AMR3757	B
	12	Address Holder Assy L	AMR3758	
	13	Address Holder Assy S	AMR3759	
	14	Plate X	ANG3132	
⚠	15	Address Heatsink S	ANH1704	
⚠	16	Address Heatsink L	ANH1705	
	17	PCB Spacer (Reuse)	AEC2122	
	18	Address Silicon A	AEH1146	
	19	Address Silicon C	AEH1156	
	20	3 Piece Connector 15P (CN101)	AKM1393	C
	21	3 Piece Connector 15P (CN102)	AKM1393	
	22	•••••		
	23	•••••		
	24	Screw	ABA1351	
	25	Screw (M3 x 6) SN	ABA1366	
	26	Screw	ABA1351	
				D
				E
				F

1 2 3 4

# 9.9 MULTIBASE SECTION

A


B

C

D

E

F





MULTIBASE SECTION PARTS LIST

Mark	No.	Description	Part No.	
	1	MAIN Assy	AWW1393	
	2	FAN Assy	AWW1394	A
	3	AUDIO Assy	AWW1398	
⚠	4	AC Inlet (CN1)	AKP1336	
	5	Flexible Cable (J211)	ADD1582	
	6	Flexible Cable (J212)	ADD1583	
⚠	7	Housing Wire (J104)	ADX3607	■
⚠	8	Housing Wire (J105)	ADX3651	
	9	5P Housing Wire (J111)	ADX3697	
	10	15P Housing Wire (J110)	ADX3698	
	11	14P Housing Wire (J109)	ADX3699	B
	12	6P Housing Wire (J140)	ADX3700	
	13	6P Housing Wire (J120)	ADX3701	
	14	13P Housing Wire (J133)	ADX3702	
	15	3P Housing Wire (J134)	ADX3703	
	16	7/6P Housing Wire (J116)	ADX3704	■
	17	Wire Saddle	AEC1745	
	18	PCB Support	AEC1938	
	19	PCB Spacer (Reuse)	AEC2087	
	20	Reuse Mini Saddle	AEC2160	C
	21	Silicon Sheet MTB A	AEH1174	
	22	Silicon Sheet	AEH1177	
	23	Inlet Sheet	AMR3875	
	24	Multi Base Assy SEP	ANA2229	
	25	Terminal Panel SEP	ANC2479	■
	26	AUDIO Heatsink	ANH1723	
	27	.....		
	28	.....		
	29	Hexagon Headed Screw	ABA1382	
	30	N Grip Screw (M3 x 6)	ABA1381	D
	31	Screw	AMZ30P060FTB	
⚠	32	Screw	BMP40P080FSN	
	33	Screw	BMZ30P060FTB	
	34	Screw	BPZ30P080FTB	■
	35	Screw	PMB30P060FNI	

E


■

F


## 9.10 PDP SERVICE ASSY

### PDP SERVICE ASSY 609FE : AWU1379

#### ● Exterior Section



## ● Packing Section



## PDP SERVICE ASSY PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
NSP 1	P. Chassis (609FE) Assy	AWU1344	26	•••••	
2	Sub Frame Assy	ANA2127	27	Screw	ABA1351
3	F. Chassis VL Assy	ANA2184	28	Screw (M3 x 6) SN	ABA1366
4	F. Chassis VR Assy	ANA2128	29	Screw (3 x 25 P)	ABA1380
5	F. Chassis HT Assy	ANA2132	30	Screw	ABZ30P080FTC
6	F. Chassis HB Assy	ANA2133	31	Screw	AMZ30P060FTB
7	Plate X	ANG3132	32	Screw	APZ30P080FTB
⚠ 8	Address Heatsink S	ANH1704	33	Screw	BMZ30P080FTB
⚠ 9	Address Heatsink L	ANH1705	34	Screw	TBZ40P060FTC
10	Ferrite Core Holder	AEC1818	35	Gasket (10 x 10 x 280)	ANK2002
11	PCB Spacer (Reuse)	AEC2122	36	Gasket (15 x 55 x 30)	ANK2003
12	Address Silicon A (508)	AEH1146	37	Caution Label	AAX3031
13	Address Silicon C	AEH1156	38	Vinyl Bag	AHG1336
14	Inner Grip Assy	AMR3434	39	Pad (609 T-L)	AHA2722
15	Front Bezel Support	AMR3755	40	Pad (609 T-R)	AHA2723
16	F. Chassis H Guide	AMR3756	41	Pad (609 B-L)	AHA2724
17	Support Bracket	AMR3762	42	Pad (609 B-R)	AHA2725
18	Address Gasket	ANK1947	43	Sub Carton LR (609E)	AHC1110
19	Front Gasket H	ANK1960	44	Under Carton (609E)	AHD3666
20	Front Gasket V	ANK1961	45	Upper Carton (609SERV)	AHD3724
21	Gasket (10 x 10 x 80)	ANK1974	46	Protect Sheet	AHG1401
NSP 22	Front Bezel (609SERV)	AMB3106	47	Mirror Mat	AHG1402
23	Rear Case Assy 60	ANE1686	48	Rivet (Plastic)	AEC1877
NSP 24	Drive Voltage Label	ARW1097	NSP 49	Caution Sheet (9G)	ARM1398
25	•••••				

## Disassembly / Reassembly of the Service Panel Assy


The panel for service for the 60-inch integrated-type monitor for overseas is used as the panel for service for the 60-inch 9G monitor. Before it can be used for servicing the 9G monitor, it is necessary to replace some of its parts with those from the chassis of the panel to be repaired.

Disassemble/reassemble the panel for service in the manner shown below.

### Procedures for removing unnecessary parts

#### 1 Rear Case Assy 60

- ① Remove the four screws. (ABA1380)
- ② Remove the 38 screws. (AMZ30P060FTB)
- ③ Remove the rear case Assy 60.





The inner grip Assys do not need to be removed from the rear case Assy 60.




#### 2 Front Bezel (609SERV)

- ① Remove the five rivets.
- ② Pull the lower part of the front bezel (609SERV) toward you and out.
- ③ Remove the front bezel (609SERV), by pulling it upward.



Turn it not to press the rivet.  
(Because when the rivet presses, fit in once again.)




Front side



### 3 Sub Frame Assy


- ① Remove the four screws. (AMZ30P060FTB)
- ② Remove the 20 screws. (TBZ40P060FTC)
- ③ Remove the two sub frame Assys.



## 4 F. Chassis HT and HB Assys

### ● F. chassis HT Assy


- ① Remove the two screws. (ABZ30P080FTC)
- ② Remove the three screws. (APZ30P080FTB)
- ③ Remove the two screws. (AMZ30P060FTB)
- ④ Remove the F. chassis HT Assy.



F. chassis HT Assy

### ● F. chassis HB Assy

- ⑤ Remove the two screws. (ABZ30P080FTC)
- ⑥ Remove the three screws. (APZ30P080FTB)
- ⑦ Remove the two screws. (AMZ30P060FTB)
- ⑧ Remove the F. chassis HB Assy.




F. chassis HB Assy

## 5 F. Chassis VL and VR Assys


### ● F. chassis VL Assy

- ① Remove the two screws. (ABZ30P080FTC)
- ② Remove the one screw. (APZ30P080FTB)
- ③ Remove the two screws. (AMZ30P060FTB)
- ④ Remove the F. chassis VL Assy.



### ● F. chassis VR Assy

- ⑤ Remove the two screws. (ABZ30P080FTC)
- ⑥ Remove the one screw. (APZ30P080FTB)
- ⑦ Remove the two screws. (AMZ30P060FTB)
- ⑧ Remove the F. chassis VR Assy.





A

## 6 Support Bracket

- ① Remove the two screws. (ABA1351)
- ② Remove the two support brackets.


B

C


D

E

F



The state that removed an unnecessary parts






## Procedures for reattaching the parts from this model

(Remove the necessary parts from the panel being repaired then reattach them to the panel for service.)

### 1 Support Bracket V and Corner Spacer


- ① Tighten the two screws, and attach the two support brackets V. (ABA1351)
- ② Tighten the two screws, and attach the two corner spacer. (ABA1351)



### 2 F. Chassis HT Assy (60M) and F. Chassis HB (60M)


#### ● F. chassis HT Assy (60M)

- ① Tighten the two screws. (ABZ30P080FTC)
- ② Tighten the three screws. (APZ30P080FTB)



#### ● F. chassis HB (60M)

- ③ Tighten the two screws. (ABZ30P080FTC)
- ④ Tighten the three screws. (APZ30P080FTB)




### 3 F. Chassis V Assy (60M)

#### ● Left side


- ① Tighten the two screws. (ABZ30P080FTC)
- ② Tighten the one screw. (APZ30P080FTB)

#### ● Right side

- ③ Tighten the two screws. (ABZ30P080FTC)
- ④ Tighten the one screw. (APZ30P080FTB)



If the front bezel support (60M) is detached from the F. chassis V Assy, reattach it.



In this state, attach the Y DRIVE Assy, X DRIVE Assy, POWER SUPPLY Unit, DIGITAL Assy, and FFC and other cables. Then attach the two sub frames.

